

Any reference to Raytheon or RTN in this manual should be interpreted as Raymarine. The names Raytheon and RTN are owned by the Raytheon Company.

## SL72 and SL72RC PLUS Pathfinder Radar and Radar/Chartplotter Owner's Handbook

Document number: 81204\_1 Date:18th January 2002

## SL72 and SL72RC PLUS Pathfinder Radar Owner's Handbook

#### January 2002

#### **SAFETY NOTICES**

This radar equipment must be installed and operated in accordance with the instructions contained in this manual. Failure to do so can result in personal injury and/or navigational inaccuracies. In particular:

**1. HIGH VOLTAGE.** The LCD display unit and scanner unit contain high voltages. Adjustments require specialized service procedures and tools only available to qualified service technicians – there are no user serviceable parts or adjustments. **The operator should never remove the display unit cover or attempt to service the equipment.** 

2. ELECTROMAGNETIC ENERGY. The radar scanner transmits electromagnetic energy. It is important that the radar is turned off whenever personnel are required to come close to the scanner to perform work on the scanner assembly or associated equipment.

It is recommended that the radar scanner is mounted out of range of personnel (above head height).

Avoid looking directly at the antenna as your eyes are the most sensitive part of the body to electromagnetic energy.

When properly installed and operated, the use of this radar will conform to the requirements of ANSI/IEEE C95.1-1992 Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic Fields, 3Hz to 300 GHz and NRPB, Board Statement on Restrictions on Human Exposure to Static and Time Varying Electromagnetic Fields and Radiation. *Doc NRPB, NO. 5 (1993)*.

**2. NAVIGATION AID.** This unit is only an aid to navigation. Its accuracy can be affected by many factors, including equipment failure or defects, environmental conditions, and improper handling or use. It is the user's responsibility to exercise common prudence and navigational judgements. This radar unit should not be relied upon as a substitute for such prudence and judgement.

Raymarine products are supported by a network of Authorized Service Representatives. For information on Raymarine products and services, contact either of the following: **UNITED STATES** Raymarine Company 22 Cotton Road, Unit D Nashua, NH 03063-4219 Telephone: +1 603 881 5200 +1 800 539 5539 Fax: +1 603 864 4756 **EUROPE Raymarine Limited** Anchorage Park Portsmouth Hampshire PO3 5TD England Telephone: +44 (0) 23 9269 3611 Fax: +44 (0) 23 9269 4642

Copyright © Raymarine Ltd 2001

The technical and graphical information contained in this handbook, to the best of our knowledge, was correct as it went to press. However, the Raymarine policy of continuous improvement and updating may change product specifications without prior notice. As a result, unavoidable differences between the product and handbook may occur from time to time, for which liability cannot be accepted by Raymarine.

Raymarine is a registered trademark of Raymarine Ltd. SeaTalk is a registered trademark of Raymarine Ltd. HSB is a trademark of Raymarine Ltd. Pathfinder is a trademark of Raymarine Ltd.

This product contains technology provided under license by Acorn Group plc. The copyright of this intellectual property is acknowledged by Raymarine Ltd, as are Acorn's trademarks and patents. Acorn's world wide web address is http://www.acorn.com.

## Preface

This handbook describes the installation, operation and maintenance for the following systems:

SL72 PLUS Pathfinder Radar system SL72RC PLUS Pathfinder Radar/Chartplotter system.

These systems comprise an SL70 or SL70RC PLUS LCD display and a 2D, 18" 2kW radome scanner unit.

The handbook contains very important information on the installation and operation of your new equipment. In order to obtain the best results in operation and performance, please read this handbook thoroughly.

Raymarine's Product Support representatives or your local dealer will be available to answer any questions you may have.

#### Warranty

To register your SL72/SL72RC PLUS ownership, please take a few minutes to fill out the warranty registration card found at the end of this handbook. It is very important that you complete the owner information and return the card to the factory in order to receive full warranty benefits.

#### **EMC Conformance**

All Raymarine equipment and accessories are designed to the best industry standards for use in the recreational marine environment.

The design and manufacture of Raymarine equipment and accessories conform to the appropriate Electromagnetic Compatibility (EMC) standards, but correct installation is required to ensure that performance is not compromised.

#### **Intended Use**

The display unit detailed in this handbook may form part of navigational radar systems intended for light marine use. This radar system is only an aid to navigation.

This Page intentionally left blank.



## **RT016**

# **EC Declaration of Conformity**

We Raymarine Limited

Anchorage Park Portsmouth Hampshire England P03 5TD

declare, under our sole responsibility, that the products identified in this declaration, and to which this declaration relates, are in conformity with the essential requirements of European Parliament and Council Directive:

1999/5/EC on radio equipment and telecommunication terminal equipment and the mutual recognition of their conformity.

Product Name:

Product Number(s):

M92650, from S/n 1112000

18" Radome Scanner Unit

Raymarine 2D - 2kW (8-Pulse Width),

Ancillary Units

'PLUS' Displays - details given on Sheet 2

The products have been assessed to Conformity Procedure Annex IV of the Directive and by application of the following standard(s):

EMC Health & Safety EN 60945 : 1997 EN 60945 : 1997

The assessment is consistent with a Technical Construction File showing conformity with the essential requirements of the Directive and has been reviewed by Notified Body No. **0191** 

The product is labelled with the CE conformity marking, the identification number of the Notified Body and class identifier.

Signatory:

Name Title Company Name Company Address Adil Abbas EMC Manager Raymarine Limited Anchorage Park Portsmouth, Hampshire England PO3 5TD

Signature

Date

January 2002

Sheet 1 of 2

## **Declaration of Conformity – Schedule of Ancillary Equipment and Radar Systems**

*The following Raymarine Display Units are combined with the Raymarine* 2D – 2kW (8-Pulse Width), 18" Radome Scanner Unit (*transceiver*) *listed on Sheet 1 to form the operational radar systems given below. Details of these units are included in the Technical Construction File:* 

#### DISPLAY (one of)

Description	Designation	Part No.
Display Unit, 7" Mono LCD	SL70 PLUS	E52028
Display Unit, 7" Mono LCD/Chart	SL70RC PLUS	R58149
Display Unit, 7" Mono LCD/hsb <sup>2</sup>	RL70 PLUS	E52031
Display Unit, 7" Mono LCD/hsb²/Chart	RL70RC PLUS	E52032
Display Unit, 7" CRT/hsb <sup>2</sup>	R70 PLUS	E52039
Display Unit, 7" CRT/hsb²/Chart	R70RC PLUS	E52040
Display Unit, 10" CRT/hsb <sup>2</sup>	R80 PLUS	E52035
Display Unit, 10" CRT/hsb <sup>2</sup> /Chart	R80RC PLUS	E52036
Display Unit, 7" Colour LCD/hsb <sup>2</sup>	RL70C PLUS	E52033
Display Unit, 7" Colour LCD hsb <sup>2</sup> /Chart	RL70CRC PLUS	E52034
Display Unit, 10" Colour LCD/hsb <sup>2</sup>	RL80C PLUS	E52037
Display Unit, 10" Colour LCD/hsb²/Chart	RL80CRC PLUS	E52038

#### PATHFINDER RADAR SYSTEMS

Radar System Designation	Scanner Unit Designation	Display Unit Designation
SL72 PLUS	2D	SL70 PLUS
SL72RC PLUS	2D	SL70RC PLUS
RL72 PLUS	2D	RL70 PLUS
RL72RC PLUS	2D	RL70RC PLUS
R72 PLUS	2D	R70 PLUS
R72RC PLUS	2D	R70RC PLUS
R82 PLUS	2D	R80 PLUS
R82RC PLUS	2D	R80RC PLUS
RL72C PLUS	2D	RL70C PLUS
RL72CRC PLUS	2D	RL70CRC PLUS
RL82C PLUS	2D	RL80C PLUS
RL82CRC PLUS	2D	RL80CRC PLUS

Sheet 2 of 2

## **Contents - SL72 and SL72RC PLUS Pathfinder Radar and Radar/Chartplotter**

	Pre	face	<b>1.iii</b>
		Warranty	1.iii
		EMC Conformance	1.iii
Chapter 1:	Ove	erview	1.1
	1.1	Introduction	1.1
		General	1.3
		Features	1.4
		Operating Modes	1.4
		Heading and Position Data	1.5
	1.2	The Pathfinder Radar Display	1.6
		Pathfinder Radar Options	1.6
		Radar Functions	1.8
	1.3	The Chartplotter Display - SL72RC PLUS only	1.9
		Chartplotter Display Options	1.10
		Chartplotter Functions	1.11
	1.4	Operating Controls	1.12
		Trackpad and Cursor	1.12
		Dedicated Keys	1.14
		Soft Keys	1.14
		Pop-Up Menus	1.15
		Database Lists	1.16
Chapter 2:	Get	tting Started & Adjusting the Display	2.1
	2.1	Introduction	2.1
		Conventions Used	2.1
		Simulator	2.1
	2.2	Switching the Display On and Off	2.2
		Simulator Mode	2.5
		Changing the Lighting and Contrast	2.6
	2.3	Changing the Lighting and Contrast Controlling the Display	2.6 2.7
	2.3	Changing the Lighting and Contrast Controlling the Display Selecting the Mode of Operation	2.6 2.7 2.7

	2.4	Radar Display Control Functions	2.16
		Using the Zoom Function	2.16
		Offsetting the Center	2.17
		Hiding the Ship's Heading Marker (SHM)	2.18
	2.5	Chart Display Control Functions (SL72RC PLUS only)	2.19
		Moving Around the Chart	2.19
	2.6	Typical Chart Scenarios (SL72RC PLUS only)	2.23
		Place and Goto a Waypoint	2.24
		Make and Follow a Route	2.26
		Review Your Passage Plan	2.28
		Displaying the Radar and Synchronizing Radar & Chart	2.30
Chapter 3:	Sta	ndard Radar Operations	3.1
	3.1	Introduction	3.1
	3.2	Range Control	3.2
		Changing the Range	
		Determining Actual Radar Range	3.3
	3.3	Interpreting and Adjusting the Radar Picture	3.4
		Identifying False Echo Returns	3.5
		Adjusting Gain, Sea Clutter, Rain Clutter and Tune	3.7
		Changing the Targets Display	3.11
	3.4	Measuring Range and Bearing Using VRM/EBLs	3.13
		Measuring Range and Bearing to Target from Vessel	3.14
		Measuring Range and Bearing Between Targets (FLOAT)	3.16
		Controlling VRM/EBL Data Boxes	3.18
	3.5	Setting Guard Zones and Alarms	3.19
		Placing a Guard Zone	3.20
		Moving, Reshaping or Deleting a Guard Zone	3.21
		Controlling Guard Zone Alarms	3.22
Chapter 4:	Inte	egrated Radar Operations	4.1
	4.1	Introduction	4.1
	4.2	Changing the Heading Mode	4.2
		True and Relative Motion	4.2

	4.3	Using Marks	4.4
	4.4	Man Overboard (MOB)	4.5
	4.5	Cursor Echo	4.6
Chapter 5:	Sta	ndard Chart Operations (SL72RC PLUS only)	5.1
	5.1	Introduction	5.1
	5.2	Using Chart Cards	5.2
		Inserting a Chart Card	5.2
		Removing a Chart Card	5.3
		Displaying the Chart Data	5.3
		Displaying Object Information	5.4
	5.3	Working with Waypoints	5.8
		Introduction	5.8
		Placing a Waypoint	5.9
		Selecting a Waypoint	5.12
		Waypoint Data Display	5.12
		Editing the Waypoint Details	5.13
		Erasing a Waypoint	5.14
		Moving a Waypoint	5.14
		Using the ST60 or ST80 Navigator Keypad	5.15
	5.4	Working with Routes	5.18
		Creating a New Route	5.19
		Saving the Current Route	5.22
		Clearing the Current Route	5.23
		Retrieve a Route From the Database	5.23
		Displaying Route Information	5.24
		Using the Route List to Erase and Name a Route	5.26
		Editing a Route	5.27
	5.5	Following Routes and Going to Points	5.30
		Follow a Route	5.30
		Target Point Arrival	5.32
		Other Follow Route Options	5.32
		Going To an Individual Target Point	5.33
		Stop Follow or Stop Goto	5.34

	5.6	Transferring Waypoints and Routes	5.35
	5.7	Using Tracks	5.38
		Setting Up a Track	5.39
		Clearing the Current Track	5.40
		Managing Tracks	5.40
		SmartRoute	5.42
Chapter 6:	Fur	ther Chart Operations (SL72RC PLUS only)	6.1
	6.1	Introduction	6.1
	6.2	Measuring Distances Using the VRM/EBL Key	6.2
	6.3	Alarms and Timers	6.4
		Alarm Reporting	6.4
		Setting Alarms and Timers	6.5
	6.4	Man Overboard (MOB)	6.6
	6.5	Cursor Echo	6.7
	6.6	GPS Setup	6.8
	6.7	Data Log Mode	6.10
Chapter 7:	Set	ting Up the System Defaults	7.1
	7.1	Introduction	7.1
	7.2	Changing the Set Up Parameters	
	7.3	System Set Up Parameters	7.4
		Data Boxes	7.6
		Bearing Mode	
		Cursor Reference	7.6
		Cursor Readout	7.7
		Day/Night	7.7
		Help	7.7
		Soft Keys	7.7
		Key Beep	7.7
		MOB Data	7.7
		Menu Timeout Period	7.7
		Units	7.8
		Variation Source	
		Bridge NMEA Heading	7.9

		NMEA Out Set Up	7.9
		Data Selection - SL70 PLUS only	7.9
		Cursor Echo	7.9
		Date and Time Settings	7.10
		GPS SOG/COG Filter - SL72RC PLUS only	7.10
		Compass Set Up - SL72RC PLUS only	7.10
		Language	7.10
		Simulator	7.11
	7.4	Radar Set Up Parameters	7.12
		EBL Display	7.12
		Timed Transmission Option	7.13
		Marks Options	7.13
		Custom Scale	7.13
		Bearing Alignment	7.14
		Antenna Size	7.14
		Send on HSB	7.14
	7.5	Advanced Settings	7.15
		Display Timing	7.15
		STC Preset	7.16
		Tune Preset	7.16
	7.6	Chart Set Up Parameters - SL72RC PLUS only	7.17
		Customize Chart	7.17
		Plotter Mode	7.18
		Chart Orientation	7.18
		Object Information	7.19
		Waypoint Options	7.19
		Vectors	7.19
		Radar/Chart Synch	7.19
		Datum Selection	7.19
		Position Offset	7.20
Chapter 8:	Inst	tallation	8.1
	8.1	Introduction	8.1
		Planning the Installation	8.2
		EMC Installation Guidelines	8.2

	8.2	Unpacking and Inspecting the Components	
	8.3	Selecting the Scanner Unit Location	8.5
	8.4	Selecting the Display Unit Location	8.9
	8.5	Cable Runs	8.11
		Power Cable	8.12
		Inter-Unit Scanner Cable	8.13
	8.6	Securing the Radome Scanner to the Mounting Surface	8.15
	8.7	Connecting the Inter-unit Cable to the Scanner	8.16
	8.8	Mounting the Display Unit	8.19
	8.9	System Connections	8.21
		Display Unit Connection	8.22
		Scanner Connection	8.23
	8.10	Radar System Tests and Post Installation Alignment	8.25
		System Check	8.25
		Switch On and Initial Setup	8.25
		Radar System Checks and Adjustments	8.26
		EMC Conformance	8.29
	8.11	Integrated Systems	8.30
		SeaTalk® and NMEA In	8.31
		Using the SeaTalk Auxiliary Junction Box	8.34
		Data Output	8.35
		Data Conversion	8.36
	8.12	Integrated System Checks	8.37
		Chart Display - SL72RC PLUS only	8.37
		Received Data	8.37
		Transmitted Data	8.37
Chapter 9:	Mai	ntenance and Problem Solving	9.1
	9.1	Maintenance	
		Routine Checks	
		EMC Servicing and Safety Guidelines	
	9.2	Resetting the System	
	9.3	Problem Solving	
		Technical Support:	

	Index	1.i
Appendix E:	Abbreviations	E.1
Appendix D:	SeaTalk and NMEA Data Received and Transmitted	D.1
Appendix C:	C-MAP Chart Card Features - SL72RC PLUS only	C.1
	Raystar 112, 105, Apelco 182 and 182X1 Raystar 120 WAAS Satellite Differential Receiver	B.2 B.6
Appendix B:	Using the Auxiliary Junction Box	B.1
	SL72 PLUS and SL72RC PLUS 7" Displays	A.3
	2D 18" Radome Scanner Unit	A.1
Appendix A:	Specification	A.1
	Worldwide Support	9.6
	How to Contact Raymarine (Europe)	9.6
	How to Contact Raymarine (US)	9.5

## **Chapter 1: Overview**

## **1.1 Introduction**

This handbook describes the Raymarine SL72 PLUS Pathfinder Radar and SL72RC PLUS Pathfinder Radar/Chartplotter system. It gives details for installation, operation and maintenance of the systems.

**Note:** Many illustrations in this handbook show example screens. The screen you see on your display depends on your system configuration and set up options, so it may differ from the illustration.

### How to Use This Handbook

If you are installing the display system yourself, you should read *Chapter 8* before you start the installation. This chapter also provides information that will be useful if you are connecting your system to other equipment.

For an overview of the display unit controls, read *Chapter 1*. *Chapter 2* will help you start using your system.

For detailed information on radar operations refer to Chapter 3 and Chapter 4.

If you have an SL72RC PLUS, refer to *Chapter 5* and *Chapter 6* for chartplotter operating details.

To change the system set up defaults, read Chapter 7.

Details on installing your display unit and radar scanner are given in *Chapter 8*.

The handbook is organized as follows:

**Chapter 1** provides an overview of the features and functions of the LCD Display. This chapter also provides an overview of the controls. You should read this chapter to familiarize yourself with the system.

**Chapter 2** explains how to start using the display and describes how to use some of the basic radar, and SL72RC PLUS chartplotter functions.

**Chapter 3** provides detailed operating information for the main radar functions - adjusting the radar picture; measuring distances and bearings; setting guard zones and alarms.

**Chapter 4** provides detailed operating information for integrated radar system functions, including using marks, man overboard and cursor echo.

**Chapter 5** provides detailed operating information for standard chartplotter functions - using chart cards, plotting waypoint and routes, following routes, and using tracks.

Introduction

**Chapter 6** provides detailed operating information for further chart functions including measuring distances, man overboard and cursor echo. It includes instructions for setting up a differential GPS.

**Chapter 7** provides instructions for setting up your system to suit your preferences. You should read this chapter to determine how to set up the radar system defaults.

**Chapter 8** provides planning considerations and detailed instructions for installing the display unit and scanner. It should be referred to when you are ready to install the system. Details to connect the display to other equipment are also provided.

**Chapter 9** provides information on user maintenance, and what to do if you experience problems.

The Appendices provide additional information that you may find useful: **Appendix A** lists the technical specifications for the radar and chartplotter. **Appendix B** provides details on connecting the display unit to specific GPS systems.

**Appendix C** defines the chart features shown on the chart display. **Appendix D** defines the SeaTalk and NMEA data that is transferred on integrated systems.

Appendix E provides a list of Abbreviations.

An Index and warranty information are included at the end of the handbook.

A summary of the radar and chart controls are provided on the Quick Reference Card(s) supplied with your system.

#### Terminology

The following terminology is used to describe radar systems:

Master	A unit capable of sourcing radar data
Integrated System	Additional instruments are connected via the Seatalk or NMEA interfaces.

Introduction

### General

The SL72 PLUS Pathfinder Radar or SL72RC PLUS Radar/Chartplotter illustrated below, comprises an SL70 or SL70RC PLUS display unit, 2D 18" 2 kW scanner unit and associated cables.



Figure 1-1: SL72/SL72RC PLUS Radar/Radar-Chartplotter System

#### **Display Unit**

The LCD display unit is waterproof to CFR46 and can be installed either above or below deck.

The unit includes:

- 7" monochromeLCD display
- Trackpad
- Eleven dedicated (labeled) control keys
- Four soft keys (unlabeled) whose functionality changes
- The SL72RC PLUS includes two slots for the C-MAP NT<sup>®</sup> chart cards

The display and keys can be illuminated for night-time use.

Full functionality of the radar or radar/chartplotter is achieved when it is part of an integrated system, with other equipment connected via SeaTalk or NMEA 0183. Data from this equipment including position and heading is displayed on the display and is used in calculations. Details on connecting other equipment are given in *Chapter 8*.

#### Scanner

The SL72 PLUS and SL72RC PLUS are supplied with an 18", 2 kW (2D) scanner unit which illuminates targets with microwave energy and then collects the returns from those targets. The scanner includes a sensitive low-noise front end receiver, and a variety of clutter attenuation controls to maintain target resolution.

The scanner is adjusted and operated from the display unit. It can be switched between transmit and standby modes. The scanner also has a power-saving timed transmit mode which pauses between bursts of transmissions.

#### Features

#### **Radar Features**

- Uses position information from GPS, DGPS or Loran-C technology
- Displays and transfers SeaTalk and NMEA data
- Half-screen windows to display Course Deviation Indicator (CDI), Bearing and Distance Indicator (BDI) or navigation data
- Cursor echo across SeaTalk
- Choice of orientation: Head Up, Course Up and North Up

#### **Chartplotter Features (SL72RC PLUS only)**

- Displays chart information from the C-MAP NT<sup>®</sup> chart cards (C-Cards)
- Three full screen operating modes Radar, Chart and Data Log.
- View radar and chart simultaneously in half-screen windows
- Can be connected to an ST80 Navigator keypad for alpha-numeric data entry.

#### **Set Up Options**

Set up options allow you to choose what is displayed, how it is displayed (including language and units), and bearing mode. You can view the cursor position and a variety of data from other equipment in a set of user-selectable data boxes, for example, speed, heading, depth, wind and tide information.

Display options are provided in System Set Up, described in *Chapter 7*. Screen Presentation options, described in *Chapter 2* allow you to switch the cursor and data boxes On/Off. The cursor box and user-selected data boxes can be moved around the screen.

### **Operating Modes**

On an SL72 PLUS you can view full screen radar; on an SL72RC PLUS you can view a full screen radar, chart or data log. You can also set *Windows On* to split the display into two half-screen windows to show supplementary data or, on a combined display unit, display radar and chart simultaneously. The main operating mode (radar or chart) is displayed in the upper window; you choose what is displayed in the lower window.

Table 1-1:	Operating Modes and Windov	perating Modes and Window Options	
Display	Full-screen mode	Half-screen Window Options	
SL72 PLUS	Radar	CDI, BDI or Nav Data	
	Radar Mode	CDI, BDI, Chart or Nav Data	
SL72RC PLUS	Chart Mode	CDI, BDI, Radar or Nav Data	
	Data Log Mode	Windows not available	

The following are available:

## Half -Screen Window Options

- Radar Display, Chart Display: If data is available as a function of the combined display unit it can be displayed full screen or in a half screen window.
- **CDI:** This gives the Course Deviation Indicator graphical display, with data relating to the target waypoint (if available on SeaTalk).
- **BDI:** This gives the Bearing and Distance Indicator graphical display, with data relating to the target waypoint (if available on SeaTalk).
- Nav Data: This shows nine data boxes, providing navigational data (from SeaTalk or NMEA) in the units specified in your set up. Note that up to 6 of these data boxes are also available as a *user-selectable group* (see *Section 7.3*).

## **Heading and Position Data**

Full functionality of the radar/chartplotter is achieved when it is part of an integrated system with other equipment connected via SeaTalk or NMEA 0183. Data from this equipment including position and heading is shown on the display and is used in calculations.

Details on connecting other equipment are given in Chapter 8.

## **1.2 The Pathfinder Radar Display**

When a scanner is connected and the radar is in Transmit mode, the radar picture provides a map-like representation of the area in which the radar is operating. Typically, your ship's position is at the centre of the display, and its dead ahead bearing is indicated by a vertical heading line, known as the Ship's Heading Marker (SHM).

The radar picture can be viewed with a variety of fixed or customised range scales. A status bar at the top of the radar image displays range, current heading and mode indicators for the various options you can set. An example radar picture is shown in *Figure 1-2*, with example radar returns (echoes) and default Pathfinder Radar information. The Status Bar indicator is also illustrated.

The radar display can show additional information, depending on your currently selected options, set up selections and the data available from other equipment. The example displays on the following pages show some of these features.

Functions are available to control the display as follows:

- Zoom the Display
- Offset your vessel from the centre of the radar picture

Operation of these functions is described in Chapter 2.

### **Pathfinder Radar Options**

Set up options allow you to customise the radar image by choosing what is displayed, how it is displayed (including language and units) and heading mode. You can also view the cursor position and a variety of data from other equipment, e.g. speed, heading, depth, wind and tide information in a set of user-selectable data boxes. The cursor box and user-selected data boxes can be moved around the screen and they can be turned on or off.

Display options are provided in System Set Up and Radar Set Up as described in *Chapter 7:Setting Up the System Defaults*. In addition, Screen Presentation Options, described in *Chapter 2:Getting Started & Adjusting the Display* are provided to switch:

- Cursor Box and Databoxes On/Off
- Range Rings On/Off
- Waypoint Display On/Off

**Note:** When you switch the display off and on again, these settings are retained in memory.

1-6





Figure 1-2: Radar Display Features

nder Rada

Options



Figure 1-3: Typical Radar Picture

## **Radar Functions**

The SL72 and SL72RC PLUS Pathfinder Radars include the following functions:

- Choice of range scales from 1/8 nm to 24nm.
- Automatic and manual control of tuning, gain and sea clutter.
- Two Variable Range Markers (VRMs) and Electronic Bearing Lines (EBLs), allowing target range and bearing measurements. VRM/EBLs can be floated.
- Target wakes and target expansion mode.
- Two guard zones with alarms.
- Add marks to record important or dangerous locations.
- Man Overboard (MOB) to navigate back to a person or object.

Operation of these functions is described in Chapter 3 and Chapter 4.

## 1.3 The Chartplotter Display - SL72RC PLUS only

The SL72RC PLUS Display includes a Chartplotter. The chartplotter includes a small-scale world map and detailed navigation information is displayed when a cartographic chart card is installed. The details displayed depend on the chart zoom level selected. A plotter mode is provided to enable route plotting and tracking at large scales even when a chart card is not installed, or when the chart is zoomed beyond the available cartographic detail. A typical chartplotter screen is shown in *Figure 1-4*.

The chartplotter uses position information from a GPS, DGPS, WAAS or Loran-C instrument. Once the position fix has been established, your vessel's position, if on screen, is shown as a boat shape pointing in the direction of the current heading (or COG if heading data is not available). If no heading or COG data is available, the vessel is shown as a circle.

The chartplotter screen includes a status bar that displays chart scale, with either cursor position, range and bearing or, when the cursor is homed to the vessel (by pressing FIND SHIP), vessel position, Speed Over Ground (SOG), Course Over Ground (COG) and fix type (VES POS, DIF FIX or SD FIX).

Any waypoints you have placed are displayed (unless you turned them off in Chart Set Up as described in *Chapter 7*) and the current route is shown. Information can be viewed on-screen by positioning the cursor over a waypoint, current route or chart object. The chartplotter screen can also show additional information, depending on your currently selected options, set up selections and data available from other equipment.

An example chart display, in its default configuration, with a chart card installed, is shown in the following illustration.

Several functions are available to control the display as follows:

- Zoom in/out and Pan the Display
- Offset the Chart or Center the Chart around the Vessel
- Synchronize the Chart and Radar (if radar data is available)

Operation of these functions is described in *Chapter 2*.

The Chartplotte Display - SL72R( PLUS only

## **Chartplotter Display Options**

In addition to the display set up options previously described, chart set up options, described in *Chapter 7*, allow you to customize the chart by selecting:

- What cartographic features and level of detail are displayed.
- Chart orientation (north up, head up or course up), datums and position offset.
- How waypoints are displayed (symbols and numbers).
- Vectors for heading, COG and tide.

The Screen Presentation Options, described in *Chapter 2* allow you to switch the Chart Grid On/Off and Custom Chart Details On/Off.

**Note:** When you turn the display off and on again, the Screen Presentation settings are retained in memory.



Figure 1-4: Typical Chartplotter Display

#### **Custom Chart Details**

The chartplotter set up options include a sub-menu to customize the cartographic features. This menu allows you to switch features On, Off, or control them using the CUSTOM soft key. The factory default settings for the Custom chart options are as follows:

- ON: Chart text, chart boundaries, depth contours, navigation marks and land features.
- OFF: Caution and routing data.

CUSTOM: Spot sounding, light sectors, marine features.

Note: The factory default for the CUSTOM settings is ON.

Icons are displayed in detail, depth shading limit is 10 m and depth contour display is 0-100 m.

A complete list of chart features is given in Appendix C.

## **Chartplotter Functions**

The SL72RC PLUS Chartplotter includes the following functions:

- Display C-MAP NT C-Card chart information including Ports and Tides (if available)
- View chart information (if available) for the Nearest Port
- Place, Move, Erase and Edit a Waypoint
- Goto Waypoint or Cursor
- Create, Save, Name, Edit and Follow a Route
- Review Route and Waypoint Lists
- Display vessel's track; Save and Name the Track for re-call to screen
- SmartRoute to make a track into a route
- Measure Chart Distances and Bearings on-screen
- Set Up Alarms and Timers
- Man OverBoard (MOB) to navigate back to a missing person or object
- Differential GPS set up page

Operation of these functions is described in Chapter 5 and Chapter 6.

## **1.4 Operating Controls**

You operate the radar system using a variety of controls:

- A trackpad providing up, down, left, right and diagonal control of an on screen cursor.
- Eleven dedicated (labeled) control keys.
- Four soft keys with labels displayed on the screen.
- Pop-up menus, displayed on-screen, from which you select options.
- Database lists, displayed on-screen, which enable you to edit items.

**Note:** The cursor is the cross-hair symbol (+) visible on the display. You move the cursor using the trackpad and use it to select a position or item on the chart.

The control keys are shown in *Figure 1-5*. They are back-lit for night-time use. When you use a control, a help message is displayed at the top of the screen (unless you switch help off as described in *Chapter 7*). The following paragraphs describe the controls and on-screen facilities.



Figure 1-5: LCD Display Control Keys

#### **Trackpad and Cursor**

The trackpad has several functions:

- To move the cursor around the screen
- To select an item from a pop-up menu
- To adjust a variable soft key control

The cursor is used to:

- Select a position on the screen.
- Select an item, e.g.guard zone on the display.
- Select an area of the radar image to zoom into.

#### **Moving the Cursor**

You can press on any of the four sections of the trackpad to move the cursor in that direction (up, down, left or right), or press two sections at the same time to move diagonally. The cursor moves faster as you continue to press the trackpad. The current cursor position is shown in the cursor data box (if selected).

**Note:** During many operations you cannot move the cursor around the screen; if you cannot move the cursor using the trackpad, check the default soft keys are displayed (unless they have been switched OFF in system set up). If not, press **ENTER** until they are displayed.

The cursor is normally displayed as a crosshair.

#### **Context-Sensitive Cursor Control**

The cursor is context-sensitive. When the cursor is positioned over special features on the display a text label appears to identify the feature as follows:

Text Label	Feature	Radar/Chart (SL72RC PLUS only)
BOX	Data box (any type)	Both
МОВ	Man Over Board marker	Both
MRK	Radar Mark	Both
WPT	Chart Waypoint	Both
CTR	Centre of radar	Radar
FLT	Floating EBL/VRM	Radar
GRD	Guard zone	Radar
SHM	Ships Heading Marker	Radar
VRM/EBL	VRM and EBL, 1 or 2	Radar
ZMB	Zoom box	Radar
A™⇒B	Ruler line	Chart
COG	Course Over Ground vector	Chart
HDG	Heading vector	Chart

Table 1-2: Context-Sensitive Cursor Text Labels

Text Label	Feature	Radar/Chart (SL72RC PLUS only)
POS	Vessel's position	Chart
RTE	Route leg	Chart
TIDE	Tide vector	Chart

Table 1-2: Context-Sensitive Cursor Text Labels

Some items on the screen, such as the cursor have information associated with them. Most information is displayed in a data box. The context-sensitive cursor allows you to move databoxes.

#### **Dedicated Keys**

The dedicated keys: **DISPLAY, MARKS, GAIN, VRM/EBL, MULTI, ALARMS, RANGE, ENTER, CLEAR, MENU** and **POWER** have fixed functions.

Some keys can be used in two ways:

- **Press:** Press the key momentarily and then release it. This method is used for most key operations.
- **Press and hold:** Press the key and hold it down for the length of time stated (for example, 3 seconds), and then release it.

When you press a dedicated key, one of the following happens:

- i. The associated operation is actioned, e.g. change range (**RANGE**).
- ii. A pop-up menu is displayed, providing further options.
- iii. A set of soft keys is displayed, providing further functions.

As you press a key, a single audio beep confirms the key action. If the keypress is not valid for the current screen or mode, three rapid beeps sound to indicate that no response is available. If required, you can turn the key beeps off as part of your set up procedure (see *Chapter 7*).

#### Soft Keys

The four keys below the screen are called soft keys because their functions change according to the operation. The soft keys are grouped into related sets and subsets providing access to the various functions. The soft key labels are displayed on the screen just above the keys. The default soft keys (illustrated below) are displayed until you press a key, or select an item on the screen; the soft keys associated with the action are then displayed.

The currently selected soft key option is shown by its graybackground. If the key text is displayed in gray rather than in black, it is not currently available.

When you press a soft key one of the following happens:

- i. The associated operation is actioned, e.g. NORTH UP.
- ii. A sub-set of soft keys is displayed, providing further functions.
- iii. A pop-up menu is displayed, providing further options.

As with dedicated keys, when you press a soft key a single audio beep confirms the key action. If the key-press is not valid for the current screen or mode, three rapid beeps sound to indicate that no response is available. If required, you can turn the key beeps off as part of your set up procedure (see *Chapter 7*).

#### **Pop-Up Menus**

Pop-up menus usually provide set up options. When a pop-up menu is onscreen, a set of associated soft keys is also displayed as shown in *Figure 1-6*.

RADAR SET	up menu
EBL DISPLAY	RELATIVE
TIMED TRANSMIT	OFF
TRANSMIT PERIOD	20 SCANS
STANDBY PERIOD	10 MINS
DEFAULT MARK SYMBOL	×
MARK DISPLAY	OFF
CLEAR MARKS	
CUSTOM SCALE	OFF
BEARING ALIGNMENT	

Figure 1-6: Typical Pop-up Menu

You use the trackpad to select an option from the menu, then use the appropriate soft key to set the option. For example, you can toggle TIMED TRANSMIT on/off.

1-15

### **Database Lists**

The waypoints, routes and tracks that you create on the SL72RC PLUS chartplotter are stored in database lists. You can view these lists and select items for editing.

SYMBOL  NAME    Image: Maypoint on the symbol  Structure    Image: Maypoint on the symbol	SYMBOL  NAME    Image: Marge of the symbol  Name    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol    Image: Marge of the symbol  Marge of the symbol	WAYPOI	NT LIST
Image: Waypoint ool    X  Waypoint oo2    X  Waypoint oo2    X  Waypoint oo3    X  Waypoint oo3    X  Waypoint oo4    X  Waypoint oo5    POSITION  50°21'966N 001°20'368W    BRG_1186°  BRG_21.0nn    TEMP  DEPTH m    DATE  TIME	Видеротит  Мачеротит  001    К  Мачеротит  002    К  Мачеротит  003    К  Мачеротит  004    К  Мачеротит  004    К  Мачеротит  005    POSITION  50°21/966N  001°20/368W    BRG  _186°  BRG  _21.0nn    TEMP C  DEPTH m    DATE   TIME     GOTO  EDIT  MAKE  NEW  WAYPOTUT	SYMBOL	NAME
X  WAYPOINT 002    X  WAYPOINT 003    X  WAYPOINT 004    X  WAYPOINT 005    POSITION  50°21:966N 001°20:368W    BRG _186°  BRG _21.0nm    TEMP     DATE	X  WAYPOINT 002    X  WAYPOINT 003    X  WAYPOINT 004    X  WAYPOINT 005    POSITION  50°21'966N 001°20'368W    BRG     BRG     BRG     DATE     COTO  EDIT    MAKE  NEW    WAYPOINT  TRANS	Ŷ	WAYPOINT 001
X  WAYPOINT 003    X  WAYPOINT 004    X  WAYPOINT 005    POSITION  50°21'966N 001°20'368W    BRG _186°  BRG _21.0nm    TEMP     DATE	X  WAYPOINT 003    X  WAYPOINT 004    X  WAYPOINT 005    POSITION  50°21:966N 001°20:368W    BRG     BRG     DATE     ZOTO  EDIT  MAKE  NEW  WAYPOINT	<b>x</b>	WAYPOINT 002
X  WAYPOINT 004    X  WAYPOINT 005    POSITION  50°21'966N 001°20'368W    BRG _186°  BRG _21.0nm    TEMP     DATE	X  WAYPOINT 004    X  WAYPOINT 005    POSITION  50°21/966N 001°20/368W    BRG  186°  BRG  21.0nn    TEMP C  DEPTH m    DATE   TIME     GOTO  EDIT  MAKE  NEW  WAYPOINT	X	WAYPOINT 003
X  WAYPOINT 005    POSITION  50°21'966N 001°20'368W    BRG _186°  BRG _21.0nm    TEMP°C  DEPTHm    DATE  TIME	X  WAYPOINT 005    POSITION  50°21:966N 001°20:368W    BRG _186°  BRG _21.0nn    TEMP°C  DEPTHm    DATE  TIME    30T0  EDIT MAKE NEW WAYPOINT TRANS	<b>X</b>	WAYPOINT 004
POSITION  50°21/366N 001°20/368W    BRG_186°  BRG_21.0nn    TEMP •C  DEPTHm    DATE   TIME	POSITION  50°21'966N 001°20'368W    BRG_186°  BRG_21.0nH    TEMP °C  DEPTHm    DATE °C  TIME m    GOTO  EDIT  MAKE  NEW  WAYPOINT	X	WAYPOINT 005
BRG _186°  BRG _21.0nm    TEMP°C  DEPTHm    DATE  TIME	BRG186°  BRG21.0nн    TEMP°C  DEPTHm    DATE  TIME    JATE  TIME    GOTO  EDIT    YPOTNT  MAKE NEW	POSITION	50°21/966N 001°20/368W
TEMP•C DEPTHm DATE TIME::	TEMPO DEPTHM DATE TIME::_ GOTO EDIT MAKE NEW WAYPO (POTNT WAYPOTNT TRANS	BRG _186°	BRG _21.Onm
DATE// TIME::	DATE TIME::	TEMP°C	DEPTHm
	30TO EDIT MAKE NEW WAYPO	DATE/	TIME::

Figure 1-7: Typical Database List

As with pop-up menus, when a database list is on-screen, a set of associated soft keys is also displayed; you use the trackpad to select an item from the list, then use the appropriate soft key to edit the item. For example, you can erase a waypoint or a route.

## Chapter 2: Getting Started & Adjusting the Display

### 2.1 Introduction

This chapter provides information and instructions to get you started using the SL72 or SL72RC PLUS display. It will help you to become familiar with the display and the functions of the controls before you start using the unit. More detailed information on operating the radar display is provided in *Chapter 3* and *Chapter 4*. Chartplotter operating details are given in *Chapter 5* and *Chapter 6*.

### **Conventions Used**

Throughout this handbook, the dedicated (labelled) keys are shown in bold capitals; for example, **MENU**. The soft key functions, menu names and options are shown in normal capitals; for example, **SCREEN**.

Operating procedures, which may consist of a single key-press or a sequence of numbered steps, are indicated by a > symbol in the margin. When the procedure requires you to press a soft key, the soft key icon is shown in the margin.

#### Simulator

The display unit includes a simulator function, that allows you to practice operating your radar or Chartplotter without data from the scanner or GPS system. You will need to use the set up options to switch the display to simulator mode, as described in *Section 2.2*. You can use it in either of two ways:

- Before the display unit has been installed on your vessel. In this case, you only need to connect the display to a 12V or 24V DC power supply, connecting the red core from the power lead to positive (+) and the black core to negative (-). See *Chapter 8* for full details.
- After the display has been installed on your vessel, but while in the marina or at anchor.

The following section, *Section 2.2*, includes instructions to view simulated radar and chart images.

## 2.2 Switching the Display On and Off

If you have a combined Radar/Chartplotter, the factory default power-up mode is radar. Once you have used the display unit it powers-up in the last used mode. The following sections describe the power-up sequence in radar and chart modes, how to adjust the lighting and how to select simulator mode.

#### **Radar Mode**

This section explains how to switch the radar display and scanner on and off, and how to switch the scanner between Transmit, Standby and Scanner Off mode.

You normally operate your radar in transmit mode, but you can use the display unit without the scanner operating as follows:

**Standby mode**: You should use this mode when you are not operating the radar for short time periods. The scanner does not transmit and the antenna does not rotate, so the radar uses less power. However, the scanner remains powered so when you return to transmit mode, the magnetron does not need to warm up.

**Scanner off mode**: You should use this mode when you do not require the radar, but you are using the display unit say, for chart data or data from another source. Scanner off mode removes power from the scanner.

➤ To switch the display on, press and hold the **POWER** key until the unit beeps. If the unit was last used in Radar mode, the keys light up, the display shows the Pathfinder graphic, followed by the start-up information illustrated below, and the radar starts the magnetron warm-up sequence.



Figure 2-1: Switching on the Radar Display

After 70 seconds, when the magnetron warm-up sequence is complete, the Standby screen is displayed, with the text STANDBY and a prompt to press the **POWER** key to enter Transmit mode.

To switch the radar scanner from Stand-by mode to Transmit mode, press the **POWER** key.

The scanner transmits pulsed energy while it rotates, and the antenna sweep builds up the radar picture using echoes returned from targets.



Figure 2-2: Radar Transmit Mode

- You can switch on and adjust the display backlighting and contrast, if required, as described later in this chapter.
- To switch to Stand-by mode, press the **POWER** key. The display returns to the Stand-by screen, and the scanner transmission and rotation stops.
- ► To use Scanner off mode:
  - 1. Ensure that the radar is in Standby mode, warming up, or displaying a message that radar data is not available.
  - 2. Press the **CLEAR** key. The message **STANDBY**. **RADAR DATA NOT AVAILABLE** appears in the radar picture. The scanner is powered down and the timer, if running, is cleared.

To return to radar operation, press the **POWER** key. The warm-up countdown is displayed and the radar goes into Standby mode. You press **POWER** again to switch to Transmit mode when required.
#### Chart Mode - SL72RC PLUS only

To switch the display on, press and hold the **POWER** key until the unit beeps. If the display was last used in chartplotter mode, the keys light up and the Raychart graphic is displayed, followed by the caution:

#### **CAUTION:**

Raychart chart displays are based on cartographic data that C-MAP believes to be accurate. However, you should not rely on these displays as your primary source of navigation. Rather, your Raychart should be used only as a backup to official government charts and traditional methods of navigation.

When you have read and understood the caution, press the CONTINUE soft key. The chart is displayed.

If this is the first time the chartplotter has been turned on, and no chart card is installed, the display shows the small-scale world map and the default soft keys. Otherwise, the display shows the selected chart area and any data that were displayed when the display was last used.



Figure 2-3: Switch On - Chart Mode

### Switch Off

To switch the scanner and display unit off, press and hold the **POWER** key for three seconds. A countdown timer is displayed as shown below:



Figure 2-4: Switch Off

When the counter reaches zero a beep sounds, and the display unit switches off. Release the **POWER** key.

Note: Switch the display unit off before you remove the power cord.

**Note:** You do not need to change to Standby mode before turning off the display: if you turn the radar display off while it is in Transmit mode, the scanner is also de-activated.

## **Simulator Mode**

When simulator mode is on a simulator data box is displayed.

When the display is switched off then on again, simulator mode is maintained. It is recommended that you select the System Set Up Menu and switch off simulator mode when you have finished.

- SYSTEM SET UP...
- ► To view a simulated image:
  - 1. Press **MENU** followed by the SYSTEM SET UP soft key. The set up menu pop-up is displayed.
  - 2. Use the trackpad to move the selection bar over the option SIMULATOR. The simulator soft keys are displayed.
  - 3. In the system set up menu, press RADAR to view a simulated radar image, DATA to view simulated data or the chart display with simulated position, or BOTH to view simulated radar and chart data.
  - 4. Press **ENTER** twice to return to the default display.

**Note:** Any waypoints placed on the chartplotter in simulator mode are retained in the database list and are available for use in routes. Simulator Mode

## **Changing the Lighting and Contrast**

You can change the level of backlighting and contrast for the screen and keys. The key lighting is set the same as the screen lighting, except that it remains switched on at its lowest level even when the screen lighting is turned off, so that you can always find the keys.

- ► To change the lighting and contrast:
  - Press the **MULTI** key to display the soft key controls: The last-used soft key is highlighted in inverse video (white text on a black background).

If you press **MULTI** during the magnetron warm-up sequence countdown, only the LIGHT and CONTRAST sliders are displayed, and the lighting is automatically switched on at its last-used level.

2. Press the LIGHT soft key if it is not already highlighted. Alternatively, you can press the trackpad left and right edges to move sideways between the controls to select the LIGHT soft key.







- 3. The LIGHT soft key toggles lighting ON/OFF.
- 4. Use the trackpad (up or down) to increase or decrease the setting, selecting one of the eight lighting levels. You can press and hold the trackpad to change the setting more rapidly. The lighting level is adjusted as you change the setting.



- 5. Press the appropriate soft key, or the right arrow on the trackpad, to select the CONTRAST control. Adjust the setting in the same way as for the light-ing. There are 64 different contrast levels.
- 6. Press **ENTER** to remove the soft key sliders and return to the default screen, with the new lighting and contrast levels retained, or press **CLEAR** to discard the changes and return to the default screen.

If lights are left ON when you switch off the display, the next time the display is switched on, the lights will be ON, but at the default setting of 40%. The new contrast level is retained until you reset it, unless you set the control very low or very high; in this case, the contrast will be restored as follows:

Contrast set < 30% restored to 30% Contrast set > 70% restored to 70%

## 2.3 Controlling the Display

You control the display using the cursor and control keys. You start all operations from the default screen, that is the default soft keys are displayed:

#### Chart (SL70RC only)



Radar



When you have completed an action using the soft keys, press **ENTER** or **CLEAR** to return to the default screen; you may need to press **ENTER** or **CLEAR** several times to back-track through the soft key hierarchy.

**Note:** If you have set up your system so that the default soft keys are not displayed all the time, press any soft key to display the labels.

The remainder of this section describes how to select the mode of operation and switch half-screen windows on/off. The following sections describe how to set up the display for the Radar and for the Chart.

The controls are summarized in the fold-out illustration on pages 2-11 and 2-12.

## **Selecting the Mode of Operation**

You use the **DISPLAY** key to select the full-screen mode.

On the SL72RC PLUS, if the data is available on your system, the following modes (described on *Operating Modes* on *page 1-4*) can be selected:

- Radar
- Chart
- Data log

The **DISPLAY** key also accesses the soft keys for the half-screen window options.



➤ To change the mode, press the **DISPLAY** key to show the DISPLAY pop-up, then press again to cycle through the modes available, shown in the *Figure 2-5*.



Figure 2-5: Using the DISPLAY Key

The selected mode is shown by an icon with a red border and the mode is displayed on the screen. The associated half-screen window soft keys are also displayed.

When the required mode is shown, press **ENTER** or **CLEAR**. The default soft keys are displayed. The selected mode is shown full-screen; in Radar and Chart mode you can switch on half-screen windows for additional display, as described in the following section.

If you press **DISPLAY** again, the pop-up and soft keys for the current mode are shown.

### **Selecting a Half-Screen Window for Display**

**Note:** Windows can only be used with Radar or Chart screens, they are not available on the data log screen.

- ➤ To select a window for display:
  - From the full-screen Radar or Chart mode, press the **DISPLAY** key. The following soft keys are displayed with an image of each available window:



- 2. To select a different window, press either SELECT WINDOWS soft key until the required window is highlighted. If necessary, this will toggle windows on. Press **ENTER**.
- 3. To toggle windows off, press the WINDOWS OFF ON soft key.

Figure 2-6 shows the half-screen horizontal windows (in radar mode).

# Switching Control Between Radar & Chart Screens (SL72RC PLUS)

In a combined or an integrated system, to switch control between radar and chart, you can change the full-screen mode using the **DISPLAY** key. Alternatively, when you have both radar and chart displayed in half-screen windows the soft key RDR CHRT lets you toggle operating control between the radar and the chart window.

If a window is active, i.e. control of the cursor via the trackpad is available in that window, and you switch windows off, control automatically returns to the full-screen (upper window) mode.

#### **Radar:**



#### Chart (SL72RC PLUS only):

ROUTE	GOTO	MORE	RDR CHRT

To change the active window, press the RDR CHRT soft key to toggle control between the radar and chart display. The current active display is highlighted in red on the RDR CHRT label and the cursor appears in that window.

## **Returning to the Full-Screen Display**

To return to the full-screen display you can turn windows off, as previously described. Alternatively, to return to full-screen display:



Press and hold the **DISPLAY** key for 2 seconds to return to the currently selected full-screen (upper window) display.

**BDI Window** 



2-10



Figure 2-6: Radar Half-Screen Window Options

004\_fold\_2.fm Page 11 Wednesday, January 23, 2002 3:22 PM

Chapter 2: Getting Started & Adjusting the Display





204\_fold\_2.fm Page 12 Wednesday, January 23, 2002 3:22 PM



۲

## **Customizing the Screen Presentation Options**

The SCREEN soft key lets you set the following screen presentation options on or off:

#### **Radar:**



#### Chart (SL72RC PLUS only):



## Switching the Cursor Data Box On and Off

The cursor data box provides the cursor's position in latitude/longitude and/or bearing/range. If you wish to see a full image, you can switch the data box off.

► To control the cursor data box:

1. Press the SCREEN soft key.



SCREEN

- 2. Press the CRSR BOX soft key to toggle the setting from OFF to ON or from ON to OFF.
- 3. To return to the default soft key display, press **ENTER**.
- ► You can move the cursor data box using the context-sensitive cursor.

## Switching Radar Range Rings or Chart Grid On and Off

The radar range rings can be turned on or off. They are normally left on, but you may wish to turn them off if you are using VRM/EBLs or guard zones (see *Section 3.4* and *Section 3.5*) to make the display clearer.

The Chartplotter display includes grid lines of latitude and longitude which you can use to help determine position on the chart. The grid lines can be switched on if required.

If you are in Chart mode the RNGE RNGS soft key is replaced by the CHRT GRID soft key.

➤ To turn the range rings or chart grid on or off:



- 1. Press the SCREEN default soft key.
- 2. Press the RANGE RINGS or the CHRT GRID soft key to toggle the setting from OFF to ON or from ON to OFF.

To return to the default soft key display, press ENTER.

### **Data Boxes**

A group of up to six data boxes can be displayed, if the information is available on your system. You select which data is displayed in the boxes during system set up as described in *Chapter 7:Setting Up the System Defaults*.

The default data box positions are along the bottom of the display. Each box can be moved to the required position on the screen using the context-sensitive cursor.

**Note:** If you select BDI, CDI or Nav Data for display in a half-screen window, the data boxes are temporarily hidden.

#### SCREEN

At any time, you can switch the *group* of data boxes on or off using the SCREEN soft key. When first installed, the boxes are all OFF. When the display unit is switched off and on again, the data boxes return to their last-used states (ON or OFF) and positions.

**Note:** The SCREEN soft key does not control the sixteen data boxes that can be displayed in the half-screen window.

► To switch the group of data boxes on or off:



- 1. Press the SCREEN default soft key.
- 2. Press the DATABOXES soft key to toggle the setting from ON to OFF or from OFF to ON.

To return to the default soft key display, press ENTER.

If you turn the data boxes on and none are displayed, you need to select the ones you require using the system set up menu, as described in *Section 7.3, System Set Up Parameters*.

- ► To move any data box:
  - 1. Use the trackpad to position the cursor over the box until the letters BOX are displayed.
  - 2. Press **ENTER** to take control of the box, use the trackpad to move it to the required position, and press **ENTER** again.

### Waypoint Display - Radar mode

If you are currently going to a waypoint, you can display the active waypoint on the radar picture. The waypoint may have been generated locally on the chartplotter, or received via the SeaTalk or NMEA interface.

**Note:** If you use the GOTO CURSOR function, the active cursor is displayed as a lollipop symbol on the radar.



➤ To display the active waypoint:



- 1. Press the SCREEN soft key.
- 2. Press the WAYPOINT soft key to toggle the setting ON.

To return to the default soft key display, press ENTER.

The standard radar picture is displayed again, with the active waypoint joined to your vessel's position by a dotted line. If the waypoint is off-screen, the dotted line is extended to the edge of the radar picture.



Figure 2-7: Active Waypoint on a Radar Display

## Custom Options - Chart mode (SL72RC PLUS only)

When chart details have been customized in the Chart Set Up menu (as described in *Section 7.6*) the SCREEN soft key can be used to switch the custom chart options off or on:

When set to ON, all chart options set to CUSTOM in the Customize Chart menu are displayed; when set to OFF, options set to CUSTOM are not shown.

The factory default for custom chart options is ON.

➤ To switch the customized options on or off:



CUSTOM

OFF ON

- 1. Press the SCREEN default soft key.
- 2. Press the CUSTOM soft key to toggle the setting from OFF to ON or from ON to OFF.

To return to the default soft key display, press ENTER.

2-15

## 2.4 Radar Display Control Functions

This section describes how to use the radar controls to:

- Use the zoom function to enlarge a selected area.
- Offset the center of the radar display.
- Momentarily hide the ship's heading marker (SHM).

## **Using the Zoom Function**

If you wish to see a section of the radar picture in more detail, you can use the Zoom function to magnify the selected area to twice its size. The enlarged area is displayed in a quarter-screen Zoom Window in the lower right corner of the screen. A box in the original radar picture indicates the enlarged area; you can move this using the context-sensitive cursor, changing the image in the Zoom Window.

**Note:** If the area you wish to enlarge is in the quarter of the screen that will be covered by the Zoom Window, you should offset the centre (see the next section) to move the area to another part of the screen before selecting Zoom mode.

**Note:** You cannot use Zoom and Windows at the same time: if you turn one on, the other is turned off automatically, and restored when the first is turned off again.

- ► To enlarge an area:
  - 1. Press the **DISPLAY** key. The soft key labels are updated.



2. Press the ZOOM soft key to toggle the Zoom function ON.

The labels are cleared, and the cursor has control of the zoom box that indicates the area to be enlarged. This is indicated by the letters ZMB in inverse video, and the four-headed cursor symbol. The zoom box defaults to its last-used position since power-on.

3. Use the trackpad to move the zoom box to the required area, and press **ENTER**.

The selected area is shown in an enlarged format in the quarter-screen Zoom window. The original radar picture occupies the rest of the screen.

**Offsetting the Center** 

- ► To move the enlarged area in view in the window:
  - 1. Move the cursor over the edge of the zoom box in the original radar picture, until the letters ZMB appear under the cursor.
  - 2. Press **ENTER** to take control of the zoom box. The cursor shape changes to a four-way arrow.
  - 3. Use the trackpad to move the zoom box over the required area.
  - 4. Press **ENTER** again to drop the zoom box, update the enlarged version, and return the cursor to normal control.



To return to the normal display, press **DISPLAY** and then press the ZOOM soft key to set the function OFF.

Alternatively, you can press and hold **DISPLAY** for 2 seconds. This also removes any grouped data boxes.

## **Offsetting the Center**

The radar picture is normally shown with your vessel at the center of the display. However, you can move the center, so that your vessel is offset by up to 66% of the radius, anywhere on the screen.

**Note:** You cannot offset the center when the radar display is set to the longest range scale.

- ► To change the center:
- 1. Move the cursor over the center of the radar picture, until the letters CTR are displayed.
  - 2. Press **ENTER** to take cursor control of the center point. The cursor changes to a four-headed arrow.
  - 3. Move the cursor to the required off-center position.
  - 4. Press **ENTER** again to set the position and return to normal cursor control.



Figure 2-8: Radar Display with an Offset Center

To return the center of the radar picture to the center of the screen, repeat step 1 and then press the CLEAR key. The center is always reset to the center of the display when you turn on the Radar display.

**Note:** When the center is offset, additional range rings are displayed to the edge of the radar picture, at the standard ring interval for the current range. If you have selected the longest range scale, you cannot offset the center.

## Hiding the Ship's Heading Marker (SHM)

The radar picture includes the ship's heading marker, which is a line from your vessel's position to the edge of the picture at the vessel's current heading. In the standard Head Up mode, the heading marker is always a vertical line.

If you wish to check for small targets that may be hidden under the heading marker, you can hide it momentarily using the context-sensitive cursor.

- ➤ To hide the heading marker:
  - 1. Position the cursor over the heading marker, so that the text SHM is displayed.
  - 2. Press and hold **CLEAR**. The heading marker is hidden until you release the **CLEAR** key.

Hiding the Ship's Heading Marker (SHM)

## 2.5 Chart Display Control Functions (SL72RC PLUS only)

## **Moving Around the Chart**

You will normally operate the chartplotter with the chart showing your vessel's current location. The default orientation is North-Up, and the vessel moves across the screen. You will need to move the chart if your vessel moves out of the area currently displayed, or if you wish to examine or place waypoints in another area. Alternatively, you can *home* the cursor onto the vessel using FIND SHIP.

There are four ways in which you can move the chart:

- Use the trackpad to move the cursor to the edge of the chart. The chart will pan across. This method is useful if the area you wish to see is only just off the screen.
- Use the context-sensitive cursor to change the chart center.
- Automatically re-center the vessel using the FIND SHIP soft key.
- Change the chart scale to zoom out and in to a new area centered on the cursor position. This method is useful if the area you wish to see is a long distance away.

## **Changing the Chart Center**

You can move the area of the chart displayed on the screen using the contextsensitive cursor. This allows you to center your vessel in the middle of the screen, or to move the chart so that your vessel is displayed off-center anywhere on the screen.

- ► To center the chart:
- 1. Use the trackpad to move the cursor to the vessel's position. The cursor text POS is displayed.
- 2. Press **CLEAR**. The chart is moved so that your vessel's position is in the center of the screen.

► To move your vessel's position off-center:

- -----POS
- 1. Move the cursor over your vessel's position until the letters POS are displayed.
- 2. Press **ENTER** to take control of the chart position. The letters POS are now in inverse video, and the cursor symbol has changed to a four-way arrow. This indicates that the cursor can be used to move the chart in any direction.

2-19



Figure 2-9: Changing the Chart Center

- 3. Use the trackpad to move the cursor to the required position.
- Press ENTER to select the position and return to normal cursor control. The chart is redrawn with the vessel position at the cursor. Alternatively, you can press CLEAR to abandon the move and leave the chart (and vessel) in its former position.

### **Using FIND SHIP**

FIND SHIP is used in chart mode to re-draw the chart with the vessel at the center and the cursor homed onto the vessel.



When you press FIND SHIP the following occur:

- The chart is re-drawn with the vessel's position in the center.
- The cursor is homed onto the vessel position and moves with it.
- When the vessel moves near the edge of the chart window, the chart is redrawn to place the vessel and cursor at the center again.
- The status bar indicates vessel position, speed and course over ground.
- To release the cursor from homed mode press the trackpad to move the cursor away from the vessel's current position. The status bar shows the cursor position, range and bearing.

#### Synchronize the Radar and Chart

If you have a combined radar/chartplotter display, with chart and radar windows on and you have selected Radar/Chart Synch in Chart Set Up (Section 7.6, Chart Set Up Parameters - SL72RC PLUS only), FIND SHIP can

be used to synchronize the radar and chart images. It is recommended that you set the radar to True motion to ensure the radar and chart images remain synchronised when the vessel moves. When you press FIND SHIP the following occur:

- The chart is redrawn so that its center position matches that of the radar display.
- The radar is redrawn to the scale and heading mode of the chart.

**Note:** Depending on the topology of the coastline, the radar returns may not relate to the charted shoreline, the radar image will therefore be different to the chart display. For example, a gently sloping beach with a cliff several hundred metres beyond the charted coastline, the cliff is not shown on the chart but will be displayed on the radar image.

## **Changing the Chart Scale**

The **RANGE** key allows you to change the chart scale so that you can see a smaller or larger area on the screen.

Plotter mode is available to allow you to zoom into a smaller area, even when no chart data is available for that scale. *Section* 7.6 describes how to set plotter mode on/off.

You can change the chart scale for two purposes:

- To see either more detail (of a smaller area) or a larger area (in less detail) on the screen.
- To move the display to another area of the chart, by zooming out to a small scale chart, then zooming in on another position centered on the cursor.

The cartographic detail available on charts varies according to the chart scale and some areas include detail at smaller scales than others. This can cause blank areas on the display when adjacent areas with different levels of detail are displayed. To reduce this affect you can use the Chart Set Up options (see *Section 7.6*) to set chart display detail to simple. Then, as you zoom in, charted areas are displayed but with less detail shown.

Each time you press the **RANGE** key, the chart scale changes to the next available setting. The status bar indicates the distance from top to bottom of the screen, in nautical miles.







RANGE

RANGE

2-22

To change the scale quickly, press and hold the required arrow on the RANGE key.

The distance indicator at the left-hand end of the status bar is updated whenever you change the chart scale.

- ► To zoom in to a larger-scale (more detailed) chart:
  - 1. Use the trackpad to position the cursor in the area you wish to see in more detail.
  - 2. Press the lower part of the **RANGE** key to zoom into the area.

The section of the chart around the cursor is enlarged to fill the screen with a larger-scale chart showing more detail. The cursor is now positioned in the center of the screen.

The distance indicated at the top left of the screen is updated.

3. If further chart enlargement is available using the current chart card you can press the bottom of the **RANGE** key to zoom in again, re-positioning the cursor first if required.

An area of further chart detail is indicated by a box around the area as shown in *Figure 2-11*.





4. When no further chart detail is available, as you press the bottom of the **RANGE** key, the effect depends on whether **Plotter Mode** is on or off as follows:

• If Plotter Mode is Off, the chart scale remains unchanged, indicating the smallest chart scale is displayed.

**Note:** If Plotter Mode is Off and the cursor is homed to the vessel (see Using FIND SHIP on page 2-20), if the vessel moves outside an area of available cartography, the chart will automatically re-scale to the next range with cartography.

• If Plotter Mode is On, the scale is decreased and the message NO CHART DATA is displayed. The vessel, waypoints, routes and tracklines are displayed without cartography.

The chart information is restored when you return to a chart scale for which the information is available.

➤ To zoom out to a smaller-scale (less detailed) chart, simply press the upper part of the **RANGE** key as many times as required.

## 2.6 Typical Chart Scenarios (SL72RC PLUS only)

The following illustrations provide operating guidelines for typical navigation scenarios. These scenarios can be used as a training guide; they show you how to perform a particular operation and they introduce many of the chartplotter functions.

Each scenario indicates the key presses required to perform particular tasks. A typical chartplotter screen image is shown for each task.

The scenarios assume you have read the previous sections of this chapter and that you are familiar with the Operating Controls. Full operating details for each function are provided in *Chapter 5* and *Chapter 6*.

Operating guidelines are provided for the following scenarios:

- Working with Waypoints Place a Waypoint Goto a Waypoint
- Make and Follow a Routes
  Create a Route
  Follow a Route
- **Review the Passage Plan** View Route Information Change the SOG, Hours and ETA.
- Displaying the Radar Image and Synchronizing Radar & Chart Changing the Full-Screen Mode & Selecting Half-Screen Windows Radar and Chart Synchronization (Find Ship) Cursor Echo

Downloaded from www.Manualslib.com manuals search engine



**Place and Goto a Waypoint** 







**Make and Follow a Route** 

2-26





Make and Follow a Route

2-27

**Review Your Passage Plan** 

2-28





**Displaying the Radar and Synchronizing Radar & Chart** 



Displaying the Rad and Synchronizin Radar & Chart



Downloaded from www.Manualslib.com manuals search engine



## **Chapter 3: Standard Radar Operations**

## 3.1 Introduction

This chapter provides detailed instructions for the standard radar operations of your SL72 and SL72RC PLUS system. Additional functions, that are available on integrated systems with appropriate data sources, are described in *Chapter 4*. If you have a combined radar/chart display refer to *Chapter 5* and *Chapter 6* for information on charting operations.

You can use this chapter with the radar display set to simulator mode, or on the water after you have installed and set up your SL72 or SL72RC PLUS system.

This chapter covers the following topics:

- Range control.
- Interpreting and adjusting the radar picture, including adjusting the gain, sea clutter and rain clutter, changing the targets display, and tuning the radar.
- Measuring range (distances) and bearings using Variable Range Markers (VRMs) and Electronic Bearing Lines (EBLs).
- Setting up guard zones and handling alarms.

**Note:** Until you are familiar with interpreting the radar display, you should take every opportunity to compare the radar's display patterns with visual targets, such as other vessels, buoys and coastal structures. You should practice harbour and coastal navigation during daylight and in clear weather conditions.

If you have a combined radar/chartplotter, or a system with any chart display connected via SeaTalk, you can identify objects using the cursor echo feature: With cursor echo on (see *Section 4.5* and *Chapter 7*) you can select an object on the radar display, the cursor is repeated on the chart display so you can check the object's identity.

## 3.2 Range Control

The radar picture can be viewed at various scales. The shortest range scale gives a maximum range of  $\frac{1}{s}$  nautical miles, measured from the default centre to the top of the radar picture. The longest range scale gives a maximum range of 24 nautical miles.

- The *long* range scales provide the best overview of your vessel's relationship to land masses, weather fronts and large ship targets in or beyond view.
- The *short* range scales provide greater detail of the radar echoes close to your vessel, and should be used as you approach the coastline, harbour or other vessels in the area.

The Pathfinder Plus Radar display includes concentric range rings, which you can use to help you to judge distances on the radar picture. Their number and spacing are adjusted automatically if you change the range scale. They can be turned off (see *Switching Radar Range Rings or Chart Grid On and Off* on *page 2-13*).

## **Changing the Range**



Figure 3-1: Changing the Radar Range



- Each time you press the **RANGE** key, the range changes to the next available setting. The system will beep three times if no further range scale is available.
- To change the range quickly, press and hold the required arrow on the RANGE key.

The range scale and range ring interval indicators, at the left-hand end of the status bar, are updated whenever you change the range.

#### **The Standard Range Scale**

Details of the standard ranges that can be selected are shown in the table below. If you wish, you can customize the range scales by specifying different ranges, as described in *Section 7.4, Radar Set Up Parameters*.

Maximum Range (nm)	Number of Range Rings	Range Ring Interval (nm)
0.125	2	0.0625
0.25	2	0.125
0.5	4	0.125
0.75	3	0.25
1.5	6	0.25
3	6	0.5
6	6	1
12	6	2
24	6	4

Table 3-1: Radar Range Scales

The number of range rings shown in the table is the number to the selected range. Additional range rings are displayed to the edge of the radar picture, at the standard ring interval for the current range, and are visible when the centre is offset.

## **Determining Actual Radar Range**

The actual maximum radar range is essentially line-of-sight, and is limited by the height of the scanner and the height of the target as shown in *Figure 3-1*. *Table 3-2* lists some range examples:



Figure 3-2: Determining Radar Range

#### Table 3-2: Radar Range

Antenna Height (m)	Target Height (m)	Maximum Range (nm)
3	3	7.8
3	10	10.9
5	3	8.9
5	10	12.0

**Note:** The ranges shown in the table are theoretical maximum ranges. The radar horizon is greater than the optical horizon, but the radar can only detect targets if a large enough target is above the radar horizon.

## 3.3 Interpreting and Adjusting the Radar Picture

Navigational echoes may be large, small, bright or faint, depending not only on the size of the object but also on its orientation and surface. Different objects reflect the radar signals in different ways. For example, vertical objects such as cliffs reflect signals better than sloping ones such as sandbanks.

High coastlines and mountainous coastal regions can be observed at the longest radar range. However, the first sight of land may be a mountain several miles inland from the coastline. The actual coastline may not appear on the radar until the vessel is close to the line of sight distance.

The radar indication may not be similar to your visual observation; a nearby small object may appear to be the same size as a distant large object on the radar. However, with experience the approximate size of different objects can be determined by the relative size and brightness of the echoes.

Some targets, such as buoys and small boats, can be difficult to differentiate, since they bob and toss about in the waves and do not present a consistent reflecting surface. Consequently, these echoes have a tendency to fade and brighten and, at times, to disappear momentarily. Buoys and small boats often resemble each other, but boats can usually be distinguished by their motion.

Not all radar echoes are produced by hard navigational items. Some echoes may be received from irregularities on the surface of the water, particularly at close range (sea clutter), or from rain or snow either around the vessel or in the distance. In addition, some echoes may be indirect returns to the radar scanner, providing false echoes or multiple echoes.

The effects of many false echoes can be minimized, and the target presentation clarified using the controls summarized below. This section explains how to interpret the radar picture and how the controls affect the display. It provides instructions for adjusting the settings, describes the circumstances in which they should be adjusted, and how they interact with each other.

Control	Option	Function	<b>Default Setting</b>
GAIN	GAIN SEA RAIN FTC	Controls the strength of the target returns Reduces sea returns Reduces close rain or snow returns Reduces distant rain or snow returns	AUTO AUTO-HARBOUR OFF OFF
MULTI	TUNE	Fine tunes the receive	AUTO
TARGETS Soft Key	INT REJ EXPANSION WAKES	Turns interference rejection on/off Turns target expansion on/off Turns wakes on/off and selects wakes length	ON OFF OFF

Table 3-3: Controls to Adjust the Radar Picture

## Identifying False Echo Returns

Not all echoes are direct returns to the radar antenna. Occasionally signals appear at positions where there is no actual target. These are called *false echoes*, and may be caused by side lobes, ghost images, indirect echoes or multiple echoes.

This section briefly describes the echo patterns that can be produced by false echoes and the likely cause. It should be noted that the radar operator, through observation, practice, and experience, can generally detect these conditions very quickly. These effects can usually be minimized using the radar controls.

### **Side Lobes**

A small part of the RF energy from each transmitted pulse is radiated outside the single narrow beam. This produces side lobe patterns, shown in *Figure 3-3*.

Side lobes have no effect on distant or small surface objects. However, the echo from a large object at short range may produce an arc on the radar screen similar to a range ring or a series of echoes forming a broken arc. Side-lobe echoes normally occur at ranges below 3nm, and can be reduced by adjusting the SEA control.



Figure 3-3: Side Lobes

#### Indirect Echoes

There are several types of indirect echoes or ghost images - some examples are shown in *Figure 3-4*. These sometimes have the appearance of true echoes, but in general they are intermittent and poorly defined.



Figure 3-4: Indirect Echoes

#### **Multiple Echoes**

Multiple echoes appear if there is a large target with a wide vertical surface at a comparatively short range. The transmitted signal will be reflected back and forth between the target and your own ship. Multiple echoes therefore appear beyond the true target's echo on the same bearing, as shown in *Figure 3-5*. This is not very common.



Figure 3-5: Multiple Echoes

#### **Blind Sectors or Shadow Effect**

Funnels and masts located near the antenna, may cause shadows. In shadow areas beyond the obstruction there will be a reduction of the beam intensity, although not necessarily a complete cut-off. However, there will be a blind sector if the subtended angle is more than a few degrees. There may also be multiple echoes which extend behind the obstruction. This should be avoided by careful selection of the scanner site prior to installation (*Chapter 8*).

## Adjusting Gain, Sea Clutter, Rain Clutter and Tune



Automatic adjustment of Gain, Sea and Tune is available, alternatively you can set any of these parameters to manual and use the trackpad to adjust its value. Rain clutter is adjusted manually using the RAIN or FTC control. GAIN, SEA, RAIN and FTC are accessed from the **GAIN** key; TUNE is accessed from the **MULTI** key.

**Note:** Gain, Sea and Tune can only be adjusted if the control is set to Manual adjustment.



When you select manual GAIN, SEA or TUNE adjustment the soft key icon shows a vertical slider bar. As you press the trackpad, the value is indicated in the slider.

When you switch FTC or RAIN On, the soft key icon shows a vertical slider bar. As you press the trackpad, the value is indicated in the slider.

If you change the settings, the new GAIN, SEA and TUNE modes (auto or manual) and values remain set even when you turn the radar off and on again; Rain and FTC are reset to Off at power-on. The status bar indicates which controls are switched to Auto or On, as shown in *Figure 3-6*.

Figure 3-6: Radar Status Bar



#### ► To adjust a parameter:

- 1. Select a range appropriate to the adjustment you wish to make. The optimum Tune setting varies slightly for different ranges, depending on the pulse width used.
- 2. Press **GAIN** or **MULTI**. The slider soft keys are displayed. The last-used slider is highlighted (displayed in inverse video) to show that it is selected.
- 3. Press the required soft key so that the slider box is highlighted. The TUNE and GAIN soft keys toggle the control between Auto and Manual mode. The SEA soft key toggles the control between Auto-Harbour, Auto-Offshore and Manual mode. If you select Manual mode the last auto setting is retained. You can only move the slider if the control is set to Manual.



3-7
Use the trackpad to move the slider up or down. You can press and hold the control to move the slider quickly rather than in single steps.
The image on the screen changes as you move the slider, so that you can see the effect of your adjustment.
If you select MANUAL TUNE adjustment, an 8-step signal-strength indicator

bar is displayed above the slider. Adjust the slider to obtain the maximum reading on the indicator.

**Note:** Because the changes to the settings are made immediately, you cannot revert to the previous setting by pressing **CLEAR**.

5. When you have set all the controls to the levels you require, press **ENTER**, or **CLEAR** to clear the slider display. The status bar is updated to indicate which controls are switched to Auto or On.

#### **Gain Control and Sea Control**

The GAIN control can be set to either Auto or Manual. In Auto mode, the Pathfinder Plus radar optimizes the setting. The SEA control can be set to Auto-Harbour (default), Auto-Offshore or Manual mode. In Auto-Offshore mode, the Pathfinder Plus Radar optimizes its settings to account for the effects of sea clutter. In harbours or close proximity to land different auto settings may be necessary to cater for the effects of land clutter. To avoid losing small targets it is therefore advisable to set the Sea control to Auto-Harbour mode. Alternatively, set both Sea and Gain to Manual mode then adjust the settings to ensure that all close small targets are visible.

The GAIN control adjusts the level of the display of signals received from the scanner; it is equivalent to a volume control on a radio.

Because the SEA control affects the gain, you may need to manually readjust it if you manually change the Gain setting.

#### **Gain Control**

When the GAIN control is set to Manual, you should check it every time you change the range scale.

On long range settings, the gain should be set to give a slight speckle in the background of the radar picture. Do not set the gain too low, or you may miss small or weak targets.

On shorter ranges, you may wish to reduce the gain slightly to reduce the speckle and therefore improve target definition.

MANUAI



#### Sea Clutter Control

Radar returns from waves around your vessel can clutter the centre of the radar picture (see *Figure 3-7*, making it difficult to detect real targets. Such *sea clutter* usually appears as multiple echoes on the display at short range scales, and the echoes are not repetitive or consistent in position. With high winds and extreme conditions, echoes from sea clutter may cause dense background clutter in the shape of an almost solid disc.



Figure 3-7: Sea Clutter

The SEA control reduces the gain level in the areas near your vessel, extending up to 3 to 5nm depending on the wave and sea conditions. This has the effect of reducing the sea returns to intermittent small dots, while small targets are still visible. Gain levels further from your vessel remain unchanged.

You can use the gain and Sea control to help minimize the effects of side lobes (see *Identifying False Echo Returns* on *page 3-5*).

**Note:** On short range scales, do not set the Sea control so high that all clutter is removed, since this could stop you seeing echoes from close targets.

## **Tuning the Receiver**



The TUNE control is used to fine tune the receiver in the scanner for maximum target returns on the display. In Auto mode, the radar tunes itself automatically on all range scales. We recommend that you leave the TUNE control in Auto mode.

If you do set the TUNE control to Manual, you will need to adjust it about 10 minutes after you have turned on the radar, since the required setting changes once the magnetron has warmed up.

You should adjust the control to obtain the maximum signal strength, as indicated in the 8-step bar above the slider. If you cannot tune the radar successfully, refer to *Section 7.5* for information on the Tune Preset function.

#### **Rain Clutter Control, using RAIN and FTC**

The radar can see echoes from rain or snow. Returns from storm areas and rain squalls consist of countless small echoes that continuously change size, intensity, and position. These returns, shown in *Figure 3-8*sometimes appear as large hazy areas, depending on the intensity of the rainfall or snow in the storm cell.

The RAIN and FTC controls are used to reduce this clutter, so that targets masked by the clutter can be seen on the radar picture.

- The RAIN control is used to reduce large clutter masses around your vessel caused by rain or snow.
- The FTC (Fast Time Constant) control is used to reduce rain clutter at a distance from your vessel, such as that shown below.







When the FTC control is turned up, only the leading edge of large (rain clutter) echoes is displayed, while the effect on smaller (ship) echoes is only slight. This means that you can also use the control on shorter ranges to distinguish between two very close echoes on the same bearing, which may otherwise merge and appear as one echo.

When the FTC control is turned up, the receiver is less sensitive, and there is a reduction of background noise and fill-in returns from land and large targets. You should therefore turn the control down when its use is not required. Since storm cells are usually visible for long distances due to their extreme altitude, you may wish to leave them displayed so that you can observe the location of bad weather.

If you turn the RAIN or FTC control Off (equivalent to setting the level to 0%), the actual setting is stored, and restored when you turn the control on again.

**Note:** RAIN and FTC are reset to Off at power-on.

0

RAIN



# **Changing the Targets Display**

The Pathfinder PLUS Radar allows you to improve target visibility by changing the following:

- Interference rejection
- Target expansion
- Target wakes

These parameters are accessed from the default soft key TARGETS.

This section explains how to change these modes and describes the effect of each mode. The current settings are shown at the right-hand end of the status bar as shown in *Figure 3-9*.

<b>3nm</b> RR <b>1/2 126°T</b> TH TY3 AUTO WKS EX GZ GST FTC RC IR	Status Bar			Wakes on	Target Expansion or	۱
Interference Bejection on	3nm	1/2	<u>126°T</u>	H-UP GS	T FTC RC IR	
			Inte	erference Reject	ion on —	986-3



- ➤ To change the settings of the target modes:
  - 1. Press the TARGETS default soft key.

The target option soft keys are displayed, with the current selections highlighted.



2. Press the appropriate soft key to toggle the required setting between OFF and ON.

**Note:** If an option is not available for the current setting, its soft key label is grey. When you press the key, the system beeps and the setting remains OFF.



For the Wakes mode, press the WAKES soft key to step the highlighted selection through the wake options.

You can use the soft keys to change the settings of any or all the modes on this display.

3. When the required options are highlighted, press **ENTER**. The screen returns to the default display with the new mode(s) in operation. The status bar is updated to indicate which controls are switched on.

#### **Interference Rejection**



Mutual radar interference is likely when two or more radar-equipped vessels are operating within range of each other. This usually appears as a series of small dots moving to and from the display center in a straight line or a long, sweeping curve. This type of interference is most noticeable at long ranges.



Figure 3-10: Interference Rejection

The Pathfinder Plus Radar includes a mechanism that automatically reduces such interference. This mechanism is normally left switched on. However, if you wish to detect the presence of other radars in the vicinity, you can turn off the interference rejection.

#### **Target Expansion**



You can make targets easier to see by expanding them. Target expansion overrides the normal pulse length, thereby increasing the size of the target seen on the screen. However, this is at the expense of range resolution.

#### **Target Wakes**

You can see the direction and speed with which targets are moving relative to your vessel by selecting the target wakes display option.



When wakes are switched on, the target is displayed at the brightest level and the previous positions of targets are retained at successively fainter levels on the screen. You can select long, medium or short wakes, which retain information from previous scans at a reduced video level.



You can clear existing wakes from the display by pressing the CLEAR WAKES soft key. The soft key is only available when wakes are switched on; the display starts showing new wakes as soon as the old wakes have been cleared.

When wakes are switched off, no new wakes are displayed and existing wakes are cleared.

# 3.4 Measuring Range and Bearing Using VRM/EBLs

The Pathfinder Plus Radar display allows you to specify up to two Electronic Bearing Lines (EBLs), each with an associated Variable Range Marker (VRM), using the **VRM/EBL** key.

A standard VRM is displayed as a circle with its centre on your vessel's position, and it's EBL is displayed as a line from the origin to the edge of the radar picture display. However, each pair can be *floated*, so that the origin can be moved.



Figure 3-11: EBL and VRM Displays

**Note:** When using VRM/EBLs, you may wish to turn off the range rings to make the VRMs clearer (see Section 2.4).

VRMs move if you change the range scale, so that the actual range you have marked is maintained. VRM/EBLs also move if you offset the centre.

When a VRM/EBL pair is active, its bearing and range are displayed in its associated data box, which can be moved, deleted or reinstated.

The bearing information is displayed as either the bearing relative to your vessel's heading or (if heading data is available from a position fixer or compass) the actual bearing in degrees magnetic or degrees true. These are controlled by the setup parameters (see *Section 7.4*).

The VRM/EBL functions allow you to perform the following tasks:

• Measure the range of a target or point from your vessel's position, using a VRM

3-13

- Measure the bearing of a target or point from your vessel's position, using • an EBL
- Measure the range and bearing between any two points on the radar, using the FLOAT function

**Note:** An alternative method of measuring range and bearing is to use the cursor data box: If the cursor readout is set to display range and bearing (rather than Lat/Long), you can determine the range and bearing by moving the cursor over the target and checking the cursor data box readings. You can also estimate the range to a target by reference to the range rings.

## Measuring Range and Bearing to Target from Vessel

To measure the range and/or bearing of a target or point from your vessel's position, you need to place a VRM/EBL and move it so that it crosses the target or point for which you require the bearing or range.

When you turn on a VRM/EBL, it is displayed in its last-used position.

**Note:** If the VRM's last-used position is outside the radar picture at the current range setting, it is placed at its default position instead. This is one third of the range for VRM1, and two-thirds for VRM2.

#### **Placing a VRM/EBL**

Placing and positioning VRM/EBLs on the Pathfinder Plus Radar display is quick and easy.

- If a VRM/EBL is not already displayed, you can place one with a single press of the VRM/EBL key.
- If you have already placed a VRM/EBL, pressing the VRM/EBL key pro-• vides soft key control of additional functions.
- ➤ To place a VRM/EBL when one is not already displayed:



VRM/EBL

#### 1. Press VRM/EBL.

The radar picture shows VRM/EBL1, together with its associated data box in its last-used position.

As shown in *Figure 3-12*, the cursor is positioned over the intersection of the VRM circle and the EBL line. It has control of the VRM/EBL as indicated by the four-way arrow, the solid VRM/EBL line, and the text VRM/ EBL.

3-14





2. If required, use the trackpad controls to change the radius (range) of the VRM circle and the angle of the EBL until they cross the required target.

The range and bearing information in the VRM/EBL data box is updated as you move the cursor.

- 3. Press **ENTER** to drop the VRM/EBL. The radar shows this VRM/EBL as a short-dashed line, and the cursor returns to normal control.
- 4. Read the range and bearing to the target or point, which is shown in the VRM/EBL data box.
- 5. If required, you can move or delete the VRM/EBL data box using the context-sensitive cursor.
- ➤ To place a VRM/EBL when one is already displayed:
  - 1. Press VRM/EBL to display the VRM/EBL soft keys.





The labels for the two left-hand soft keys indicate the current status of the two VRM/EBLs.



2. Press the soft key for the VRM/EBL you require, to toggle the setting from OFF to ON.

The soft key labels are cleared, and the radar picture shows the VRM/EBL and its associated data box.

3. Position the EBL/VRM using the trackpad, and press **ENTER** to drop it. The radar shows the VRM/EBL as a short-dashed line (VRM/EBL1) or a long-dashed line (VRM/EBL2), and the cursor returns to normal control.

## **Moving an Existing VRM/EBL**

You can move an existing VRM/EBL using the context-sensitive cursor. You can control the VRM and EBL separately or both together.

- ► To move the VRM and/or EBL:
  - 1. Move the cursor over the VRM or EBL you wish to change. If you wish to change the VRM and EBL together, move the cursor over the intersection of VRM/EBL. The cursor text indicates the current object as VRM, EBL, or VRM/EBL.
  - 2. Press **ENTER** to take control of the object. The object(s) under control is displayed as a solid line, and the cursor as a four-headed arrow.
  - 3. Move the EBL to the new angle and/or change the VRM radius (range) using the trackpad controls.
  - 4. Press **ENTER** again to drop the VRM/EBL in its new position, or **CLEAR** to abandon the operation and return the VRM/EBL to its previous position.

The radar shows the VRM/EBL as a short-dashed line (VRM/EBL1) or a long-dashed line (VRM/EBL2), and the cursor returns to normal control.

#### **Deleting an Existing VRM/EBL**



VRH

You can delete a VRM/EBL by using the VRM/EBL key to display the soft keys, and pressing the required VRM/EBL soft key to toggle the setting from ON to OFF.

 Alternatively, you can delete an existing VRM/EBL using the contextsensitive cursor. To do so:

- 1. Move the cursor over the VRM/EBL you wish to control, until the letters VRM, EBL, or VRM/EBL are displayed.
- 2. Press CLEAR.

This has the same effect as turning the VRM/EBL off using the VRM/EBL soft keys. It turns off the VRM/EBL pair, irrespective of the cursor text: you cannot turn off VRMs and EBLs independently.

## **Measuring Range and Bearing Between Targets (FLOAT)**

You can measure the range and bearing between any two points on the radar, such as two targets, using the Pathfinder Plus Radar's Float function. This allows you to move the origin of a VRM/EBL away from your vessel's position and onto a target. You can then change the angle of the EBL, relative to its new origin, to obtain the bearing between two points. The radius of the VRM can also be adjusted to determine the distance between two points.

#### **Floating a VRM/EBL**

**Note:** You can float a VRM/EBL pair using either the soft keys or the contextsensitive cursor. The procedure for using the cursor is the same as for moving or unfloating a VRM/EBL pair, as described below; however, as it is more difficult to locate the VRM/EBL origin when it is over the centre, you will probably find it easier to use the keys in this case.

- ➤ To float a VRM/EBL pair using the keys:
  - 1. If one is not already present, place a VRM/EBL pair as described in the previous section.
  - 2. Press **VRM/EBL** to display the VRM/EBL soft keys.
  - 3. Press the FLOAT soft key. The soft keys are updated, with the relevant options displayed.





- FLOAT 1
- 4. Press the FLOAT 1 soft key to float VRM/EBL1, or the FLOAT 2 soft key to float VRM/EBL2.

The soft keys are cleared. The cursor is positioned over the origin of the VRM/EBL, over your vessel. The cursor has control of the VRM/EBL, as indicated by the four-headed arrow, the text FLT in inverse video, and the solid VRM/EBL line.

- 5. Use the trackpad to move the origin of the VRM/EBL to the required position (over the first target).
- 6. Press **ENTER** to drop the VRM/EBL in its new position, or **CLEAR** to abandon the operation and return the VRM/EBL to its previous position.

The radar shows the VRM/EBL as a short-dashed line (VRM/EBL1) or a long-dashed line (VRM/EBL2), and the cursor returns to normal control.

- . ₩ VRH
- 7. Use the context-sensitive cursor to take control of the VRM and/or EBL, to obtain the range and/or bearing to a second target, as previously described.
- 8. Read the range and bearing information from the VRM/EBL data box.

#### **Moving and Unfloating a Floating EBL**

You can move or unfloat a VRM/EBL that has been floated. You can unfloat a VRM/EBL either by using the context-sensitive cursor or by using the FLOAT soft key options.

► To move or unfloat a floating VRM/EBL using the cursor:

÷ FLT

- 1. Move the cursor over the origin of the VRM/EBL you wish to control, until the letters FLT are displayed.
- 2. If you wish to unfloat the VRM/EBL, press **CLEAR**. The origin of the VRM/EBL is reset to your vessel's position.

3. Alternatively, if you wish to move the floating VRM/EBL, press **ENTER** to take control of it and move it using the trackpad.

Press **ENTER** again to drop the VRM/EBL in its new position, or **CLEAR** to abandon the operation and return the VRM/EBL to its previous position.

- ► To unfloat a floating VRM/EBL using the keys:
  - 1. Press **VRM/EBL** to display the VRM/EBL soft keys.
  - 2. Press the FLOAT soft key.
  - 3. Press the UNF LOAT 1 soft key to unfloat VRM/EBL1, or the UNFLOAT 2 soft key to unfloat VRM/EBL2.

The soft keys are cleared, and the VRM/EBL is repositioned with its origin at your vessel's position.

# **Controlling VRM/EBL Data Boxes**

► To move a VRM/EBL data box, using the context-sensitive cursor:

- H BOX
- 1. Move the cursor over the box until the letters BOX are displayed, and press **ENTER** to take cursor control of the box.
- 2. Use the trackpad to move the box to its new location, and press **ENTER** to drop it and return to normal cursor operation.

Each VRM/EBL data box is switched on and off with its associated VRM/ EBL. However, when one or both VRM/EBLs are active, you can turn the data box(es) off at any time, if required.

- ► To control the VRM/EBL data boxes:
- VRM/EBL DATABOX
- 1. Press VRM/EBL to display the VRM/EBL soft keys.
- 2. Press the VRM/EBL DATABOX soft key to toggle the setting from OFF to ON or from ON to OFF.

**Note:** *VRM/EBL* data boxes are not affected by the setting of the DATABOXES soft key accessed using the SCREEN default soft key. This only controls the set of data boxes available for integrated systems (see Chapter 2).



## 3.5 Setting Guard Zones and Alarms

The Pathfinder Plus Radar display allows you to set up one or two guard zones, using the **ALARMS** key. You can set up sector zones or  $360^{\circ}$  (circular) zones as shown in *Figure 3-13*.

**Note:** You can only view and control guard zones if you are using the Master display (that is, the display to which the scanner is connected).



Figure 3-13: Guard Zone Display

Guard zones are fixed with respect to the ship's heading marker (SHM), moving as the SHM moves. They also move if you offset the centre, or if you change the range scale, so that the area you have marked is maintained.

The guard alarm sounds when a target enters a guard zone, exceeding the target density threshold within the zone; the alarm also sounds on a repeater display. The alarm sensitivity control allows you to set the threshold above which a new target will trigger an alarm, and also to turn the alarm on or off.

**Note:** A guard zone only operates when the whole zone is displayed on the screen, or could be displayed by offsetting the centre. In addition, a guard zone is inactive for 10 seconds after it is placed or re-sized, to avoid inappropriate alarms during positioning.

This section covers the following topics:

- Placing a guard zone
- Moving, reshaping or deleting a guard zone
- Controlling guard zone alarms

## **Placing a Guard Zone**

Placing and positioning guard zones on the Pathfinder Plus Radar display is quick and easy.

- If a guard zone is not already displayed, you can place one using the **ALARMS** key.
- If you have already placed a guard zone, pressing the **ALARMS** key allows you to toggle either guard zone on or off.

**Note:** When you turn on a guard zone, it is normally displayed in its last-used position and shape. However, if this position is off-screen at the current range setting, or within one quarter of the current range from your vessel, the guard zone is placed at its default position and shape instead. This is at one third (Zone 1) or two thirds (Zone 2) of the current range, as a sector zone occupying 30° either side of the ship's heading marker.

- ► To place a guard zone:
  - 1. Press ALARMS. The soft keys are displayed.





The soft keys indicate the current status of the two guard zones.



2. If necessary, press the soft key for the guard zone you require, to toggle the setting between OFF and ON. The soft keys are cleared. If you turned a guard zone on, it is displayed in its last-used position with one corner under cursor control.

The radar picture shows the guard zone as a four-sided shape bounded by a solid line (or a circle if previously set as one).

The cursor is positioned over an outer corner of the zone as shown in *Figure 3-14*. The cursor has control of this corner, as shown by the text GRD in inverse video, the four-headed arrow, and the solid guard zone boundary.



Figure 3-14: Placing a Guard Zone

Placing a Guard Zone

3. If necessary, use the trackpad to move the corner of the guard zone to the required position. As you move the corner, the width and/or height of the zone changes, but its general sector shape is retained.

**Note:** To create a 360° guard zone, rather than a sector guard zone, you can either move the corner all the way round to form a circle, or move it back to just the other side of the other outer corner.

4. Press **ENTER** to drop the corner in its new position and redraw the zone, or **CLEAR** to abandon the operation and return the corner to its previous position.

The display shows this zone boundary as a short-dashed line (zone 1) or a long dashed line (zone 2), and the cursor returns to normal control.

5. If required, use the context-sensitive cursor to reposition other corners/ sides of the zone in turn, as described below.

## Moving, Reshaping or Deleting a Guard Zone

- You can move, reshape or delete an existing guard zone using the contextsensitive cursor. To do so:
  - 1. Move the cursor over the guard zone corner or side that you wish to control, until the letters GRD are displayed.
  - 2. If you wish to delete the whole zone, press **CLEAR**.
  - 3. Alternatively, if you wish to move the corner or side, press **ENTER** to take control of it. The zone boundary is displayed as a solid line, and the cursor as a four-headed arrow.
  - 4. Move the corner or side to the new position, as described on the previous page.

**Note:** To convert a 360° guard zone back to a sector guard zone, take control of any point on the circle, and move it to open up the circle.

5. Press **ENTER** again to drop the corner or side in its new position, or **CLEAR** to abandon the operation and return it to its previous position

The radar shows the zone boundary as a short-dashed line (Zone 1) or a long-dashed line (Zone 2), and the cursor returns to normal control.

6. If required, reposition the cursor and repeat steps 3 to 5 to move the other corners or sides.



3-21

ALARM

## **Controlling Guard Zone Alarms**

The guard alarm is triggered when a target enters a guard zone which exceeds the target density threshold. You can set the threshold above which a new target will trigger an alarm, and can also turn the alarm on or off.

When the alarm is triggered, the unit beeps and a text message is displayed.

► To clear the alarm, press **any** key (on the master or repeater display).

The alarm will sound again after 10 seconds, unless one or more of the following happens:

- You turn the guard zone off
- You adjust the guard zone size/shape to reduce the number of targets in the zone
- You turn the alarm off
- You decrease the alarm sensitivity
- The target leaves the guard zone
- ► To change the alarm sensitivity setting:
  - 1. Press **MULTI** to display the sliders.
  - 2. Press the ALARM soft key to highlight the Alarm slider.



- 3. If required, press the soft key again to toggle the setting between OFF and ON. You can only move the slider if the control is set to ON.
- 4. Use the trackpad to increase or decrease the alarm slider setting. You can press and hold the trackpad to change the value more rapidly.
- 5. The higher the setting, the more sensitive the alarm, and the smaller the target density required to set it off.
- 6. Press **ENTER** to clear the slider display.

MULT

# **Chapter 4: Integrated Radar Operations**

## 4.1 Introduction

This chapter explains how to use and display non-radar information that may be available from other units connected to your system. It also explains how to use the man overboard (MOB) function. You can use this chapter with the radar display set to *simulator mode*, or on the water after you have installed and set up your SL72 or SL72RC PLUS Pathfinder Radar system.

In order to use these functions, you need the following additional data from equipment connected to your system via a SeaTalk or NMEA link:

Table 4-1:Function of External Data

Data	Example source	Integrated functions available
Heading	Compass* Autopilot	<ul> <li>Heading value in status bar</li> <li>North Up or Course Up heading modes (as alternatives to Head Up</li> <li>MOB (if speed data also available)</li> </ul>

\*If heading data is available via both NMEA and SeaTalk, NMEA data takes priority. For all other data, SeaTalk data takes priority (see *Section 8.8*).

Waypoint data	Chartplotter	- Waypoint display and data
Position	GPS system	- Marks - Position data in Data Box and Nav Window - MOB - COG, SOG and time
Other data	Transducers	- Data Box and Nav Window data displays including speed, depth, wind
Chart display	Chartplotter - (SL72RC PLUS sys- tems)	- Chart display as full-screen or half-window display

This chapter covers the following topics:

- Changing the heading mode of the radar picture
- Using marks
- Man Overboard (MOB)
- Cursor echo

**Note:** Until you are familiar with interpreting the radar display, you should take every opportunity to compare the radar's display patterns with visual targets, such as other vessels, buoys and coastal structures. You should practice harbour and coastal navigation during daylight and in clear weather conditions.

ntroduction

# 4.2 Changing the Heading Mode

The radar picture is normally shown with your vessel's dead ahead bearing straight up, as indicated by the Ship's Heading Marker at 0° relative bearing. This is the Head Up orientation.

If heading information is available via a SeaTalk or NMEA connection, you can choose a different heading mode. In Course Up and North Up mode you can also select relative or true motion.

## **True and Relative Motion**

Relative motion is the default for the radar display. In relative motion your own ship's position remains fixed on the radar screen and all radar targets move relative to your own ship.

In true motion, fixed radar targets maintain a constant position on the screen, whilst your own ship moves across the radar image at the appropriate speed and heading. A map-like image is thus displayed, with all moving vessels travelling in true perspective to each other and to fixed land masses. As your ship's position approaches the edge of the screen, the radar display is automatically reset to reveal the area ahead of your ship. You can manually reset your ship's position at any time by pressing the TRUE REL soft key twice.

## **Heading Modes**

The heading modes are as follows:



Figure 4-1: Radar Heading Modes

- **Head Up:** The radar picture is displayed with the vessel's current heading upwards. As the heading changes the picture will rotate.
- North Up: The radar picture is stabilized and displayed with north upwards. As you change heading, the ship's heading marker moves.
- **Course Up:** The radar picture is stabilized and displayed with the currently selected course upwards. As you change heading, the ship's heading marker moves. If you select a new course, the picture resets to display the new course upwards.

The reference used for the Course Up depends on the information available. The first available in the following list is used:

- 1. A locked heading (i.e. the heading being used by an autopilot) over a SeaTalk connection
- 2. The heading at the time Course Up was selected

If 1. is in use and a new course (locked heading) is selected, the picture automatically rotates to the new Course Up. If 2. is in use, press the HDG MODE soft key then COURSE UP to manually reset

the Course Up to the new course.

# **Selecting the Heading and Motion Mode**

Press the HDG MODE default soft key to obtain the following display, when heading information is available:



The currently selected mode is highlighted, and is indicated in the radar status bar (N-UP, C-UP or H-UP and TM or RM).

TRUE REL

- ► To change the heading and motion mode:
  - 1. Press the HDG MODE default soft key.
  - 2. Press the soft key corresponding to the mode you require. The radar picture changes to the selected mode.
  - 3. Press **ENTER** to clear the heading mode soft keys. The current orientation is indicated in the status bar.

Note: True Motion is only available in Course Up and North up mode.

If you re-select Course Up when this is already the current mode, the Course Up reference is reassessed according to the current data.

# **Effect on VRM/EBLs**

VRM/EBLs do not move on the screen, unless you change the range, offset the centre, or change the heading mode.

- In Head Up mode, the VRM/EBLs are fixed with respect to the ship's heading marker.
- In North Up mode, the VRM/EBLs are fixed with respect to North.
- In Course Up mode, the VRM/EBLs are fixed with respect to the selected course.

# 4.3 Using Marks

The Marks function allows you to place a mark anywhere on the radar picture. You can also move existing marks or delete them. You should be aware that radar marks are not the same as chart waypoints and cannot be used in routes, nor can they be transferred to other displays.

Marks are placed with the default mark symbol  $\bigotimes$  at either cursor or vessel position. If you wish to use a different symbol, you can change the default setting from the RADAR SET UP menu (see *Section 7.4*). Mark symbols are always displayed within a circle.

Marks are stored with their latitude, longitude and symbol; the information is retained when the radar is turned off. Up to 100 marks can be stored in each display unit.

MARKS

**Note:** When you use the **MARKS** key to access the Marks function, simply press the key momentarily and release it. If you hold it down for two seconds, the Pathfinder Radar will enter man overboard (MOB) mode, as described in Section 4.4.

The Marks function is only available when your vessel's position is known via the SeaTalk or NMEA connection.

# **Placing a Mark**

► To place a mark symbol:

default symbol.



1. Press the **MARKS** key. The soft keys PLACE MRK AT CURSOR and PLACE MRK AT VESSEL are displayed.

2. To place a mark at the cursor, position the cursor at the required point. If

you are displaying the cursor position box showing the lat/long position, you can check the coordinates to place the mark accurately. Press the PLACE MARK AT CURSOR softkey. The mark is placed using the



3. To place a mark at the vessel position, press PLACE MRK AT VESSEL. The mark is placed using the default symbol.

**Note:** If the Mark database is full, a warning message is displayed, with the position (in latitude and longitude) of the oldest mark. You have the following options:

- i. Press the YES soft key to replace this old mark with the new mark.
- ii. Press the NO soft key to keep the old mark and display the next oldest mark. You can keep pressing NO to step through the mark database until a mark you wish to replace is displayed, and then press YES.
- iii. Press **CLEAR** to keep all the existing marks, and cancel the new mark placement.

## **Moving or Deleting a Mark**

You can move or delete marks using the context-sensitive cursor.

► If you have placed a mark and wish to move it later:



- 1. Move the cursor over the mark until the letters MRK are displayed.
- 2. Press ENTER to take control of the mark.
- 3. Move the mark to the new position using the trackpad.
- 4. Press **ENTER** again to drop the mark in its new position, or **CLEAR** to abandon the operation and return the mark to its previous position.
- To delete an individual mark, move the cursor over the mark until the letters MRK are displayed, then press CLEAR.

# 4.4 Man Overboard (MOB)

If you lose a person or object overboard, and need to return to the location, you should use the Man Overboard (MOB) function immediately.

Note: To obtain an MOB position, you need either of the following:

- Position data from a GPS or equivalent device
- Heading and speed data, so that the position can be calculated by dead reckoning

You can select the type of data used for the MOB position using the Set Up Menus (see *Section 7.3*).



To initiate the MOB procedure, press and hold the MARKS key for two seconds.

The Pathfinder Plus Radar then performs all the following tasks automatically:

- Marks the current position with a MOB (iii) symbol.
- The MOB waypoint replaces any current active waypoint and route.
- Displays the MOB data box, showing the bearing and distance from your vessel to the MOB waypoint position, and the elapsed time since the MOB was initiated.
- Displays the position data box, showing your vessel's position.
- As your vessel moves away from the MOB position, a dotted line is displayed connecting the MOB position and the vessel's current position.
- Sounds a 4-second alarm pattern every 30 seconds.
- Sends an MOB message to other units in the system, via the SeaTalk connection.





► To cancel the MOB, press and hold the **MARK** key for 2 seconds.

**Note:** *The MOB procedure can also be initiated or cancelled remotely if the appropriate SeaTalk message is received by the Pathfinder Radar.* 

# 4.5 Cursor Echo

MARKS

In a combined radar/chart display, or in a system with any chart display connected via Seatalk, you can set the display to enable cursor transfer. Cursor echo (accessed from the Set Up Menu) enables you to display a chart cursor on the radar picture, or a radar cursor on the chart picture.

The following options are provided:

- Radar Cursor In (SL72RC PLUS): displays the cursor from the radar on the chart window (default OFF).
- **Chart Cursor In:** displays the cursor from another chartplotter on the radar window (default OFF).

Note: The remote display must have SeaTalk Cursor Out enabled.

- SeaTalk Cursor Out: enables the output, onto SeaTalk, of the display's own cursor (default OFF).
- **Cursor Echo Local (SL72RC PLUS):** echoes the cursor position between open windows on the same display (default ON).

When the appropriate option is switched on, the display shows its own cursor, plus the cursor of the other display(s) with appropriate cursor text (RDR or CHT) to indicate its origin. This means that you could move the cursor over a target on the radar display, and check the identity of the target by looking at the radar cursor position on the chartplotter.

Refer to Section 7.3 for cursor echo setup details.

# Chapter 5: Standard Chart Operations (SL72RC PLUS only)

# 5.1 Introduction

This chapter explains how to use the chart functions to navigate with your SL72RC PLUS display. It covers the following topics:

- Using chart cards.
- Controlling waypoints, including placing, moving, editing and deleting waypoints.
- Working with routes, including creating a new route, managing routes using the route database and editing routes.
- Following routes and going to waypoints.
- Transferring Waypoints and Routes
- Using tracks, including showing tracks, setting up tracks, saving tracks and creating a route from a track (SmartRoute).

All these chart functions are available in plotter mode, so you can plot and track routes at large scales even when a chart card is not installed.

Further functions, including measuring distances and setting alarms are described in *Chapter 6*.

## Safety

The chartplotter makes it very easy to place a waypoint and travel towards it. However, you should always check first that the route is safe. If you are using the chartplotter in combination with a SeaTalk autopilot, the autopilot will prompt for confirmation before it steers the vessel towards the waypoint.

If you have entered your route using a small-scale chart, zoom in to a larger scale to check for hazards, such as small shoals, that may not be shown on the smaller scale charts.

**Note:** Until you are familiar with interpreting the chart display, you should take every opportunity to compare the displayed objects with visual targets, such as buoys and coastal structures. You should practice harbour and coastal al navigation during daylight and in clear weather conditions.

#### **CAUTION:**

The equipment should not be used as a substitute for good navigational practice nor for official government paper charts.

## 5.2 Using Chart Cards

The chartplotter has a built-in world map; most areas are displayed on a scale of 4000 nm from the top to the bottom of the screen, and can be zoomed in to 150 nm.

To use the chartplotter as a navigation aid, charts with detailed information for the area you wish to navigate are required. The charts are available on C-MAP NT electronic chart cards (C-Cards), each of which can store as many as 20 charts in an electronic format. A single C-MAP chart normally provides as much information as is available in paper charts for that geographic area, and can be displayed down to a range of 1/64 nm on the screen if the data is available.

Two card slots are provided on the display unit. Chart data from both slots can be downloaded.

The chart scale in use is indicated in the status bar - the number represents the distance (in nautical miles) displayed from the top of the chart window to the bottom of the chart window.

**Note:** You can remove and insert cards while a chart is displayed. The chart information is retained on-screen until the chartplotter redraws the screen: for example, when you pan outside the current area, or use the **RANGE** key to change the chart scale.

## **Inserting a Chart Card**

► To insert a chart card:

- 1. Check that the card is a C-MAP NT C-Card with the required chart stored on it.
- 2. Open the card cover, at the lower left of the display front panel.
- 3. Hold the card with the title label towards the left, as shown in the illustration.
- 4. Gently push the card into one of the two slots. It will only go in if it is correctly oriented. Push the card in as far as it will go, then move it to the right so that the top is under the retaining pegs. The card will be held in place by the pegs.
- 5. Close the card cover until it clicks shut, to prevent water entering the display unit.



Figure 5-1: Removing the Chart Card

# **Removing a Chart Card**

We recommend that before you remove a chart cartridge, you ensure the chart is not being used on any other display unit. Removing a chart cartridge whilst a display unit is accessing the chart may cause an operational error.

- ► To remove a chart card:
  - 1. Open the card cover, at the lower left of the display front panel.
  - 2. Press on the card you wish to remove, and move the top of the card to the left to clear the retaining pegs.

The card will spring half-way out, enabling you to grip the card and remove it from the slot.

3. Remember to close the card cover so that it clicks shut, to prevent water from entering the card reader assembly.

# **Displaying the Chart Data**

The new chart information will be displayed when you move the cursor into an area covered by the new chart or, if it is already in the area, change the range scale.

The boundary of each chart digitized in the current card is defined by a box or rectangle. (You can switch off the chart boundaries display if you wish, as part of the chartplotter set up described in *Section* 7.6.)

► To zoom in:

1. Use the trackpad to move the cursor inside one of the chart boxes, and press the lower part of the **RANGE** key.

That area is expanded, with the cursor at the centre, so that you can see more detail. Note that the smaller the chart box is on the screen, the further you can zoom in and the greater the amount of detail that is available.

If you have switched on **Plotter Mode** (see *Section 7.6*), you can zoom in further than the most detailed chart; all chart functions remain available.

# **Displaying Object Information**

Chart cards include a number of displayed objects for which information is available, such as lights and buoys. If your chart includes port and tide data, this can be displayed along with information for the nearest port facility (for a selected position). Chart source data is also available. You use the contextsensitive cursor to identify the object and display detailed information.

- ► To obtain the chart object, port or tide information:
  - 1. Move the cursor over the symbol for which you require the information. An Object data box such as the following is displayed at the lower left corner of the screen:

	1 Object	
Caution	area	

2. To view further details, press **ENTER**. The details available are listed onscreen in an object information pop-up.

Use the trackpad to move the selection bar over the required item then press **ENTER** to display the full details.

3. Press **CLEAR** twice to remove the pop-up from the screen and return to the default display.

#### **Chart Source Data**

The chart card contains additional background data for most chart objects, icons, lines, open sea areas etc. Some of these items automatically provide an information data box, as described above. For other chart objects, such as bridges and territorial lines, you need to press **ENTER** to display the object information pop-up.

To obtain chart source data, move the cursor so that is not over a symbol, then press ENTER.

An object information pop-up is displayed, providing source information for the selected land or depth area.



#### Port Area

At large chart scales **port area** information is indicated by the symbol ④. An object information pop-up provides the name of the marina or port and a list of the facilities available.

Where available, details for each facility can be displayed. This information includes items such as accommodation, slip sizes, fueling, sanitation, electrical or other maintenance services provided, VHF channels monitored, and other safety and navigation information.

In some areas the chart shows symbols for individual facilities. The facilities and their associated symbols are illustrated in *Figure 5-2*.



Figure 5-2: Port Symbols

#### Tide Data

The symbol T indicates **tide height** data is available for that position on the chart. When you select the tide height option, a graph of predictions for maximum and minimum tide heights is displayed, data for sunrise and sunset is also provided as illustrated *Figure 5-3*.

**Note:** The predictions available are sufficiently accurate under moderate weather conditions, for the coastal areas served by the reference station, to be used for navigation planning. However, certain weather fronts and storms can alter tidal patterns and influence predicted times and heights.

The cursor, represented by a dotted vertical line on the graph, is used to select a time for which the tide height is displayed.

You can use the soft keys and trackpad to change the date for which tide information is shown.



Figure 5-3: Tide Data

- ➤ To select a time, use the trackpad to move the cursor to the required time.
- To change the day press PREV. DAY, DAY or TODAY, as required. Alternatively, press SET DATE; to change date, use the trackpad to move the cursor left/right to select the character and up/down to increase/decrease the value. The graph and tide data will be updated accordingly.

## Nearest

- ► To obtain the information for the nearest port facility:
  - 1. Move the cursor to the required position this can be anywhere on the chart and may be over an object then press **ENTER** to display the object information pop-up.
  - 2. Press the NEAREST soft key. The port facility symbols are displayed.
  - 3. Use the trackpad to highlight the required facility, then press **ENTER**.
  - 4. The nearest ports providing that facility are listed with distance and bearing to the port.

If you highlight a port name then press **ENTER**, details for that facility are displayed. Typical port data is shown in *Figure 5-4*.

Press **CLEAR** to return to the port list.

Press **CLEAR** to return to the facility symbols.

5. Press **CLEAR** to return to the default display.



Figure 5-4: Nearest Port - Typical Data

## 5.3 Working with Waypoints

#### Introduction

The SL72RC PLUS Chartplotter enables you to place up to 998 waypoints (in addition, waypoint number 999 is used for MOB operation): a waypoint is a position entered on a chart as a reference, or as a place to go to. All waypoints *placed on the chartplotter* are stored in a waypoint database list which includes symbol, position, bearing, range and additional data. All waypoints in the database are displayed on the screen, unless you set waypoint display off in the Chart Set Up menu, as described in *Chapter 7*. You can select a waypoint, either on-screen or from the list, for editing.

A waypoint can be placed at the cursor position, or at the vessel's current position (this is sometimes known as an event mark); a waypoint at the vessel position includes additional information (if available) on the depth and temperature when it was placed. Alternatively, you can manually enter Waypoints as either Lat/Long coordinates or Loran TDs which are automatically converted into Lat/Long coordinates. All waypoints can be included in a route. You can place waypoints, using simulator mode, before you install the chartplotter on your vessel.

#### **Note:** Radar marks may also be displayed on the screen; these are screen annotations - you cannot GOTO marks, nor include them in routes.

When you place a new waypoint, it is displayed using the default symbol of a cross (unless you have changed the symbol in Chart Set Up). The waypoint is added to the waypoint list and tagged with the next available number. You can use the edit functions to change the symbol and name. When the cursor is positioned over a waypoint, the waypoint bearing and range are displayed.

Waypoints in the current route are available on other SeaTalk instruments that support current route transfer, for example, another SL72RC Chartplotter or ST80 Masterview. You can transfer waypoints between the chartplotter and other NMEA or SeaTalk instruments using the Waypoint Transfer functions. You can also save waypoints to, or load them from, a user cartridge. These functions are described in *Section 5.6*.

This section explains how to perform the following tasks using the on-screen cursor and the waypoint list:

- Placing a Waypoint
- Selecting a Waypoint
- Displaying Waypoint data
- Editing a Waypoint (symbol, name & position)
- Erasing a Waypoint

Downloaded from www.Manualslib.com manuals search engine

Placing a Waypoint

• Moving a Waypoint

At the end is a section about using the ST60/80 Navigator Keypad to select, edit, and name your waypoints.

# **Placing a Waypoint**

The scenario *Place and Goto a Waypoint* on *page 2-24* provides a simple example of how to place a waypoint.

➤ To access the place waypoint soft keys, press **MARKS**:





- To place a waypoint at the cursor position or at the vessel position:
  - Press either the PLACE WPT AT CURSOR or the PLACE WPT AT VESSEL soft key. The waypoint is added to the waypoint list and tagged using the next available number.

The waypoint soft keys are displayed until you move the cursor away from the waypoint or press **CLEAR**.



You can use the EDIT WAYPOINT soft key to name the waypoint as described in Editing Waypoints below.

2. Press **CLEAR** or **ENTER** to remove the place waypoint soft keys.

To place a waypoint as latitude/longitude using the Waypoint List:

MARKS

1. Press **MARKS**, followed by the WAYPOINT LIST soft key. The Waypoint List and associated soft keys are displayed.



2. Press the MAKE NEW WAYPOINT soft key followed by the LAT/LONG soft key; the WPT POSITION (LAT/LONG) screen is displayed, with it's associated soft keys. The waypoint is placed at the current vessel position, or if not available, the cursor position.



SYMBOL         NAME           Image: Symbol         Waypoint 001           Image: Waypoint 002         Waypoint 002           Image: Waypoint 003         Waypoint 003           Image: Waypoint 004         Waypoint 004           Image: Waypoint 005         Waypoint 005           POSITION         50°21′.966N           Image: Stress of the stress of t	WAYPOI	NT LIST
Image: Waypoint ool           X         Waypoint oo2           X         Waypoint oo3           X         Waypoint oo3           X         Waypoint oo4           X         Waypoint oo5           POSITION         50°21′966N 001°20′368W           BRG_186°         RNG_21.0nm           TEMP         DEPTH         mm           DATE         TIME         mm	SYMBOL	NAME
X       WAYPOINT 002         X       WAYPOINT 003         X       WAYPOINT 004         X       WAYPOINT 004         X       WAYPOINT 005         POSITION       50°21'966N 001°20'368W         BRG _186°       RNG _21.0nm         TEMP          DATE	\$	WAYPOINT 001
X         WAYPOINT 003           X         WAYPOINT 004           X         WAYPOINT 005           POSITION         50°21′966N 001°20′368W           BRG_186°         RNG_21.0nm           TEMP            DATE	×	WAYPOINT 002
X         WAYPOINT 004           X         WAYPOINT 005           POSITION         50°21'966N 001°20'368W           BRG _186°         RNG _21.0nm           TEMP            DATE	X	WAYPOINT 003
X         WAYPOINT 005           POSITION         50°21(966N 001°20(368W)           BRG_186°         RNG_21.0nm           TEMP            DATE	X	WAYPOINT 004
POSITION         50°21'966N 001°20'368W           BRG _186°         RNG _21.0nm           TEMP°C         DEPTHm           DATE         TIME	X	WAYPOINT 005
BRG _186°         RNG _21.0nH           TEMP°         DEPTHm           DATE         TIME	POSITION	50°21′966N 001°20′368W
TEMPO DEPTHm DATE/ TIME::	BRG _186°	RNG _21.0nm
DATE/ TIME::	TEMP°C	DEPTHm
	DATE//	TIME::
		MAKE NEW WAYPOJ
30TO EDIT MAKE NEW WAYPOJ ZPOTNI WAYPOINI WAYPOINI IRANSE		

3. You can use the soft keys to edit the waypoint position as described in *Edit-ing the Waypoint Details* on *page 5-13*.

It is added to the Waypoint List and named with the next available number.

To return to the default soft key display, press ENTER or CLEAR twice.

- ► To place a waypoint as Loran TDs using the Waypoint List:
  - 1. Press **MARK**, followed by the WAYPOINT LIST soft key; the Waypoint List and associated soft keys are displayed.
  - Press the MAKE NEW WAYPOINT, the waypoint is placed at the current vessel position, or if not available, the cursor position. To change the position press the LORAN TDs soft key; the WPT POSITION (LORAN TDs) screen is displayed, with it's associated soft key.

**Note:** You can enter waypoints as Loran TDs which are converted to Lat/Long coordinates. However, although the waypoint is shown in both Lat/Long and Loran TDs in the Waypoint List, you can subsequently only edit the position as Lat/Long coordinates. TD entries in the Waypoint List are shown only for those waypoints which were entered as TDs.

H	PT POSITION (LORAN TDs)
CHAIN	6731 - NELS Lessay
SLAVES	Y - Z (24 -39)
TD 1	29138.0
TD 2	44713.8
ASF 1	+0.0
ASF 2	+0.0



- 3. Edit the Loran parameters as required, using:
  - i. The CHAIN soft key, which enables selection of both the Chain and it's Slave:

HF	PT POSITION (LORAN TDs)
CHAIN	6731 - NELS Lessay
SLAVES	Y - Z (24 -39)
TD 1	29138.0
TD 2	44713.8
ASF 1	+0.0
ASF 2	+0.0



ii. The ASF1/ASF2 soft key, which presents two soft keys for editing ASF 1 and ASF 2 parameters independently:



iii. The SET TD 1 and SET TD 2 soft keys, which enable editing of each TD's parameters independently.

**Note:** *Except for the* CHAIN *setting, parameters are edited using the* trackpad *as described in Editing the Waypoint Details on page 5-13.* 

4. When editing is complete, press the **ENTER** key to save the waypoint or **CLEAR** to cancel the operation; the display returns to the New Waypoint screen.

Press the ENTER or CLEAR to return to the Waypoint List.

## **Selecting a Waypoint**

Positioning the cursor over a waypoint selects that waypoint and accesses the waypoint soft keys. These keys enable you to GOTO (described in *Section 5.5*), EDIT (symbol, name, position), ERASE or MOVE the waypoint. Selecting a waypoint from the List allows you to GOTO and EDIT (symbol, name, position, erase) the waypoint. The Waypoint List also provides options to make a new waypoint and transfer waypoints.

- ► To select a waypoint using the cursor:
  - 1. Move the cursor over the waypoint, until the letters WPT are displayed.
  - The Waypoint Data box (see *Waypoint Data Display* on *page 5-12*) and the following soft keys are displayed:



The selected waypoint can be edited via these soft keys.

► To select a waypoint using the Waypoint List:



- Press MARKS, followed by the WAYPOINT LIST soft key. The Waypoint List and associated soft keys are displayed. The list details all waypoints in alpha-numeric order. The selected waypoint is indicated by the selection bar; its position, bearing and range are provided.
- 2. Use the trackpad to move the selection bar up and down the list to highlight the required waypoint.

The selected waypoint can be edited via the soft keys displayed.

# **Waypoint Data Display**

Waypoint data can be viewed in two ways: you can use the context-sensitive cursor to select the waypoint and thus display the waypoint data box, or you can view waypoint details on the waypoint list.

**Note:** To permanently display the target waypoint data box, select it in the System Set Up menu (see Section 7.3) and use the SCREEN soft key to switch data boxes on.

To display the waypoint data box, move the cursor over the waypoint. The waypoint data box is displayed, this indicates waypoint number/name, bearing and range (or latitude and longitude if selected in system set up).



While the cursor is over the waypoint, the waypoint soft keys are displayed.

► To remove the waypoint data box and soft keys either:

Move the cursor away from the waypoint, or press CLEAR.

➤ To display the waypoint details from the waypoint list:



Select the waypoint in the list as described above.

The details for the selected waypoint are displayed in the lower half of the window. Temperature, depth, date and time are included (if available) for waypoints placed at the vessel position.

To remove the Waypoint List and return to the default soft key display, press **CLEAR** twice.

# **Editing the Waypoint Details**

You can change the name, symbol and position of any waypoint.

- ► To edit a waypoint:
  - 1. Select the waypoint, using the cursor or the waypoint list, as previously described. The waypoint soft keys are displayed.



2. Press the EDIT WAYPOINT soft key. The Edit Waypoint soft keys are displayed:



3. To edit the symbol, press the SYMBOL soft key.

Use the soft keys, shown in the following illustration, to highlight the required symbol, then press **ENTER** to confirm the selection.

Press **ENTER** or **CLEAR** to return to the default soft keys.



4. To edit the waypoint name, press the NAME soft key.

The NAME WAYPOINT window is displayed.

Use the trackpad to enter or edit the name:

Use the left or right side of the trackpad to move the cursor to the character you wish to change.

Use the top or bottom of the trackpad to scroll through the characters.

When you have finished editing the name, to remove the window, press **ENTER** to save the name or **CLEAR** to cancel the operation. The waypoint name replaces the waypoint number.

Press **ENTER** or **CLEAR** to return to the default soft keys.



5. To edit the waypoint position, press the EDIT WAYPOINT soft key, followed by POSITION. The Waypoint Position pop-up is displayed.

Use the soft keys to select LAT, LON, BRG or RNG.

Use the trackpad to edit the value:

Use the left or right side of the trackpad to move the cursor to the character you wish to change.

Use the top or bottom of the trackpad to scroll through the characters. Adjust each parameter until the waypoint position is correct.

When you have finished editing the position, press **ENTER** to save the position or **CLEAR** to cancel the operation. Press **ENTER** or **CLEAR** again, the Waypoint Position window is removed from the screen and the default soft keys are displayed.

# **Erasing a Waypoint**

You cannot erase the target waypoint or waypoints that are used in routes. However, you can remove a waypoint from the current route - see *Editing a Route* on *page 5-27*.

If you try to erase a waypoint that is used in a saved route you are warned "WAYPOINT IS USED IN A ROUTE & CANNOT BE DELETED"

- . ₩PT
- To delete a waypoint using the cursor:
  1. Move the cursor over the waypoint, until the letters WPT are displayed. The



waypoint soft keys are displayed.Press the ERASE WAYPOINT soft key. The waypoint is removed from the screen and the Waypoint List is updated.

**Note:** If you have stopped a GOTO (see Stop Follow or Stop Goto on page 5-34), the target waypoint remains displayed as a target; you need to use the CLEAR GOTO soft key before you can erase the waypoint using the cursor.

► To delete a waypoint using the waypoint list:



- 1. Select the waypoint from the waypoint list as previously described. The waypoint list soft keys are displayed.
- 2. Press the EDIT WAYPOINT soft key, followed by ERASE WAYPOINT. The waypoint is removed from the screen and the waypoint list is updated.

# **Moving a Waypoint**

You can move any waypoint except the target waypoint (the waypoint you are following). You can use the Waypoint soft keys and cursor to move the selected waypoint, or you can edit the waypoint position.

#### CAUTION:

Take care when editing waypoints as it is possible to move waypoints that are used in routes stored in the Route Database. In such instances, the stored route will include the waypoint in its new position.

► To move a waypoint using the cursor:



MOVE

- 1. Move the cursor over the waypoint, until the letters WPT are displayed. The waypoint soft keys are displayed.
- 2. Press MOVE WAYPOINT, the cursor changes to a four-headed arrow.
- Move the cursor to the required waypoint position.
   Press ENTER to set the position and return to normal cursor control.
   Press CLEAR to cancel the operation.
- ► To move a waypoint using the Waypoint Edit functions:
  - 1. Select the waypoint using either the cursor or the waypoint list as described above. The waypoint soft keys are displayed.
  - 2. To edit the waypoint position proceed as previously described in *Editing the Waypoint Details* on *page 5-13*.

## Using the ST60 or ST80 Navigator Keypad

If you have an ST60 or ST80 Navigator Keypad connected on SeaTalk it can be used to name or edit your waypoints, tracks, or routes on any display in the system. The keypad can also be used to select entries in the Waypoint List. The Navigator provides 10 dedicated alphanumeric keys, a multidirectional cursor control pad, plus Insert and Delete keys.

**Note:** When using the Navigator Keypad, you should be aware that it can control several displays simultaneously; any display in edit mode (i.e. ready for alpha-numeric data entry) will be affected by the Navigator Keypad.



Figure 5-5: ST80 Navigator Keypad
Most of the alphanumeric keys are used to input multiple characters. Each time you press one of these keys in succession, the next character on that key is input. For example, each press of the **1** key alternately inputs A, B, C, then 1.

The Navigator's arrow keys function much like the radar/chart display's, enabling you to move the cursor position or input alpha, numeric, or special characters (., -/`&).

The **ins** key functions the same as the **ENTER** key on radar/chart display and **del** inserts a space during edit mode.

#### Selecting an Entry in the Waypoint List

The Navigator can be used to select an existing item in the Waypoint List. This can be accomplished using the arrow or alphanumeric keys.

- ► To select an existing item in the Waypoint List:
  - 1. Use the up and down arrow keys to move the selection bar up and down the list to highlight the desired entry.

or

Press the alphanumeric key that contains the first letter or number of the desired waypoint name. The selection bar moves to the entry starting with that letter or number.

If more than one entry begins with that character, the selection bar moves to the first one in the list. Each time the same key is pressed, the selection bar moves to the entry starting with the next character on the key. If no entry exists for that character, the entry starting with the nearest previous character is selected. If the numeric value of the key is input when no numeric entry exists, the selection bar moves to the first alpha entry.

For example, let's say we have four waypoints named ORION, POLARIS, QUANTUM, and 6-GUN. Pressing the **opq/6** key four successive times would select the waypoints ORION (O), POLARIS (P), QUANTUM (Q), then 6-GUN (6). However, pressing the **rst/7** key four successive times would select QUANTUM for the first three key presses because entries beginning with the associated letters do not exist and Q is the next previous beginning letter. The fourth press of the **rst/7** key would select 6-GUN because no entries begin with a 7 and 6 is the next previous beginning number.

2. Use the **ins** key like the display's **ENTER** key, to close the Waypoint List. The **del** key and left and right arrow keys do not function in select mode.

#### Editing Entries in the Waypoint, Route, or Track Lists

You can also use the Navigator Keypad to edit an existing item or to name a new item in the Waypoint List, Route List, or Track List. You first must enter the edit mode for the list you want to modify. Methods for editing each list are described in the respective sections of this chapter.

- ► To edit an item in a list using the Navigator Keypad:
  - 1. If necessary, use the right and left arrow keys to move the cursor to the desired character position.
  - 2. Press an alphanumeric key until the desired character is displayed. Each time you press one of these keys in succession, the next character on that key is input.

or

1. Use the up and down arrow keys to scroll through the list of alpha, numeric, and special characters until the desired character is displayed (just as you would with the ). Note that you must use this method to input special characters; they are not available using the alphanumeric keys.

Use the **del** key to insert a space, if required.

- 2. Use the arrow keys and alphanumeric keys to input the remainder of the characters required to complete the editing.
- 3. When done, press the **ins** key to enter your changes.

#### 5.4 Working with Routes

A route is made up of a series of waypoints (maximum 50). To make a route you place a series of waypoints on the chart, or you can select waypoints from the Waypoint List. You can also save your vessel's track as you navigate, then convert the track to a route - this function is described in *Section 5.7*.

When a route is created it becomes the current route and is displayed onscreen. The current route is maintained when you power-off. Only one route can be current and is displayed (if it is in the field-of-view) as solid lines connecting waypoints. If you are following the route, the current leg is shown as a dotted line and previous legs are removed from the screen (although the waypoints remain displayed). The current route (and its waypoints) is transferred via SeaTalk to a repeater chart display and other instruments. You can also use the Waypoint Transfer functions to transfer the route database to a repeater display.

Once you have created a route you can use the GOTO soft keys to follow the route. In addition, the GOTO default soft key provides various options as described in *Section 5.5*.

Up to 20 routes can be saved in the route database. You can then select a route from the database list as the current route.

The current route can be edited by adding and moving waypoints. The current route is always placed in the database list as route number 0, so you can edit the current route without affecting the original route in the database. Once a route has been saved, options are also provided to name a route, erase a route and to display route details.

You can use the route information to review your passage plan by adjusting the planned Speed Over Ground (SOG).

#### Note:

It is possible for the current route to be overwritten by a route from another unit on an integrated system, so it is advisable to save all routes.

This section explains how to perform the following tasks:

- Creating a new route.
- Saving the current route in the database list.
- Clearing the current route.
- Retrieving a route from the database list as the current route.
- Displaying route information, including the route leg data and waypoint details. Use the waypoint details to review your passage plans for different speeds.
- Using the database list to erase and name existing routes.
- Editing a route by adding, removing and moving waypoints.

5-18

► To access the route soft keys, press the default soft key ROUTE:

ROUTE



#### **Creating a New Route**

**Note:** If there is a current route, it is cleared when you select MAKE ROUTE. If you are following the current route you are prompted to STOP FOLLOW. Press the YES soft key to continue, or NO to abandon route creation. If the route has not been saved you are prompted to save it.

The chart scenario *Make and Follow a Route* on *page 2-26* provides a simple example of how to create a route.

There are two methods to create routes, whilst creating a route you can switch between these methods:

- Placing new waypoints on the chart.
- Selecting existing waypoints from the Waypoint List.

You can edit a route after you have finished making it, as described in *Editing a Route* on *page 5-27*.

To make a new route by placing waypoints:

route soft keys are displayed:

Note: You can pan the chart and change the scale while placing waypoints.

1. If necessary, move the cursor to the area in which you wish to make the route, and select a suitable chart scale.

2. Press the ROUTE soft key, then press the MAKE ROUTE soft key. The make

ROUTE



PLACE AYPOTN1



3. Move the cursor to the position on the chart where you want your first waypoint to be. Press the PLACE WAYPOINT soft key.

**Note:** You can position the cursor on an existing waypoint – the cursor text WPT indicates you are re-using the waypoint rather than placing a new one. This waypoint is included in the route when you press PLACE WAYPOINT.

The waypoint appears on the screen at the cursor position. The number displayed alongside the waypoint identifies its position in the route. The new waypoint is temporarily added to the waypoint list with the first available waypoint number. The waypoints in the current route are re-numbered to identify the new positions.



#### Note: If you Clear the route before it is Saved, the waypoint is removed.

4. Move the cursor to the next waypoint position. A dotted line connects the cursor to the last placed waypoint.



JAYPOTN1

ACCEPT ROUTE



If you placed the waypoint incorrectly, you can delete the last-placed waypoint by pressing the UNDO WAYPOINT soft key.

- 6. Repeat steps 4 and 5 until you have placed all your waypoints. You can have up to 50 waypoints in a route.
- 7. When you have entered all your waypoints, either:

Press the ACCEPT ROUTE soft key (or **ENTER**) to complete the route. Your route is displayed on the screen, and is the current route, but it is not active.

The first waypoint of a new route is outlined with a square, indicating that it will be the target waypoint when the route is activated. If selected, the waypoint data box is displayed for the target waypoint.

You can save the route as described below.

**Note:** The completed route is stored in the display unit, and will be re-displayed if you turn the unit off and on again. However, on an integrated system it is possible for a current route from another unit to overwrite this route; it is therefore recommended that you Save the route as described below.

- ► To make a new route using the Waypoint List:
  - 1. Press the ROUTE soft key; the route soft keys are displayed.



2. Press the MAKE ROUTE soft key; the make route soft keys are displayed.



3. Press the USE WPT LIST soft key; the MAKE ROUTE screen is displayed with its associated soft keys.

MAKE	MAKE ROUTE	
WAYPOINTS	NEW ROUTE	
COWES	01 HARBOUR	
GURNARD LEDGE	02 MAIN CHANNEL	
MAIN CHANNEL	03 COWES	
NEEDLES FAIRWAY	04 LYMINGTON	
PORT SOLENT		
50°50'000N	50°52/230N	
001°06/000W	001°02/390W	
348°m 2.30nm	300°m 1.00mm	
INSERT REMOVE	ACCEPT USE ROUTE CURSOR	

The available Waypoints are listed in the left hand column (alphanumeric); the right hand column lists the waypoints in the New Route, the number indicates its order in the route. The lower part of the table shows position, bearing and range of the highlighted waypoint.

You use the trackpad left/right to move control between the two columns (the highlighted title indicates the selected column) and the trackpad up/down to scroll through the lists.

- 4. Select a waypoint from the Waypoint List then go to the New Route column and select a position in the list.
- 5. Press the INSERT WAYPOINT soft key to place the waypoint *below* the selected position in the Route. You can have up to 50 waypoints in a route.
- 6. To remove a waypoint from the New Route column, highlight the waypoint and press the REMOVE WAYPOINT soft key.

**Notes:** (1)*A* waypoint cannot be used more than once in a route; those already used are displayed in a lighter shade of gray.

**Notes:** (2) *The* INSERT WAYPOINT *or* REMOVE WAYPOINT *action adds/removes the highlighted waypoint to/from the Route column, regardless of which column is selected.* 

7. When all waypoints have been entered, press the ACCEPT ROUTE soft key (or **ENTER**) to complete the route.

**Note:** The completed route is stored in the display unit and will be re-displayed if you turn the unit off then on again. However, on an integrated system it is possible for a current route from another unit to overwrite this route; it is therefore recommended that you save the route, as described in Saving the Current Route on page 5-22.

#### **Saving the Current Route**

You can save up to 20 named routes in the route database list. These routes can then be re-displayed and followed at a later date. When you save the route, all new waypoints are saved in the Waypoint List.

**Note:** If the current route has not been saved, when you attempt an operation that affects this route, e.g. CLEAR ROUTE, you are prompted to save it.

► To save and name the current route:



SAVE ROUTE

- 1. To access the SAVE ROUTE soft key, press the ROUTE soft key, followed by MORE.
- 2. Press the SAVE ROUTE soft key. The save route pop-up and the NAME ROUTE soft keys are displayed as illustrated in *Figure 5-6*.
- 3. The next available entry on the route list is highlighted. (If required, you can use the trackpad to select another position in the list; this can be a blank slot, or an existing route that you no longer require).

	SAVE	ROUTE	
1	EMPTY		
2	EMPTY		
3	EMPTY		
4	EMPTY		
5	EMPTY		
		NAME	ROUTE?
		YES	NO

Figure 5-6: Save Route Window

4. If you do not wish to name or re-name the route, press the NO soft key to clear the list. The route is saved and is listed as Route Not Named.

If you wish to name the route press the YES soft key. Use the trackpadto move the cursor right or left to the character you wish to edit. Then use the top or bottom of the trackpad to increase or decrease the letter or number.

You can use a Navigator Keypad (see *Using the ST60 or ST80 Navigator Keypad* on *page 5-15*) to name the route.

5. Press **ENTER** to finish and clear the Name List, or press **CLEAR** to cancel the operation. To return to the default soft key display, press **ENTER** again.

# **Clearing the Current Route**

You can clear the current route from the screen. When you select CLEAR ROUTE if the current route has not been saved, you have the option of saving it and, if you are following the current route, you have the option to stop.

► To clear the current route:



 Press the ROUTE default soft key or place the cursor over a route leg until the text RTE is displayed.
 Press the CLEAP POULTE off key.

Press the CLEAR ROUTE soft key.



2. If you are following the current route the STOP FOLLOW soft keys are displayed.

To cancel the CLEAR operation press NO. To stop following and clear the route press YES.



3. If the route has not been saved the SAVE ROUTE soft keys are displayed. To clear the route, without saving it in the route database, press NO. To save the route in the database, press YES. The Name route soft keys are displayed and you should continue as described in the previous section, *Saving the Current Route* on *page 5-22*.

The current route is cleared from the screen and the default soft keys are displayed. You can now use the ROUTE soft keys to make a route, or to show another route from the database.

# **Retrieve a Route From the Database**

You can select a route as the current route from the database list. The list is accessed from the second set of ROUTE soft keys.

► To select a route as the current route:



- 1. Press the ROUTE soft key, followed by MORE, then press ROUTE LIST. The route list is displayed as illustrated in *Figure 5-7*. The selection bar indicates the selected route.
- 2. Use the trackpad to select the required route then press the SHOW ROUTE soft key. The chart is re-drawn at a scale suitable to display the whole route.



Figure 5-7: Route List Window

# **Displaying Route Information**

You can display the following information that relates to your route:

- Route leg or waypoint information, using the context-sensitive cursor.
- Details of waypoints in the route, using the soft keys. You can use this information to review your passage plan.

#### **Route Leg and Waypoint Information**

To display information about a route leg, move the cursor over the leg until the letters RTE are displayed. A Route Leg data box such as the following is displayed.

ROUTE NO.	
ROUTE NAME	
LEG 02 - 03	
0°T 5.5nm	

To remove the data box, move the cursor away from the route or press **CLEAR**.



To display information about a route waypoint, move the cursor over the waypoint until the letters WPT are displayed. The waypoint data box is displayed, this box includes the route and waypoint number.
To remove the data box, move the cursor away from the route or press CLEA.

To remove the data box, move the cursor away from the route or press **CLEAR**.

5-24

#### **Using Route Information to Review Your Passage Plan**

You can view data for all the waypoints in the current route, or any saved route.

You select the route from the database list and the information is displayed in a Route Information pop-up; the following details are provided for each waypoint:

Position Bearing (from previous waypoint) Length of leg (from previous waypoint) Total Length Time (ETA or Elapsed)

Soft keys are provided to toggle the time between ETA or elapsed and to change the Speed Over Ground (SOG) value; the ETA for each waypoint is calculated using the selected SOG, so you can change the SOG to determine its effect on your ETA.

The chart scenario *Review Your Passage Plan* on *page 2-28* provides a simple example of how to use the route information.

➤ To display information about any route in the database:



- 1. Press the ROUTE soft key, followed by MORE, then press ROUTE LIST. The route list is displayed. The selection bar indicates the selected route.
- 2. Use the trackpad to select the required route, then press the ROUTE INFO soft key.

The Route Information pop-up is displayed. As illustrated in *Figure 5-8*, this lists the waypoints in the route and details bearing, length of each leg, total distance, and either the estimated time of arrival (ETA) or the elapsed time.

The soft keys allow you to toggle between ETA or total (elapsed) time, and to change the Speed Over Ground (SOG) value used in the time calculations. The current selections are highlighted.

- ► To change the SOG used for ETA calculations:
  - 1. Press one of the PLANNED SOG keys to switch from actual to planned SOG.
  - 2. Press the up or down PLANNED SOG keys to change the planned SOG value. The Time values in the Route Information list are updated.
  - 3. Press the ACTUAL SOG key to use the actual SOG value rather than a planned one.

I	NFO FOR	ROUTE	E-CURR	ENT ROUTE
WPT	POSITION	BRG D	ISTANC	E TOTAL TIME
		• I	rm 	nm EIA
01	50°21:97	N	0.0	0.0:
I	001°15/80	М		
02	50°21/97	N 090	4.4	4.4:
I	001°08/75	М		
03	50°27:48	N 000	5.5	10.0:
	001°08/75	М		
	A		1	
T		SOG	F	LANNED SOG
TA.	TOTAL 1	.0Kn		0.0Kn
		$\checkmark$		

Figure 5-8: Route Information Window

- 4. Press ENTER to remove the Route Information window, then ENTER or CLEAR to return to the route soft keys.
- 5. To return to the default soft key display, press **ENTER**.

### Using the Route List to Erase and Name a Route

You can delete a route and you can re-name a route by selecting the route on the route list.

- ► To select a route to delete or re-name:
- ROUTE
- Press the ROUTE soft key, followed by MORE, then press ROUTE LIST. The route list is displayed. The selection bar indicates the selected route. Press the appropriate soft key – ERASE ROUTE or NAME ROUTE.



 If you ERASE a route you are prompted to confirm. Press NO to cancel the operation, then ENTER or CLEAR if you wish to remove the route list. Press YES to erase the route from the list, then ENTER or CLEAR to remove the route list.

- NAME ROUTE
- 3. If you NAME a route, use the trackpad to move the cursor right or left to the character you wish to edit. Then use the top or bottom of the trackpadto increase or decrease the letter or number.
- 4. Press **ENTER** to clear the Name List, or **CLEAR** to cancel the name then to return to the default soft key display, press **ENTER** again.

# **Editing** a Route

Once you have created a route, you can edit it using the Waypoint List as described in *Creating a New Route* on *page 5-19*, or using the context-sensitive cursor to:

- Insert a Waypoint into the route
- Add waypoints at the end of the route
- Remove a Waypoint
- Reverse a Route
- Move a Waypoint as described in *Moving a Waypoint* on page 5-14.

Any changes you make to the route, except move a waypoint, affect only the current route. The current route is always held in position 0 in the database, so you need to Save the route if you want to keep the changes.

### Inserting a Waypoint into a Route

You can use the context-sensitive cursor to insert one or more waypoints in the current route. However, if the route is being followed you cannot insert a waypoint into the current leg.

► To insert a new waypoint in the current route:

- 1. Move the cursor over the route leg into which you wish to insert a waypoint. The letters RTE and the route leg data box are displayed. The Route soft keys are displayed.
- 2. Press **ENTER**. The cursor changes to a four-way arrow, controlling a new waypoint. The waypoint is connected to the existing waypoints on either side with a dashed line.
- 3. Move the new waypoint to the required position, and press **ENTER** to drop it and return to normal cursor operation, or **CLEAR** to abandon the operation.

The new waypoint is temporarily added to the waypoint list and named with the first available waypoint number. The waypoints in the current route are renumbered to identify the new positions.

Note: If you Clear the route before it is Saved, the new waypoint is removed.

#### Adding Waypoints at the End of the Route

- ➤ To add waypoints at the end of the route:
  - 1. Press the ROUTE soft key, followed by the EDIT ROUTE soft key. The Make Route soft keys are displayed and the cursor is connected to the last-placed waypoint with a dotted line. You can add further waypoints to the route in the same way as for a new route.
    - 2. Either:



LINDO

ACCEPT ROUTE

MAYPOIN

ROUTE

EDIT

ROUT

i. Move the cursor to the required location, and press PLACE WAYPOINT soft key.

If you place the waypoint in the wrong position, press the UNDO WAY-POINT soft key.

Or

- ii. Press USE WPT LIST, the MAKE ROUTE pop-up is displayed. Select a waypoint from the Waypoint List then press the INSERT WAY-POINT soft key to place the waypoint at the end of the Route.
- 3. Place as many waypoints as required, and press the ACCEPT ROUTE soft key, the default soft keys are displayed.

**Note:** You can UNDO waypoints in the original route, not just the new ones.

# Removing a Waypoint from the Route

➤ To remove a waypoint from the current route:





- 1. Move the cursor over the required waypoint until the letters WPT are displayed. The waypoint soft keys are displayed.
- 2. Press the REMOVE WAYPOINT soft key. The waypoint is removed from the route and the route is re-numbered.

Alternatively, you can remove the last waypoint from a route by pressing the UNDO WAYPOINT soft key, as described above in Adding Waypoints at the End of the Route on page 5-28.

If the route has *not* been saved and the waypoint was placed as part of the route, the waypoint is erased.

If the route has been saved, or the waypoint existed before you created the route, the waypoint remains on the screen.

#### **Reversing the Route**

➤ To reverse the route, so you can Follow the route back:

ROUTE

1. Either press the ROUTE soft key followed by MORE, or move the cursor over the required waypoint until the letters RTE are displayed.

The route soft keys are displayed.



2. Press the REVERSE ROUTE soft key. The current route is reversed on the screen.

# 5.5 Following Routes and Going to Points

The default soft key GOTO accesses the functions to FOLLOW a route and GOTO a waypoint or cursor. When you select the target destination, the chartplotter calculates bearing, distance and cross track error; this information is passed to a helmsman or autopilot. You can also restart the cross track error (XTE) from the actual vessel position to set XTE to zero at that point.



When the chartplotter is following a route, the target destination is indicated by a square around the waypoint (or cursor marker) and a dotted line shows the intended track, from your start point or previous waypoint, to the target waypoint.

This section describes the following:

- Follow a route either forwards, or in reverse order.
- Target Point Arrival
- Other follow route options, including joining at a selected waypoint, advancing waypoints, and restarting XTE.
- Go to an individual point, either an existing waypoint or the cursor.
- Stop and Restart Follow/Goto.

An alarm is triggered when you approach a waypoint, this section describes what happens when you arrive at waypoints. *Chapter 6* describes how to set the alarm.

The chartplotter can also display the vessel's actual track and the track can be recorded for later display. The Track function is described in the *Section 5.7*.

To access the Goto/Follow soft keys, press the default soft key GOTO (the soft keys differ if a follow or goto is already in progress):



#### **Follow a Route**

**Note:** The current route may have been created on this display, or created on another unit and received on this display via SeaTalk. If a route has been reversed or if a route on screen was being followed but stopped before completion, the target waypoint – outlined by a square box – may be different to when the route was created.

GOTO

# You should always check the target waypoint before initiating a follow route.

► To follow the current route:



- 1. Press the GOTO default soft key. The Goto/Follow soft keys are displayed.
- 2. Press the FOLLOW ROUTE soft key.

Alternatively, to follow a route:

1. Place the cursor over a route leg until the letters RTE and the route soft keys are displayed then press FOLLOW ROUTE.



Your vessel's current position becomes the origin, and the target waypoint in the current route becomes the active target. The soft keys change as follows:



These options are described in the following sections.

➤ To follow the current route in reverse:



- 1. Press the ROUTE default soft key, followed by MORE. The route soft keys are displayed.
- 2. Press the REVERSE ROUTE soft key. The current route is reversed on the screen. Press **ENTER** or **CLEAR**.
- 3. Press the GOTO default soft key. The Goto/Follow soft keys are displayed.
- 4. Press the FOLLOW ROUTE soft key.



GOTO

The soft keys change as follows:



These options are described in the following sections.

Alternatively:

FOLLOW

ROUTE

1. Place the cursor over the route leg until the letters RTE and the route soft keys are displayed. Press REVERSE ROUTE then FOLLOW ROUTE.

Your vessel's current position becomes the origin, and the target waypoint in the current route becomes the active target.







#### **Target Point Arrival**

The arrival alarm is used to alert you when the vessel is approaching the target point. The arrival alarm is defined as a circle (not visible on the screen) around the target. You can specify radius of the arrival alarm (see *Section 6.3*).

The alarm is triggered when either of the following conditions is met:

- The distance to the target point is less than that specified for the arrival alarm.
- Your vessel reaches the closest point of approach to the target (defined by a line passing through the waypoint and perpendicular to the route leg).
- To cancel the arrival alarm and go towards the next waypoint in the route, either press any key or wait for 10 seconds.

The target becomes the origin, the next waypoint becomes the target point, and the two are connected by a dotted line indicating the current leg. Any previous route leg is removed from the screen, but waypoints remain.

**Note:** When following a route using a SeaTalk autopilot, the autopilot will not turn to the new waypoint until it is accepted at the autopilot control unit.

### **Other Follow Route Options**

You can use the soft keys to follow a route from a selected waypoint (join a route), or if already following, you can advance to the next waypoint. You can also restart the cross track error, setting the current vessel position as the new origin.

In addition, you can move a selected waypoint as described in *Section 5.3*, or remove a waypoint from the route as described in *Section 5.4*.

#### **Joining a Route**

➤ To start tracking the current route at a selected waypoint:



1. Move the cursor over the required waypoint until the letters WPT and the waypoint soft keys are displayed.



Downloaded from www.Manualslib.com manuals search engine

- Press the FOLLOW FROM HERE soft key. Your vessel follows the route, using the selected waypoint as the target point.
- 3. To return to the default display, move the cursor away from the waypoint or press **CLEAR** or **ENTER**.

5-32

### **Advancing to a Waypoint**

Once you are following a route, you can advance to the next waypoint, even if you have not reached the current target waypoint:



1. If necessary, press the GOTO default soft key to display the Goto/Follow soft keys.



2. Press the WAYPOINT ADVANCE soft key. The current leg of the route is abandoned and the next waypoint becomes the target. The display is updated to show the new route leg.

# **Restart Cross Track Error (XTE)**

While you are following a route, or going to a target point, you can restart the XTE. This sets the XTE to zero and moves the origin to the actual vessel position.

Restarting XTE is useful if you find yourself off track and want to go straight to your target, rather than get back onto the original track.

► To restart XTE:



- 1. Press the GOTO default soft key, the Follow/Goto soft keys are displayed.
- 2. Press the RESTART XTE soft key. The route origin moves to the current vessel position, thus the XTE becomes zero.

# **Going To an Individual Target Point**

Rather than following a route, you can go directly to a selected target point, this can be an existing waypoint (not in the current route), or the cursor position.

- ► To navigate directly to an existing waypoint:
  - 1. Use the trackpad to position the cursor over the required waypoint until the letters WPT and the waypoint soft keys are displayed.



Alternatively, you can select the waypoint from the waypoint list as described in *Section 5.3*.







2. Press the GOTO WAYPOINT soft key.

Navigation to the selected waypoint begins. The soft key STOP GOTO is displayed.

- 3. To return to the default soft key display, move the cursor away from the waypoint or press **ENTER** or **CLEAR**.
- ► To navigate directly to the cursor position:
  - 1. Use the trackpad to position the cursor as required.



 Press the GOTO default soft key, followed by GOTO CURSOR. If navigation is currently in progress you are warned "Already following route. Cancel route and goto cursor?".



To cancel the GOTO CURSOR operation, press NO. To continue with the GOTO CURSOR operation (and stop the current GOTO ROUTE), press YES.

The chartplotter places a temporary waypoint as the target and starts to navigate towards it. The waypoint is shown as a square with a circle and dot in the centre, and is connected to the vessel's starting position with a dashed line.

The soft key STOP GOTO is displayed.

3. To return to the default soft key display, move the cursor away from the waypoint or press **ENTER** or **CLEAR**.

# **Stop Follow or Stop Goto**

soft key.

To stop following the route or target point either:

	GOTO	
_		_
	STOP	
	_0010_	

Or:

- STOP FOLLOW
- 1. Move the cursor over any waypoint or leg in the current route, then press the STOP GOTO/FOLLOW soft key.

1. If necessary, press the GOTO soft key, then press the STOP GOTO/FOLLOW

The dotted line from your vessel to the target waypoint disappears. If you stopped a GOTO WAYPOINT or CURSOR, to remove the target point from the screen, move the cursor over the target point then press the CLEAR GOTO soft key.

If you subsequently use the FOLLOW ROUTE soft key to restart navigation, the route is followed from the point at which it was stopped. This is indicated by a square around the target waypoint. If you want to follow from another waypoint you can initiate the follow then use the WAYPOINT ADVANCE or FOLLOW FROM HERE soft key to step through the route.



# 5.6 Transferring Waypoints and Routes

#### **Displayed SeaTalk Waypoints**

In an integrated system, when a route is made current on any SeaTalk equipment it is sent to all SeaTalk instruments, including this chartplotter; this route will override any other current route. When GOTO waypoint or GOTO cursor is in operation it is considered a route.

The current route can be edited on any instrument with route edit capability.

**Note:** Transferred waypoints are not automatically saved by the chartplotter, however you can save the route locally, thus adding the waypoints to the local waypoint list.

#### **Managing Database Lists**

There are several methods of maintaining database lists. The method you choose will depend on the links available (SeaTalk orNMEA), and whether you want to transfer individual waypoints or the complete waypoint and route list:

- You can save the complete Waypoint and Route Lists to a user cartridge in the chart card slot.
- You can load new Waypoint and Route Lists from a user cartridge in the chart card slot.
- If waypoints are transmitted by other equipment on SeaTalk or NMEA, you can receive them on the chartplotter.
   When RECEIVE WPTS FROM ST/NMEA is selected, any waypoints sent on SeaTalk or NMEA are transferred and appended, one-by-one, to the waypoint list; routes sent on NMEA are appended to the route list.
   You can use this function to add waypoints from a PC connected via NMEA.
- You can send the waypoint and route lists from the chartplotter to other instruments via NMEA using the SEND WPT LIST function.
   Sending the waypoint list does not affect current routes.
   The NMEA link could be to a PC.

#### **CAUTION:**

The function LOAD USER CARD replaces the existing waypoint and route lists with the transferred lists.

► To save waypoints to, or load waypoints from a user cartridge:

#### CAUTION:

Loading waypoints from a user cartridge overwrites any existing waypoint and route lists.

- 1. Insert a C-MAP User Card into the lower of the two cartridge slots.
- 1. Press **MARKS** followed by the LOAD/SAVE USER CARD soft key.
- 2. The User Card Menu and associated soft keys are displayed.
- 3. Press the SAVE WPT/RTE DATA TO CARD or LOAD WPT/RTE DATA FROM CARD soft key; an appropriate warning and Yes/No soft keys are displayed.





- 4. Press Yes to continue or No to abandon the operation and return to the previous screen.
- 5. If the operation is successful, confirmation of the number of Routes and Waypoints saved/loaded is displayed.



If the operation fails, the Save Failed message is displayed.

MARKS



WAYPOINT

MARKS

WAYPOIN

L TSI

WAYPOIN TRANSFE

- 1. Display the waypoint list as previously described, then press the WAY-POINT TRANSFER soft key.
- 2. Press the soft key SEND WPT LIST ON NMEA. The soft key changes to STOP SENDING WAYPOINTS. The waypoint and route lists are transmitted from the chartplotter to other instruments on NMEA.

# 5.7 Using Tracks

The Track function is used to mark on-screen the trail that your vessel has followed, as if it had left a visible fixed wake.

While the track is switched on it is recorded in the display unit's memory. You specify the interval at which track points are made and a line is drawn onscreen between each point. Up to 4500 track points can be saved in total, in up to 5 track files (each a maximum of 750 points). The current track remains onscreen, even following a power off/on, until you clear the track.

Breaks in the track will be caused when any of the following occur for longer than the specified track interval: the track is switched off then on; the position fix is lost; the display unit is switched off.

To enable you to follow this track on your return voyage, the *SmartRoute* function converts the track (or the last segment of a track with breaks) into a route which is automatically reversed, see *SmartRoute* on *page 5-42*.

A track can be saved and retrieved for display at a later date. You can only display one track at a time; you must clear a current track from the screen if you want to display a saved track.

This section describes:

- Setting up a track, including how to specify the interval.
- Clearing the current track.
- Managing tracks, using the track list, including Saving, Naming, Erasing and Showing a track.
- Making a Track into a Route
- ► To access the track controls:
  - 1. From the chart display, press the **MENU** key to display the chart set up soft keys.



2. Press the TRACK SETUP soft key to display the Track soft keys:



The following instructions assume you have the track soft keys displayed.

# **Setting Up a Track**

You use the track soft keys to switch the track on and to specify the interval, as time or distance, at which track points are saved. The time interval between track points can be set to 1s, 5s, 10s, 30s, 1min, 3min, 5min, 10min or 30minutes. The distance spacing between track points can be set to 0.1nm, 0.5nm or 1.0nm. The interval default is a distance of 0.1nm. The maximum track length is 750 points. When the track has reached this length, the first points are overwritten. The track is saved until you switch it off. When the unit is powered off, the current track (thus far) is retained in memory.

Setting a short time interval between track points is best suited to navigation within a close or complex environment, e.g. an estuary or marina whereas, in contrast, a greater distance interval is best suited to a long haul voyage.

Refer to the setting guide shown in *Figure 5-9* to determine the best setting for your planned voyage; this is particularly important if you wish to use *SmartRoute* to convert your track to a route.





You can change the setting at any time. The setting applies only to the current track and is not saved as a stored track.

- ► To set up a track:
  - 1. Press the MORE soft key to access the TRACK INTERVAL soft keys. Press the appropriate soft key to set either a time interval or a distance interval; press the UP arrow to increase the interval, the DOWN arrow to decrease the interval.

Setting Up a Track

Press **ENTER** to return to the track soft keys.





SAVE TRACI 2. Press the TRACK OFF ON soft key to toggle tracks on.

Your vessels trail will be displayed on-screen, with a line joining the points at the selected interval.

# **Clearing the Current Track**

You can clear the current track from the screen. When you select CLEAR TRACK, if the current track has not been saved, you have the option of saving it.

- ► To clear the current track:
- CLEAR<br/>TRACK1. Press2. If the table
  - 1. Press the CLEAR TRACK soft key.
  - If the track has not been saved the SAVE TRACK soft keys are displayed. To clear the track without saving it in the Track List, press NO. To save the track in the list, press YES. The Name track soft keys are displayed and you should continue as described in the following section, Saving and Naming a Track.

Press **CLEAR** to abort the Clear Track operation.

The current track is cleared from the screen and the default soft keys are displayed.

# **Managing Tracks**

Although it is easy to set up a track, and this track is retained even if you switch off your display, you can store a number of different tracks so that you can review them at a later date. This section explains how to perform the following tasks:

- Save and Name a track.
- Name, Erase and Show an existing track.

#### **Saving and Naming a Track**

You can save up to 5 named tracks in the Track List. These tracks can be redisplayed at a later date.

► To save and name the current track:



- 1. Press the MORE soft key followed by the TRACK LIST soft key. The track list pop-up and associated soft keys are displayed.
- 2. The next available entry on the track list is highlighted. (If required, you can use the trackpad to select another position in the list; this can be a blank slot, or an existing track that you no longer require).

SHOW TRACK



- SAVE TRACK
- 3. Press SAVE TRACK. The name track soft keys are displayed.



If you do not wish to name or rename the track, press the NO soft key (or CLEAR) to clear the list. The track is saved and is listed as Track Not Named.

If you wish to name the track press the YES soft key. Use the trackpad to move the cursor right or left to the character you wish to edit. Then use the top or bottom of the trackpadto increase or decrease the letter or number. You can use a Navigator Keypad (see *Using the ST60 or ST80 Navigator Keypad* on *page 5-15*) to name the track.

5. Press **ENTER** to finish and clear the Track List, then to return to the default soft key display, press **ENTER** again or **CLEAR**.

#### Naming, Erasing and Showing a Track

➤ To name an existing track, erase a track or show a track, you select the track from the track list, then press the appropriate soft key as follows:



1. Press the TRACK LIST soft key. The Track List is displayed. The selection bar indicates the selected track.

Select the required track then press the appropriate soft key.



2. If you NAME a track, use the trackpad to move the cursor right or left to the character you wish to edit. Then use the top or bottom of the trackpad to edit the letter or number. Press **ENTER** finish the operation or **CLEAR** to cancel the name, then **ENTER** to remove the track list.



- If you ERASE a track you are prompted to confirm.
   Press NO to cancel the operation, then ENTER to remove the track list.
   Press YES to erase the track from the list, then ENTER to remove the track list.
- 4. If you SHOW a track, and you have a current track on screen, you are prompted to save the track. Proceed as previously described in Clearing the Current Track.

Alternatively, press the NO soft key to cancel the SHOW TRACK operation. The track list is removed and the selected track is displayed.

5. Press **ENTER** or **CLEAR** to return to the default display.

#### SmartRoute

SmartRoute enables the current track, or the last segment of a track with breaks, to be converted to a route (the track could have been retrieved from the track list). SmartRoute places a waypoint at the last track point, then considers each point in turn and determines the closest route through the recorded track. The number of waypoints created is minimized, whilst maintaining optimum correlation to the recorded track. On completion, the maximum deviation of the route from the recorded track is displayed.

► To convert the current track into a route:

#### 1. Select MAKE INTO ROUTE and press ENTER.

The current track is converted to a new route and becomes the current route, with the most recently placed track point as the start of the route, i.e. the track is reversed.

If there is an unsaved current route on screen, the option to save the route is given, see *Section 5.4, Working with Routes*.

2. Check the calculated route and, in particular, that the route deviation from the original, given in the warning box, is within navigable limits.

#### CAUTION:

Before following the route, ensure that it is safe for navigation, noting that it may deviate from your actual path travelled.

# Chapter 6: Further Chart Operations (SL72RC PLUS only)

# 6.1 Introduction

This chapter explains how to use the additional functions that are provided on the SL72RC PLUS combined radar/chartplotter.

It covers the following topics:

- Measuring distances and bearings on the chart, using the VRM/EBL key
- Setting alarms and timers
- Man Overboard (MOB)
- Cursor Echo
- GPS Setup
- Data Log Mode

In order to use some of these functions, you may need the following additional data from equipment connected to your system via a SeaTalk or NMEA link:

Data **Example source** Integrated functions available Compass\* - Head Up or Course Up heading modes Heading COG GPS - MOB (if speed data also available) Radar data Radar system - Radar data, either full-screen or in a half-screen window Position GPS system - Waypoints Position, COG, SOG and time data in Data Box and Nav Window - MOBy - Data Log Other data Transducers - Data Box and Nav Window data displays, including speed, depth, wind, temperature

Table 6-1:Function of External Data

\*If heading data is available via both NMEA and SeaTalk, NMEA data takes priority. For all other data, SeaTalk data takes priority (see *Section 6.3*).

# 6.2 Measuring Distances Using the VRM/EBL Key

You can obtain an accurate measurement of the distance and bearing between two points by using the **VRM/EBL** key.

➤ To place a ruler line and Ruler data box:



- 1. Position the cursor on the starting point from which you wish to measure.
- 2. Press VRM/EBL.

A Ruler data box is displayed showing the bearing and distance from the starting point to the cursor position. The character A appears at the cursor location.

- 3. Use the trackpad to move the cursor to the measurement end point. A line connects the cursor to the starting point, and the Ruler data box is updated to show the bearing and length of the line as shown in *Figure 6-1*.
- 4. Press ENTER to fix the end point of the ruler line, and return to normal cursor control. The letter B marks the location of the end point on the chart.



Measuring Distance Using a VRM

- ➤ To re-position one end of the ruler line:
  - 1. Move the cursor over the ruler line towards the end that you want to reposition, until the letters  $A \rightarrow B$  are displayed.
  - 2. Press **ENTER** to take cursor control of the ruler. The ruler end moves to the cursor which changes to a four-headed arrow.
  - 3. Move the cursor to the required position. The ruler data box is updated.
  - 4. Press **ENTER** again to set the position and return to normal cursor control. Alternatively, press **CLEAR** to reset the ruler to the previous position.
- To clear the ruler line and ruler data box either:

Move the cursor over the ruler line, until the letters  $A \rightarrow B$  are displayed, then press **CLEAR**.

or:



VRM/EBL

Press **VRM/EBL**, the ruler soft keys are displayed. Press **RULER OFF ON** to toggle the ruler line and data box off.

► To clear the ruler data box:

Press **VRM/EBL**, the ruler soft keys are displayed. Press **RULER DATABOX OFF** ON to toggle the ruler data box off.

- ► To move the Ruler data box, using the context-sensitive cursor:
  - 1. Move the cursor over the box until the letters BOX are displayed, and press **ENTER** to take cursor control of the box.
  - 2. Use the trackpad to move the box to its new location, and press **ENTER** to drop it and return to normal cursor operation.





# 6.3 Alarms and Timers

### **Alarm Reporting**



The chartplotter reports the following alarms, that are set using the **ALARMS** key:

Alarm	Indicates:
Arrival	Your vessel has arrived at the active waypoint: it has either reached the arrival circle (the radius of which is specified) or, has reached its closest point of approach (defined by a line passing through the waypoint and perpendicular to the route leg).
Off Track	Your vessel has exceeded the specified distance (maximum cross track error) from the active route leg.
Anchor	Your vessel has drifted from its anchor position (set when the alarm was turned on) by more than the specified distance.
Countdown	The countdown timer has reached zero.
Alarm Clock	The time matches the specified alarm time.
The alarms are menu, accessed	switched on or off, and the limits set, using the Alarms Set Up I from the <b>ALARMS</b> key.

When an alarm is triggered, the alarm buzzer sounds and a pop-up window describing the alarm is displayed.

To silence the alarm and clear the message, press any key. If the alarm was generated by the chartplotter, the appropriate action is taken. For example, following an arrival alarm, the next route leg is activated. If an anchor alarm is silenced, but the alarm condition perstists, the alarm is repeated every 30 seconds.

#### **External Alarms**

All SeaTalk system alarms (except autopilot alarms) are received and displayed on the chartplotter. You can silence these alarms by pressing any key. No other action is taken by the chartplotter except to silence the alarm.

Alarms and Timers

# **Setting Alarms and Timers**

➤ To set up an alarm or timer:



- 1. Press the **ALARMS** key. The Alarms Set Up menu is displayed, showing the current settings (see *Figure 6-2*).
- 2. Use the trackpad to move the selection bar up or down the options. As each line is highlighted, the soft key labels are updated to show the current settings and controls.

ALARMS	SET UP
ARRIVAL ALARM	0.01nm
OFF TRACK ALARM	ON
ANCHOR ALARM	OFF
COUNTDOWN TIMER	00:33:00
ALARM CLOCK	OFF
SELECT	ARRIVAL RADIUS

Figure 6-2: Alarms Set Up List

3. Use the up or down soft keys to change the alarm setting. For example, for the arrival alarm you can adjust the radius from the waypoint at which the arrival alarm will be triggered.

The alarm distances can be set in the range 0.01 to 9.99 nm, in steps of 0.01nm. The timer is set in hours, minutes and seconds, and the alarm clock in hours and minutes.



4. If required, press the ALARM OFF ON soft key to toggle the alarm on or off. If you turn an alarm off, its value is retained and will be used when you turn the alarm on again.

**Note:** You can turn all the alarms and timers on and off, except for the Arrival Alarm which is always on.

5. Press **ENTER** to save the changes and clear the list.

6-5

# 6.4 Man Overboard (MOB)

If you lose a person or object overboard, and need to return to the location, you should use the Man Overboard (MOB) function.

You can select the type of data used for the MOB position using the set up menus (see *Section 7.3*).

**Note:** To obtain MOB position, you need either of the following:

- Position data from a GPS or equivalent device
- Heading and speed data, so that the position can be calculated by dead reckoning

➤ To initiate the MOB procedure, press and hold the **MARKS** key for two seconds. The system then performs the following tasks automatically:

- Redraws the chart at 1/2 nm (even if cartography is not available but plotter mode is on).
- Marks the current position with a MOB symbol which replaces any current active waypoint and route.
- Displays the MOB data box, showing the bearing and distance from your vessel to the MOB waypoint position, and the elapsed time since the MOB was initiated (*Figure 6-3*).
- Displays the position data box, showing your vessel's position.
- As your vessel moves from the MOB position, a dotted line is displayed connecting the MOB symbol and the vessel's current position.
- Sounds a 4-second alarm pattern every 30 seconds.
- Sends an MOB message (including bearing and distance) to other units in the system, via the SeaTalk connection.



MARKS



To cancel the MOB, press and hold the MARKS key for 2 seconds. The chart is re-drawn at its previous scale, and the MOB symbol and data box are removed.

**Note:** The MOB procedure can also be initiated or cancelled if the appropriate SeaTalk message is received by the display unit.

# 6.5 Cursor Echo

In a combined radar/chart display you can set the display to enable cursor echo. Cursor echo (accessed from System Set Up, described in *Section 7.3*) enables you to display a radar cursor on the chart picture, or a chart cursor on the radar picture.

The following options can be toggled ON or OFF:

- **Radar Cursor In:** displays the cursor from another radar on the chart display or chart window (default OFF).
- **Chart Cursor In:** displays the cursor from another or chartplotter on the radar display or radar window (default OFF).
- SeaTalk Cursor Out: enables the output, onto SeaTalk, of the display's own cursor (default OFF).
- **Cursor Echo Local:** echoes the cursor position between open windows on the same display (default ON).

If you set the options to OFF, no cursor echo information is displayed.

When the appropriate option is switched on, the display shows its own cursor, plus the cursor of the other display with appropriate cursor text (RDR or CHT) to indicate its origin. This means that you could move the cursor over a target on the radar display, and check the identity of the target by looking at the radar cursor position on the chartplotter.

# 6.6 GPS Setup

GPS set up page provides you with information and the status of the tracked navigation satellites for a SeaTalk GPS. It also enables you to SET UP a SeaTalk Differential GPS, by manually retuning it to a different differential beacon.

The GPS Navigation Status pop-up window (shown in *Figure 6-4*) provides, for each tracked satellite, the satellite number, a graphical signal strength bar and its current usage status. HDOP and satellite Fix Status are also displayed. Data for up to 12 satellites are shown.



Figure 6-4: Navigation Status Window

Positional accuracy is dependent upon certain parameters; in particular for GPS, the azimuth and elevation angles are used in a triangulation process to calculate position. HDOP (Horizontal Dilution Of Position) is a measure of this accuracy; a higher figure signifies greater error. In ideal circumstances, the figure should be in the region of 1.0. The Fix Status can indicate:

- FIX, where a satellite fix has been acquired.
- D-FIX, where a differential beacon fix has been acquired.
- SD-FIX, where a satellite differential fix has been acquired.
- NO FIX, where no fix can be acquired.



► To select GPS Set Up:

Press **MENU**, then press the GPS SETUP... soft key. The Navigation Status pop-up window shown in *Figure 6-4* is displayed.

#### **Restart GPS**

This soft key enables re-acquisition of a GPS position fix.

Note: Under normal circumstances RESTART GPS is not required.

#### **D-GPS Set Up**

The D-GPS SET UP function provides the ability to set up an external Differential GPS, either automatically (default) or by manually retuning it to a different differential beacon.

In AUTO mode, the D-GPS is set to automatic and beacon selection is made automatically by the beacon receiver. The beacon frequency and bit rate received from the beacon receiver are displayed. The soft keys are disabled and grayed out.

In MANual mode, you can select the beacon frequency and bit rate that are sent to the beacon receiver.

When you select D-GPS SETUP a pop-up window, providing the following parameters, is displayed with associated soft keys:

- Beacon ID This shows the Beacon ID of the beacon transmitter. If no beacon has been found this item states NOT LOCKED.
- Beacon Frequency Both the menu item and associated soft keys show the currently used differential beacon's frequency in kHz. The frequency range available is 283.5kHz to 325.0kHz.
- Bit Rate Both the menu item and associated soft keys show the currently used differential beacon's bit rate in bps. The rates available are 50bps, 100bps and 200bps.
- Signal Strength and Signal to Noise Ratio These items indicate the
  received signal strength and Signal to Noise Ratio (SNR) in dB, received
  from the beacon receiver. If the display unit is using RTCM data received
  via NMEA, this information is not available and the item shows dashes,
  one per character. The received Signal Strength and SNR are interrelated.
  SNR provides a measure of the quality of the received signal and is dependent upon signal strength.
- Differential Age This indicates the time elapsed since the last differential beacon correction update.
- ► To tune a differential SeaTalk GPS to another beacon:
  - 1. Press D-GPS SETUP, the Differential GPS Setup pop-up is displayed.



2. Press MODE AUTO MAN to toggle between AUTO and MAN modes; the selected mode is highlighted is indicated in the pop-up window.
**Note:** If the display unit is receiving RTCM data via NMEA, repeating a differential fix from another unit, the MODE soft key is set to AUTO and is grayed out. If receiving RTCM data, the setting must be performed manually on the external DGPS receiver.

3. To set a new beacon manually, press BEACON SELECT, use the soft keys to set the required beacon frequency and bit rate.

Press **ENTER** to return to the Differential GPS Setup pop-up window. The status of the selected beacon is displayed in the pop-up.

Press **ENTER** to return to the Navigation Status window, then **ENTER** to return to the **MENU** soft keys.

### 6.7 Data Log Mode

You can set the chartplotter to log course data every thirty minutes. Up to 48 log entries are held, when 48 entries have been made, the chartplotter will start overwriting the first entries.

You start the log using soft keys provided in Data Log Mode. When you select Data Log Mode the log is displayed full-screen. If the screen is full, you use the trackpad to scroll the list and view further log entries. Each line in the log shows:

- Time of log entry
- Position at time of log entry
- Course Made Good (CMG) since last log entry
- Distance Made Good (DMG) since last log entry

Once you have enabled the data log, data is continually logged, but you must set the display to Data Log Mode to view it. You use the **DISPLAY** key to change the full-screen mode.

You can stop the log at any time and you can clear the log from memory.

If the chartplotter is switched off while the log is running, a dashed line will be displayed before the first new entry since switching the chartplotter on again.

- ► To activate Data Log Mode:
- 1. Press **DISPLAY**, the DISPLAY pop-up is shown.
- 2. Press **DISPLAY** again, until LOG is selected, then press **ENTER**.
- To start recording log entries, press the START LOG soft key. As shown in *Figure 6-5*, the chartplotter records the time and vessels position. Every thirty minutes the time, new position, distance made good and course made good are recorded.

START LOG

The START LOG soft key changes to STOP LOG.

Data Log Mode

TIME	POSITION	CHG	DHG
15:30	50°21/890N	346°м	6.86км
16:00	50°18/010N	180°m	7.23км
16:30	50°21/850N	012°m	7.23км
17:00	50°18/500N	206° M	6.67км
17:30	50°20'990N	043°m	5.74км
18:00	50°19/660N	245°m	5.00км
18:30	50°19/730N	093°m	4.63км
19:00	50°20/930N	302°m	5.00км
19:30	001°21:750W 50°18:550N 001°18:650W	145°m	5.74км
STOP LOG CLEAR LOG			
L.			D4284

Figure 6-5: Data Log Window

➤ To stop recording log entries:

Press the STOP LOG soft key.



➤ To clear the log entries:

CLEAR LOG

Press the CLEAR LOG soft key, you are prompted "Are You Sure". To cancel the CLEAR LOG operation press the NO soft key. To continue press the YES soft key, all log entries are deleted, but the data log remains active.



STOP LOG

► To return to the chart display:

Press **DISPLAY** to select the chart mode, then press **ENTER**. The log continues until you return to the data log mode and press STOP LOG. Data Log Mode



# **Chapter 7: Setting Up the System Defaults**

## 7.1 Introduction

Once you have installed your display unit and are familiar with its basic operation (described in *Chapter 1* and *Chapter 2*), you need to set it up so that it obtains the correct information from the equipment you have connected it to, operates according to your requirements, and displays information according to your preferences.



This is achieved using the soft key controls that are displayed when you press the **MENU** key.

In most cases, you will only need to use the **MENU** key options when you first set up your system. However, you may decide to change the way you have customized some aspects, such as the screen and help setting, as you become more familiar with your system.

Once you have set the values, they remain as the default settings until you reset them; they are retained even if you power off your display.

This chapter covers the following topics:

- Changing the default set up parameters
- System parameter functions and default settings
- Radar-specific parameter functions and default settings
- Advanced Radar functions
- Chart specific parameter functions and default settings (SL72RC PLUS only)

You should check the functions of the parameters, and decide on the new settings, before making the changes.

**Note:** *The* SYSTEM SET UP *menu option from the chartplotter display is the same as that accessed from the radar display* SYSTEM SET UP *menu.* 

### 7.2 Changing the Set Up Parameters

The set up parameters are divided into four sections:

- **System**, to control the aspects of the system that are not specific to the radar or chart.
- **Radar**, includes bearing alignment, display preferences and the timed transmission option.
- Advanced, to control specialist radar settings such as display timing, STC preset and tune preset (see *Section 7.5* for instructions on how to access these functions).
- **Chart**, to control the chartplotter display (SL72RC PLUS only), including waypoint information, vectors and radar/chart synchronization.

Note: The GPS and Track Set Up menus are described in Chapter 6.

This section provides instructions for displaying and changing the default values. The following sections list the parameters and their possible settings, and describe the function of each parameter in turn.

- ➤ To set the default parameters:
  - 1. Press the **MENU** key to display the set up soft keys the options available depend on the selected operating mode.

#### Radar



#### Chart (SL72RC PLUS only)



2. Press the soft key for the set up you require.

The requested set up menu is displayed, listing the parameters and their current settings.

3. Use the trackpad to move the selection bar up and down the list. An arrow is displayed at the top or bottom right-hand corner if you can scroll the list to display further parameters.

As each line is highlighted, the soft keys are updated to show the settings available.

• For parameters that have a numeric value, or more than four possible settings, a scroll list is displayed above two of the soft keys.

MENU



- Some parameters are controlled by a slider that is displayed above two of the soft keys.
- For some parameters, a soft key provides access to a sub-menu of further options.
- 4. Press the soft key corresponding to the desired setting or, for scroll lists, use the soft keys to scroll forwards or backwards through the list until the required setting is displayed. This setting is retained when you move the selection bar on to the next parameter in the menu list.

For sliders, press the appropriate soft key repeatedly to increase or decrease the slider value in individual steps, or press and hold the key to change the setting quickly.

- 5. Once you have set all the required values, press **ENTER** to clear the menu and return to the set up soft keys.
- 6. Press **ENTER, MENU** or **CLEAR** to clear the soft keys and return to the default display.

You can return all the settings to their original factory settings, if required, by performing a factory reset as described in *Chapter 9*.

## 7.3 System Set Up Parameters

The following table lists the System menus and their options, shows the factory default setting, and provides a space for you to make a note of your new default setting. Each parameter is described in the following subsections.

Menu Options		Factory Default	New Default
DATA BOXES			
POSITION	OFF, LAT/LONG, TDs	OFF	
SPEED	OFF or ON	OFF	
DEPTH	OFF or ON	OFF	
COG	OFF or ON	OFF	
SOG	OFF or ON	OFF	
TIME	OFF or ON	OFF	
DATE	OFF or ON	OFF	
WIND	OFF, APP, TRUE or BOTH	OFF	
WAYPOINT	OFF, LAT/LON, or RNG/BRG/TTG	OFF	
	OFF or ON	OFF	
CROSS TRACK ERROR	OFF or ON	OFF	
HEADING	OFF or ON	OFF	
LOG/TRIP	OFF or ON	OFF	
PILOT	OFF, WIND, WPT or BOTH	OFF	
VMG	OFF or ON	OFF	
TEMPERATURE	OFF or ON	OFF	
TIDE SET/DRIFT			
BEARING MODE	MAGNETIC, TRUE	TRUE	
CURSOR REFERENCE	MAG/TRUE, RELATIVE	RELATIVE	
CURSOR READOUT	OFF,LAT/LONG,RNG/ BRG,BOTH	RNG/BRG	
DAY/NIGHT	DAY, NIGHT	DAY	
HELP	OFF/ON	ON	
SOFT KEYS	OFF/ON	ON	
KEY BEEP	OFF/ON	ON	
MOB DATA	DR, POSITION	DR	
MENU TIMEOUT PERIOD	NO TIMEOUT, 10, 20, 30 SECONDS	NO TIMEOUT	
DISTANCE UNITS	NAUTICAL MILES, STATUTE MILES, KILOMETERS, KILOYARDS	NAUTICAL MILES	
SPEED UNITS	KNOTS, MILES PER HOUR, KILOMETERS PER HOUR	KNOTS	
DEPTH UNITS	METERS, FEET, FATHOMS	FEET	

Table 7-1:System Set Up Parameters

Menu	Options	Factory Default	New Default
TEMPERATURE UNITS	CENTIGRADE, FAHRENHEIT	FAHRENHEIT	
VARIATION SOURCE	AUTO, MANUAL	AUTO	
BRIDGE NMEA HEADING	OFF or ON	ON	
NMEA OUT SET UP			
APB	OFF or ON	ON	
BWC	OFF or ON	ON	
BWR	OFF or ON	ON	
DBT,	OFF or ON	ON	
DPT	OFF or ON	ON	
MTW	OFF or ON	ON	
RMB	OFF or ON	ON	
RSD	OFF or ON	ON	
RTE	OFF or ON	ON	
TTM	OFF or ON	ON	
VHW	OFF or ON	ON	
VIW	OFF or ON	ON	
WPI	OFF or ON	ON	
GGA	OFF or ON	ON	
GU	OFF or ON		
RMA	OFF or ON		
PMC	OFF or ON		
VTG	OFF or ON		
	OFF or ON		
ZDA	OFF OF ON	ON	
DATA SELECTION - SL72	SEATALK/NMEA IN, NMEA	SEATALK/NMEA	
PLUS only	IN/OUT	IN	
CURSOR ECHO			
RADAR CURSOR IN	OFF or ON	OFF	
(SL72RC PLUS)			
CHART CURSOR IN	OFF or ON	OFF	
S/T CURSOR OUT	OFF or ON	OFF	
CURSOR ECHO LOCAL	OFF or ON	ON	
(SL72RC PLUS)			
DATE FORMAT	DD/MM/YY, MM/DD/YY	MM/DD/YY	
TIME FORMAT	12 HOUR, 24 HOUR	12 HOUR	
TIME OFFSET	UTC, or local offset value: Plus or minus up to 13 hours, in whole hours	UTC	
GPS SOG/COG FILTER - SL72RC PLUS only	HIGH, MEDIUM, LOW	MEDIUM	
COMPASS SET UP -		-	
SL72RC PLUS only	Press soft kev to start the		
LINEARISE COMPASS	linearisation procedure and		
	to align the heading		
ALIGN HEADING	2g a		

Table 7-1:System Set Up Parameters

System Set Up Parameters

Menu	Options	Factory Default	New Default
LANGUAGE	ENGLISH (UK), ENGLISH (US), DANISH, FRENCH, GERMAN, DUTCH, ITALIAN, ICELANDIC, NORWEGIAN, PORTUGUESE, SPANISH, SWEDISH, FINNISH	ENGLISH (US)	
SIMULATOR	OFF, DATA, RADAR, BOTH	OFF	

Table 7-1:System Set Up Parameters

#### **Data Boxes**

Press the SELECT BOXES soft key to display the data box sub-menu. This allows you to select up to 6 data boxes that you can display on the fishfinder.

**Note:** *1. A fixed set of 16 of these data items are available for display in the Nav Data half-screen window (see Chapter 2).* 

2. In addition to these grouped data boxes, boxes for the cursor readout, VRM/ EBL data, waypoint data, MOB data and simulator status are displayed when selected or when the appropriate function is active.

**3.***Radar data is only repeated if the display is connected to an* hsb<sup>2</sup> series radar master display.

Data boxes provide regularly used data in a compact form so that most of the picture can still be seen. The ones you select here can be turned on and off as a group during normal operation, and you can also move them around the screen individually using the context-sensitive cursor (see *Context-Sensitive Cursor Control* on *page 1-17.*).

#### **Bearing Mode**

The mode (magnetic or true) of all the bearing and heading data displayed. This is indicated in the radar status bar after the heading value.

#### **Cursor Reference**

The mode of the bearing data displayed for the cursor readout. The bearing information can be displayed in either of two forms:

- Relative: The bearing relative to your vessel's heading.
- Mag/True: The actual bearing in either degrees magnetic or degrees true. This option is only available in Radar mode if your system includes a radar display and you have heading data from a compass.

If you choose this mode, the selection you made for the previous parameter (Bearing Mode), °M or °T, is displayed in the cursor (Rng/Brg) data boxes. The current units are shown for the heading value in the status bar at the top of the screen.

### **Cursor Readout**

This option controls whether the cursor data is shown in latitude and longitude or in range and bearing. Alternatively, you can show both types of readout, in separate boxes, or turn the cursor data box off.

You can also turn the cursor readout box(es) on and off during normal operation, via the SCREEN default soft key (see *Switching the Cursor Data Box On and Off* on *page 2-13.*)

### Day/Night

This option allows you to change the display between day and night modes. If you select NIGHT mode, a different palette, more suited to night time viewing is used.

#### Help

When Help is set to ON, a prompt appears when selecting a soft key or menu choice, and when using the context-sensitive cursor. The help message is cleared when an action is selected.

### Soft Keys

When the Soft Keys option is set to ON, the default soft keys are displayed if no other operation is in progress.

When the Soft Keys option is set to OFF, the default soft keys are only displayed when a soft key is pressed, and they disappear if no operation is performed for 10 seconds.

### **Key Beep**

This option controls whether or not the keys make a noise when you press them.

#### **MOB** Data

This option controls whether MOB data is based on position data, or on dead reckoning (DR). Dead reckoning normally provides a better indication of the course to an object in the water, on the assumption that your vessel and the object are both subject to the same tide and wind effects.

### **Menu Timeout Period**

With no timeout set, menus and soft key labels remain displayed until you clear them by pressing **ENTER**, **CLEAR** or the appropriate dedicated key.

If you set a value here, the menus and soft key labels will be cleared if a key has not been pressed for the specified number of seconds.

This setting does not affect the *default* soft key labels, which are controlled by the Soft Keys option (see above).

### Units

You can set the units for speed, depth and temperature. The units you set will be used to display all data, including information received from other instruments on the system. However, the distance units do not affect the instrumented range of the radar, which is always in nautical miles.

#### **Variation Source**

The variation value is the difference between True and Magnetic direction data for heading or bearing values. The Variation Source option provides soft keys for selecting Auto or Manual variation mode, displays the current variation value for each and highlights the currently selected mode.

#### Auto Mode

If you select Auto mode, the display obtains the value of variation automatically, normally from received data. The variation value that is used depends on the data available, and is selected in the following order of priority:

- 1. Variation value from the same source as the heading data:
  - If heading data is being taken from NMEA, then variation is also taken from NMEA
  - If heading is taken from SeaTalk, then SeaTalk variation is used
- 2. Variation value from a different source:
  - If heading data is being taken from NMEA, but no NMEA variation is available, then variation is taken from SeaTalk
  - If heading is taken from SeaTalk, but no SeaTalk variation is available, then variation is taken from NMEA
- 3. A calculated variation value, using position data, if no SeaTalk or NMEA value is available
- 4. The current manual variation value, if no SeaTalk or NMEA value and no position data is available

#### **Manual Mode**

If you select Manual mode, by pressing either of the MANUAL keys, you can specify the local variation value according to the area in which you are operating. Press the appropriate MANUAL key to adjust the variation up or down, to a maximum of 30° East or West.

This value is then transmitted to any other SeaTalk instruments on your system. It is retained if you turn the display off and on again.

In Manual mode, incoming NMEA variation is ignored. However, if the variation is changed on another SeaTalk instrument, the new value is used and the manual value that is displayed is updated.

**Note:** The Manual variation value defaults to 0°, so it is important to set up a value if variation is not available from an external source.

### **Bridge NMEA Heading**

The SL72 and SL72RC PLUS displays bridge NMEA input data to the SeaTalk bus (see *Section 8.8*). The Bridge NMEA Heading option can be used to prevent NMEA heading data being bridged onto the SeaTalk bus. For example, if you have a course computer connected on SeaTalk and NMEA, and an active compass connected on NMEA, SeaTalk data overrides NMEA data in the course computer. You should therefore switch OFF the Bridge NMEA Heading option to ensure the course computer receives the same NMEA heading input as the radar system.

#### **NMEA Out Set Up**

This option lets you switch off individual NMEA out sentences.

### **Data Selection - SL70 PLUS only**

The Data Selection option specifies how the SeaTalk connector on the rear of the SL72 PLUS radar display will be used. You can select either:

- SeaTalk data input and output (the default) or
- NMEA data output

Refer to Section 8.11 for connection details.

### **Cursor Echo**

You can set up an integrated system so that radar and chartplotter displays connected via SeaTalk can display each other's cursors.

Cursor echo functions so that you can display a chart cursor on the radar picture, or a radar cursor on the chart picture. When the appropriate options are switched on, each display shows its own cursor, plus the cursor of the other display with appropriate cursor text (RDR or CHT) to indicate its origin. This means that you could move the cursor over a target on the radar display, and check the identity of the target by looking at the radar cursor position on the chartplotter.

Press the CURSOR ECHO soft key to display the cursor transfer soft keys. The following options can be toggled ON or OFF:

- Radar Cursor In (SL72RC PLUS): displays the cursor from another radar on the chart display or chart window (default OFF).
- **Chart Cursor In:** displays the cursor from another or chartplotter on the radar display or radar window (default OFF).

**Note:** The remote display must have SeaTalk Cursor Out enabled. Raymarine recommend that in multi-display systems, you do **not** enable Cursor Out on more than two displays. If multiple displays have cursor out enabled, the cursors will not be displayed simultaneously, but will flash on/off.

- SeaTalk Cursor Out: enables the output, onto SeaTalk, of the display's own cursor (default OFF).
- **Cursor Echo Local (SL72RC PLUS):** echoes the cursor position between open windows on the same display (default ON).

If you set the options to OFF, no cursor echo information is displayed.

### **Date and Time Settings**

Set your preferred date format (DD/MM/YY or MM/DD/YY) and time format (12 or 24 hour). If you wish to display local time, use the soft keys to change from UTC to the required time offset. This can be up to plus or minus 13 hours, in hourly steps.

### GPS SOG/COG Filter - SL72RC PLUS only

The SOG/COG filter averages the velocity vectors to compensate for the oscillating motion of the vessel, giving a clearer indication of the vessel's course and speed. The filter does not affect the calculation of the GPS position.

The velocity vectors calculated from the GPS Signal give an instantaneous measure of speed and direction of the GPS antenna. The COG and SOG can therefore seem erratic under certain conditions. For example, when a vessel is moving slowly through rough seas, the antenna moves from side to side as well as in the direction of the vessel.

Slow moving vessels, or vessels sailing in rough seas will benefit from a high setting, whereas a power boat that can quickly change speed and direction will benefit from a low setting.

Select the SOG/COG filter setting as required. This can be set to HIGH, MEDIUM or LOW.

### Compass Set Up - SL72RC PLUS only

This option is used to calibrate a Raymarine heading sensor such as the Rate Gyro Compass. Controls are provided for Linearise Compass which detects and corrects for heading errors caused by metal objects, and Align Heading which matches the displayed heading to a known heading or transit.

Refer to the Handbook supplied with your heading sensor for more details.

#### Language

Select the language in which you wish information to be displayed. The selected language will be used for screen text, labels, menus and options, but will not affect the letters displayed by the context-sensitive cursor. The language setting also affects the display format for lat/long position information.

### Simulator

The simulator allows you to operate your display without data from the antenna and/or external data sources. The system set up simulator options have the following functions:

- Data provides simulated numerical data, and a waypoint display.
- **Radar** provides simulated radar picture, with example targets. The picture does not change if you change the range, although the range rings are adjusted (see *Chapter 3*).
- Both provides simulated data and radar picture.

When the simulator is switched on, a SIMULATOR data box is displayed during operation, showing the simulation selected.

### 7.4 Radar Set Up Parameters

The RADAR SET UP option allows you to set up the radar according to your system configuration and your personal preferences.

**Note:** Some parameters can only be changed if you are using the Master display (that is, the display to which the scanner is connected).

The following table lists the Radar Set Up parameters and their options, shows the factory default setting, and provides a space for you to make a note of your new default setting. Each parameter is described in the following subsections.

Parameter	Options	Factory Default	New Default
EBL DISPLAY	MAG/TRUE, RELATIVE	RELATIVE	
TIMED TRANSMIT	OFF, ON	OFF	
TRANSMIT PERIOD	10 scans, 20 scans, 30 scans	20 scans	
STANDBY PERIOD	3, 5, 10 or 15 mins	10 minutes	
DEFAULT MARK SYMBOL	<b>∞,⊠,</b> X,Ů	×	
MARK DISPLAY	OFF, ON	ON	
CLEAR MARKS	Press soft key to clear marks database	N/A	
CUSTOM SCALE	OFF, ON, SET RANGES	OFF	
BEARING ALIGNMENT	Slider value	0°	
ANTENNA SIZE	Not valid for SL72 & SL72RC PLUS	-	
SEND ON HSB	Not valid for SL72 & SL72RC PLUS	-	

#### Table 7-2: Radar Set Up Parameters

### **EBL Display**

The mode of the bearing data displayed for Electronic Bearing Lines (EBLs). The bearing information can be displayed in either of two forms:

- **Relative:** The bearing relative to your vessel's heading.
- **Mag/True:** The actual bearing in either degrees magnetic or degrees true. This option is only available if you are obtaining data from a compass.

If you choose this mode, the selection you made for Bearing Mode determines whether °M or °T is displayed in the EBL data boxes. The current units are shown for the heading value in the status bar at the top of the screen.

## **Timed Transmission Option**

The TIMED TRANSMIT parameter, together with the TX PERIOD and STANDBY PERIOD parameters, controls the radar's timed transmission power-saving mode.

When TIMED TRANSMIT is set to ON, the scanner performs the number of scans specified by TX PERIOD and then shuts down for the number of minutes specified by STANDBY PERIOD. While it is shut down, the scanner does not rotate, and the display is in stand-by.

Set the TIMED TX parameter to OFF for normal operation. In this case, the TX PERIOD and STANDBY PERIOD values are ignored.

Note: Timed Transmission is not available on a Repeater Display.

## **Marks Options**

You can select the mark symbol that will be used when you place a mark (see *Section 4.3*).

If you turn the MARK DISPLAY option OFF, any marks you have placed are hidden on the display, but retained in the marks database. You can turn the option on again to display them at any time.

To clear all stored marks from the marks database, press the CLEAR MARKS soft key, and the YES soft key to confirm the deletion.

## **Custom Scale**

You can set up your own range scale. When switched ON, this is used instead of the Pathfinder Plus Radar default range scale (see *Section 3.2*).

To set up a scale, press the SET RANGES soft key. The Custom Range Setup Menu is displayed, which allows you to change the maximum range for each range selection.

The following table lists the ranges, shows the factory default setting, and provides a space for you to make a note of your new setting.

Range	Default Setting (nm)	New Setting (nm)
1	0 1 2 5	
1	0.125	
2	0.25	
3	0.5	
4	0.75	
5	1.5	
6	3.0	
7	6.0	
8	12.0	
9	24.0	

Table 7-3: Radar Custom Range Scales

To change the range scale, highlight the required range and use the soft keys to change the value. Start at the top of the list and work down, since each value must be greater than the value for the previous range in the list. The following scale increments are available:

Range Scales (nm)	Scale Increments (nm)
0.125 to 0.5	0.125
0.5 to 3.0	0.25
3.0 to 6.0	0.5
6.0 to 24.0	2.0
24	4.0

Table 7-4:Radar Range Scale Increments

When you have finished setting up the new scale, press **ENTER** to return to the Radar Set Up Menu, and press the ON soft key to select your new scale.

### **Bearing Alignment**

The bearing alignment is normally set when you first install your system, and is described in *Radar System Checks and Adjustments* on *page 8-16*.

The bearing alignment corrects for display azimuth error. It can be set to a value in the range  $-180^{\circ}$  to  $+179.5^{\circ}$ , in increments of  $0.5^{\circ}$ .

#### **Antenna Size**

This option is not available on the SL72 and SL72RC PLUS systems.

### **Send on HSB**

This option is not available on the SL72 and SL72RC PLUS systems.

## 7.5 Advanced Settings

The ADVANCED SET UP option allows you to set up values for the following three parameters that affect the fine-tuning of the radar. Advanced settings are only available from the Master radar display (that is, the display connected to the scanner).

Parameters	Function	Slider Range
Display timing	Corrects for display range error	0m to 153m
STC preset	Equalizes target levels across display	0-preset maximum
Tune preset	Allows adjustment of the tuning range controlled by the TUNE control	0-255

Table 7-5: Advanced Radar Set Up Parameters

**Note:** Under normal circumstances you will not need to adjust these settings, as they are set automatically at the factory. **If these parameters are set incorrectly the performance of the radar will be adversely affected.** Access to the menu is therefore via a hidden key press.

- ► To change the settings:
  - 1. Press the **MENU** key to display the set up soft keys.
  - 2. Press and hold the blank soft key directly to the right of the RADAR SET UP soft key for 5 seconds. The Advanced Settings menu is then displayed.
  - 3. Use the trackpad to move the selection bar to the required option.
  - 4. Use the soft keys to increase or decrease the slider setting. As soon as you start to adjust the setting, the menu page is cleared so that you can see the effects of the adjustment on the radar picture, and the radar is set to 1/8nm range.
  - 5. Press **ENTER** to display the menu again.
  - 6. Press **CLEAR** to return to the Menu soft keys, and **CLEAR** again to return to normal operation.
- If required, you can recall the factory defaults for this page. To do so, move the selection bar to the SCANNER RESET option, press the ADVANCED SETTING RESET soft key, and press the YES soft key to confirm.

### **Display Timing**

If you extended the inter-unit cable, you should have set the display timing when you first installed your system, as described in *Radar System Checks* and Adjustments on page 8-16.

Under certain circumstances, it may be easier to adjust the display timing with MBS (Main Bang Suppression) off; press the MBS soft key to toggle the setting OFF. MBS is reset to ON automatically when you finish adjusting the display timing.

### **STC Preset**

The Sensitivity Time Control can be adjusted to equalise targets levels across the display. The factory setting should provide an even display, but if you find that targets are brighter or dimmer nearer the centre than at the edge of the display, you can adjust this slider until the required display is achieved.

**Note:** *Caution should be observed when adjusting this parameter as poor adjustment can adversely affect auto gain and sea controls.* 

### **Tune Preset**

The radar tuning is controlled either automatically or manually using the TUNE control (see *Tuning the Receiver* on *page 3-9*). However, this only controls a restricted range of tuning values. If the actual tuning peak falls outside this range, you will need to adjust the Tune Preset slider to move the controlled range over the tuning peak.

Press the INITIATE SET UP soft key to enable slider control, and adjust for maximum image intensity.

If required, you can press the RESTORE PREVIOUS soft key to reset the Tune Preset to the value before you pressed INITIATE SET UP.

### 7.6 Chart Set Up Parameters - SL72RC PLUS only

The CHART SET UP option allows you to set up the chartplotter according to your system configuration and your personal preferences.

The following table lists the Chart Set up parameters and their options, shows the factory default setting, and provides a space for you to make a note of your new default setting. Each parameter is described in the following subsections.

Parameter	Options	Factory Default	New Default
CUSTOMIZE CHART	See below for details		
PLOTTER MODE	OFF, ON	OFF	
CHART ORIENTATION	NORTH UP, COURSE UP, HEAD UP	NORTH UP	
OBJECT INFORMATION	OFF, ON	ON	
WAYPOINT SYMBOLS	OFF, ON	ON	
WAYPOINT NUMBERS	OFF, OFF	ON	
DEFAULT WAYPOINT SYMBOL	<b>⇔,⊠,X</b> ,Ů	×	
HEADING VECTOR	OFF, 3 MINS, 10 MINS, INFINITE	OFF	
COG VECTOR	OFF, 3 MINS, 10 MINS, INFINITE	OFF	
TIDE VECTOR	OFF, 10 MINS, 1 HOUR, INFINITE	OFF	
RADAR/CHART SYNCH	OFF, ON	OFF	
DATUM SELECTION	WGS 84, LOCAL	WGS 84	
POSITION OFFSET	OFF, ON	OFF	

Table 7-6: Chart Set Up Parameters

## **Customize Chart**

This provides a list of chart options, enabling you to specify how the chart features are displayed. Most options can be toggled between on, off and custom - custom passes on/off control to the SCREEN soft keys (see *Customizing the Screen Presentation Options* on *page 2-13*).

The following features can be set using Customize Chart, factory default settings are shown in **bold** type:

- chart text (on, off, custom)
- chart text size (small, **normal**, large)
- chart display (**detailed**, simple)
- chart boundaries (**on**, off, custom)
- spot soundings (on, off, **custom**)
- depth shading limit (set the limit)
- depth contours (**on**, off, custom)
- depth contour display (set the upper and lower limits)
- nav marks (on, off, custom)
- light sectors (on, off, **custom**)
- caution and routing data (on, off, custom)
- marine features (on, off, **custom**)
- land features (on, off, custom)
- icon display (simple, detailed, custom)

The factory default for CUSTOM options is ON.

#### **Plotter Mode**

Plotter Mode enables you to zoom into a smaller area, even when no chart data is available for that scale. This allows you use the chartplotter functions at large scales even when a chart card is not installed.

### **Chart Orientation**

The chart orientation is normally North Up, but can be changed to Course Up or Head Up if heading data is available. The orientation modes give the following displays:

- North Up: The chart is displayed with north upwards. As you change heading, the ship's heading marker moves. This is the default mode, and is the only mode available if there is no heading data.
- **Course Up:** The chart is stabilized and displayed with the currently selected course upwards. If you select a new course, the picture rotates to display the new course upwards.

The reference used for the Course Up depends on the information available. The first available in the following is used:

i. A locked heading over a SeaTalk connection

ii. The heading at the time Course Up was selected

To update the Course Up reference while Course Up is the current mode, re-select Course Up from the set up menu.

• **Head Up:** The chart is displayed with the vessel's current heading upwards. As the heading changes the chart will rotate.

### **Object Information**

You can set Object Information ON or OFF. When set ON, object information is displayed in normal chartplotter operation when the cursor is placed over a chart object for two seconds. When set OFF, no information is displayed.

### **Waypoint Options**

**Waypoint Symbols** controls whether or not the waypoints are shown on the Chart display, with their appropriate symbols. The active waypoint, and waypoints in the current route are always shown.

**Waypoint Numbers** controls whether or not the waypoint numbers are shown for any waypoints in the current route.

**Default Waypoint Symbol** lets you select the symbol you want used for waypoint display.

### Vectors

Heading, Tide and Course Over Ground vectors can be displayed as a line from your vessel. The length of the vector is determined by your choice of SOG and the time period. An infinite vector extends to the edge of the chart screen.

Heading Vector indicates your current heading.

COG Vector indicates your course over ground.

**Tide Vector** indicates the tide angle. Tide information is calculated from the speed through water, compass and position data.

## **Radar/Chart Synch**

If you have a combined radar/chartplotter display you can select Radar/Chart Synch ON or OFF. When set ON with chart and radar windows displayed, FIND SHIP can be used to synchronize the radar and chart images.

The chart is redrawn so that its centre matches that of the radar display. The radar is redrawn to the scale and heading mode of the chart.

### **Datum Selection**

You can select either WGS 84 or LOCAL datum. In LOCAL mode, you are presented with a list of datums; use the trackpad to scroll through the list, then press **ENTER** to select the option and close the menu.

#### **CAUTION:**

Changing the chart datum does *not* cause any waypoint or routes stored in the chartplotter to move on the display, although their latitude and longitude changes to reflect the new datum.

When adding waypoints numerically to the waypoint list, or via SeaTalk or NMEA, it is important that they are referenced to the same datum to which the display is currently set.

When you change datum selection, the system attempts to set any connected GPS to the new mode, using SeaTalk and NMEA set up commands. A message shows whether the set up was successful or not.

### **Position Offset**

You can offset the vessel position to allow for differences between the GPS and paper chart data. This may be useful if you are using a datum that is not available on the Chartplotter, or if you are referring to a paper chart drawn to unknown datum.

You can change the offset by moving the cursor to the known vessel position. This offset is applied to all incoming position data. The default offset value is zero.

When position offset is switched on, all displayed vessel position data is annotated (C) to indicate it has been corrected.

- ► To switch the position offset on/off:
  - 1. Select the POSITION OFFSET option, then press the OFFSET OFF ON soft key to toggle the option on/off. The last selected offset value is added to position data and the vessel is displayed at the corrected position.
- ► To set a new offset value:
  - 1. Select the POSITION OFFSET option, then press the SET UP OFFSET soft key. If necessary, position offset is automatically toggled on.
  - 2. Use the trackpad to move the cursor to the required vessel position; the cursor position is displayed in a position offset data box.
  - 3. Press the ACCEPT OFFSET soft key, the vessel is displayed at the new position. Press **ENTER** to return to the default display.
- ► To set the offset value to zero:
  - 1. Select the POSITION OFFSET option, then press the SET UP OFFSET soft key
  - 2. Press the CANCEL OFFSET soft key. The position offset value is set to zero.

# **Chapter 8: Installation**

## 8.1 Introduction

This chapter provides installation instructions for the SL72 PLUS Pathfinder Radar and SL72RC PLUS Pathfinder Radar/Chartplotter system. Details for mounting and connecting the equipment are included. A typical radar system is shown below



Figure 8-1: Typical System

**Note:** If you wish to practice using the display before installation, connect a 12V or 24V DC power supply (connecting the red wire via a 6.3A quick blow fuse to positive and the black wire to negative) and using the simulator mode, as described in Chapter 2.

If you are connecting your radar system to other equipment install then test the display and scanner as described in this chapter. Once the system is operating correctly, you can connect the display to other equipment as described in *Section 8.11*, taking particular care to ensure the correct polarity of the SeaTalk supply. *Section 8.11* describes the SeaTalk and NMEA interfaces.

For full functionality of the radaryou need to provide position and heading data.

- Orientation heading data is required for the radar to operate in North Up and Head Up mode, and the chart (SL72RC PLUS) to operate in Course Up and Head Up.
- MOB requires heading and speed data. Alternatively, SOG and COG (derived from the same source as position data) enable the MOB function.
- Position data is required for to place Marks and for full functionality of the chartplotter (SL72RC PLUS).

Full details of heading, position and other data are given in Section 8.11.

### **Planning the Installation**

Before you install your system, plan the installation, considering:

- Location of the display unit and scanner, as described in *Section 8.4* and *Section 8.3*.
- Cable Runs, including cables for an integrated system (to provide heading and position data etc.), as described in *Section 8.5*.

### **EMC Installation Guidelines**

All Raymarine equipment and accessories are designed to the best industry standards for use in the recreational marine environment.

Their design and manufacture conforms to the appropriate Electromagnetic Compatibility (EMC) standards, but correct installation is required to ensure that performance is not compromised. Although every effort has been taken to ensure that they will perform under all conditions, it is important to understand what factors could affect the operation of the product.

The guidelines given here describe the conditions for optimum EMC performance, but it is recognized that it may not be possible to meet all of these conditions in all situations. To ensure the best possible conditions for EMC performance within the constraints imposed by any location, always ensure the maximum separation possible between different items of electrical equipment.

For optimum EMC performance, it is recommended that wherever possible:

- Raymarine equipment and cables connected to it are:
  - At least 3 ft (1 m) from any equipment transmitting or cables carrying radio signals e.g. VHF radios, cables and antennas. In the case of SSB radios, the distance should be increased to 7 ft (2 m).
  - More than 7 ft (2 m) from the path of a radar beam. A radar beam can normally be assumed to spread 20 degrees above and below the radiating element.

- The equipment is supplied from a separate battery from that used for engine start. Voltage drops below 10 V, and starter motor transients, can cause the equipment to reset. This will not damage the equipment, but may cause the loss of some information and may change the operating mode.
- Raymarine specified cables are used. Cutting and rejoining these cables can compromise EMC performance and must be avoided unless doing so is detailed in the installation manual.
- If a suppression ferrite is attached to a cable, this ferrite should not be removed. If the ferrite needs to be removed during installation it must be reassembled in the same position.

### **Suppression Ferrites**

The following illustration shows typical cable suppression ferrites used with Raymarine equipment. Always use the ferrites supplied by Raymarine.



Figure 8-2: Typical Suppression Ferrites

### **Connections to Other Equipment**

If your Raymarine equipment is to be connected to other equipment using a cable not supplied by Raymarine, a suppression ferrite MUST always be attached to the cable near to the Raymarine unit.

## 8.2 Unpacking and Inspecting the Components

Unpack your system carefully, to prevent damage to the equipment. Save the carton and packing, in case you need to return a unit for service. Check that you have all the correct system components. These depend on your system:

ltem	Part No	Supplied With
SL72 PLUS System with 10 m cable	E52026	SL72 PLUS
SL72 PLUS System with 15 m cable	E52027	SL72 PLUS
SL72RC PLUS System with 10 m cable	E52041	SL72RC PLUS
SL72RC PLUS System with 15 m cable	E52042	SL72RC PLUS
LCD Display Accessories		
SL70 PLUS 7"LCD Display	E52028	SL72 PLUS
SL70RC PLUS 7"LCD Display	R58149	SL72RC PLUS
7″ Sun cover	D331	SL72 PLUS & SL72RC PLUS
Trunnion knobs (x2)	W145	SL72 PLUS & SL72RC PLUS
7" Mounting bracket assy	W143	SL72 PLUS & SL72RC PLUS
Handbook	81204	SL72 PLUS & SL72RC PLUS
Quick Reference Card - Radar	86051	SL72 PLUS & SL72RC PLUS
Quick Reference Card - Chart	86057	SL72RC PLUS
Flush Mount kit	M92708	Optional
2D 18" Radome Scanner Unit	E52010	SL72 PLUS & SL72RC PLUS
Mounting Hardware Kit, including:	W104	SL72 PLUS & SL72RC PLUS
M8x40 bolts (4), M8 spring washers		
(4), M8 flat washers (4), bitumen		
sealing washers (4), paper template.		
Power/NMEA input cable, 1.5m (5ft)	W144	SL72 PLUS & SL72RC PLUS
Seatalk cable assembly -		
Flat moulded plugs both ends:		
3 ft 3 in (1 m) long	W284	Optional
9ft 9 in (3 m) long	W285	Optional
16 ft 3 in (5 m) long	W286	Optional
29 ft 3 in (9 m)) long	W287	Optional
Flat to male round connector:	D407	
12 In (U.3 m) long	אוט	Uptional
Flat to female round connector:	D100	Ontional
I 2 IN (U.3 M) long	8810	υρτιοπαι
rial moulded plug one end only		
- SUILADIE TOF INIVIEA SYSTEMS:	0220	Ontional
S IL S III ( I III) IOIIY Forrita for SasTalk/NIMEA cable	U229	
	-	3L/2 PLUS & 3L/2KC PLUS
Inter-unit cable 10 m (33ft) light	M92692	SL72 PLUS & SL72RC PLUS
Inter-unit cable 25m (81ft) heavy	M92669	Optional
Extension cable 5 m	M92699	Optional
Extension cable 10 m	M92700	Optional
Mast Mount 18" Scanner	M92722	Optional
Radar Mounting Interface Plate	M92731	Optional
Scanner 8-way connector	R126	Optional
SeaTalk Junction 3-way block	D244	Optional
SeaTalk Auxilary Junction Box	R55006	SL72RC PLUS

Table 8-1: Parts and Accessories

## 8.3 Selecting the Scanner Unit Location

This section provides information that affects the possible locations of the scanner, and its position relative to the display unit and to the power supply.

The dimensions of the scanner unit are shown in *Figure 8-3*.

Selecting the best location for the scanner unit requires careful consideration of the following points, to ensure reliable and trouble free operation:

**Note:** In order to minimize potential interference to other systems on board ship (EMC), it is advisable to mount the scanner on a part of the boat that is insulated from the ship's battery negative. If you cannot do this, and encounter problems, you can fit insulating bushes between the scanner and its mounting bracket.



Figure 8-3: Scanner Dimensions

- **Height:** The scanner unit should normally be mounted as high as practical above the waterline, for three reasons:
  - For safety reasons the scanner should be out of range of personnel, preferably above head height. This avoids mechanical danger and electromagnetic contact, particularly with the eyes.
  - Radar operates at the line-of-sight, so a high mounting position gives better long range performance.
  - Surrounding large objects, in the same horizontal plane, can interfere with the radar signal and cause blind areas or shadow sectors and false targets on the radar screen (see below).

8-5

However, do not mount the scanner so high that it is affected by the pitching and rolling of the vessel. In addition, you may need to lower the scanner to avoid creating a shadow sector underneath the scanner's beam.

- Access: The scanner unit site should be easily accessible to allow maintenance to be carried out safely.
- Magnetic compass: Mount the scanner unit at least 1 m away from a magnetic compass.
- **Cable run:** The maximum length of cable between the display unit and the scanner unit should not normally exceed 20 m (60 ft) for radome scanners. If you need to use a longer cable power cable lengths must be considered, refer to *Section 8.5* to determine appropriate lengths.
- Shadow sectors and false echoes: Mount the scanner away from large structures or equipment, such as the fly bridge, large engine stacks, search-lights, horns, or masts. It is particularly important to avoid shadow sectors near the bow. Raising or even lowering the scanner may help to reduce these effects.

In shadow areas beyond the obstruction there will be a reduction of the beam intensity, although not necessarily a complete cut-off; there will be a blind sector if the subtended angle is more than a few degrees.

In some shadow sectors the beam intensity may not be sufficient to obtain an echo from a very small object, even at close range, despite the fact that a large vessel can be detected at a much greater range. For this reason the angular width and relative bearing of any shadow sector must be determined at installation. Sometimes shadowing can be seen by increasing the radar gain until noise is present. Dark sectors indicate possible shadowed areas. This information should be posted near the display unit and operators must be alert for targets in these blind sectors.

It should also be noted that wet sails create shadow areas and thus sail boat operators should be aware that radar performance may reduce in rain.

If you mount the scanner on a mast, echoes from the mast may appear on the radar display. These can be minimized by placing absorbing material, such as a block of wood, between the scanner and mast.

- **Platform rigidity/stability:** The scanner platform should not twist (causing bearing errors) or be subject to excessive vibration.
- **Heat/fumes:** Mount the scanner away from the top of exhaust stacks, since the scanner and cables can be damaged by excessive heat and the corrosive effects of exhaust gases.

### **Mounting surface: sailboats**

The scanner unit can be installed on a mast platform, an arch, or a bridge structure. Make sure that the platform surface is flat and the radome scanner unit drain hole is not obstructed. Raymarine recommends that radome scanner units are best suited for sailboat operation as open array systems are more difficult to protect from ropes and sails.

For sailboat installations, Raymarine offers a universal mast mount kit for the radome scanner. This optional mount is used to fit a radome scanner to a flat surface on a mast with a minimum diameter of  $60 \text{ mm} (2\frac{1}{2} \text{ in})$ . When using the mast mount kit, appropriate hardware should be used for the style and structure of the mast aboard the vessel. Typically, the scanner will be mounted near the first set of mast spreaders. If there is any doubt concerning the appropriate type of hardware, consult your boat dealer or representative for their recommendations.

Depending on the type of sailboat, a radar scanner guard should be installed if the sails could touch the scanner or platform. Without a proper radar guard the mounting platform and the radar scanner could be severely damaged.

### Mounting surface: power boats

On many small vessels the scanner unit can be installed on a mast platform, an arch, or a bridge structure, but take care to follow the scanner site guidelines, particularly regarding height. If necessary, construct a radar mounting platform to obtain a sufficiently high mounting position. Make sure that the platform surface is flat and the radome scanner unit drain hole is not obstructed. Ensure the platform is strong enough to support the maximum shock loads likely to occur.

### **Setting the radiation plane**

The scanner unit should be mounted so that the array rotates parallel to the waterline. The radar beam is approximately  $25^{\circ}$  wide in the vertical direction, providing good target detection during the vessel's pitching and rolling.



Figure 8-4: Ideal Radiation Plane

Planing hull vessels, and some displacement hull vessels, adopt a higher bow angle when the vessel is at its cruising speed. In many cases this substantially alters and raises the radar's main radiation plane, and can cause poor detection of nearby targets. It may be helpful to lower the radar beam back towards the parallel, by shimming the rear of the radar, so that the beam points slightly downwards with respect to the waterline when the vessel is at rest.



Figure 8-5: Adjusting the Radiation Plane

The shims may be made from aluminium plate wedges, simple flat washers, or an angled wooden block. For thick shims, you may need longer securing bolts than the M8x40 bolts supplied with the radome scanner, or the M10 studding supplied with the open array scanners.

## 8.4 Selecting the Display UnitLocation

The SL70 and SL70RC PLUS LCD display units are waterproof to CFR46 and can be installed either above or below deck. The display unit can be mounted using the mounting bracket supplied, or console mounted using the optional flush-mounting kit.

The dimensions of the display unit, including the bracket, are shown in *Figure* 8-6.

When planning the display installation, the following should be considered to ensure reliable and trouble free operation:

• **Convenience:** the display unit should be mounted in a convenient position, where it can be viewed straight-on or with a viewing angle of less than 35°. Power the unit and select a suitable mounting location prior to installing the display.

The mounting location should be easily accessible to allow operation of the front panel controls.

- Access: There must be sufficient space behind the display to allow cable connections to the rear panel connectors, avoiding tight bends in the cable.
- **Interference:** The selected location should be far enough away from devices that may cause interference, such as motors, generators and radio transmitter/receivers (see the EMC guidelines earlier in this section).
- Magnetic compass: Mount the display unit at least 3 ft (1m) away from a magnetic compass.
- **Cable runs:** The display unit must be located near a DC power source. The power cable supplied is 4.9 ft (1.5m), but a longer cable can be used if required: refer to *Section 8.3*.

The maximum length of cable between a display and the scanner unit should not normally exceed 60 ft (20 m). If you need to use a longer cable, refer *Section 8.3*.

• Environment: Do not restrict airflow at the rear of the display unit. Ventilation is required to prevent the unit from overheating. The display should be protected from physical damage and excessive vibration. Mount the display in a protected area away from prolonged and direct exposure to rain and salt spray.

Figure 8-6: 7" SL70/SL70RC PLUS LCD Display Dimensions

### 8.5 Cable Runs

Consider the following before installing the system cables:

- You need to attach the power cable and the scanner cable. Additional cables will be required if you are installing an integrated system.
- All cables should be adequately secured, protected from physical damage and protected from exposure to heat. Avoid running cables through bilges or doorways, or close to moving or hot objects.
- Acute bends must be avoided
- Where a cable passes through an exposed bulkhead or deckhead, a watertight feed-through gland or swan neck tube should be used.
- Secure cables in place using tie-wraps or lacing twine. Coil any extra cable and tie it out of the way.
- Avoid cutting and re-joining cables (if necessary, refer to the notes below).

You need to run the following cables:

• **Power/NMEA Input cable**, supplied with the display unit. This has a connector plug at one end for connecting the display unit, and 7 wires at the other end for connecting the power supply and optional NMEA inputs (see *Section 8.11, Integrated Systems*).

#### **CAUTION:**

Do not pull the cable through bulkheads using a cord attached to the connector. This could damage the connections.

- Inter-unit cable, supplied with the scanner unit. This is Vinyl-covered and shielded, with a connector plug at one end for connecting to the display unit or extension cable; the other end of the radome scanner cable is fitted with an 8-way plug and power cores (covered by a clear protective sleeve) for connecting to the scanner.
- SeaTalk/NMEA Output cable, optional, with SeaTalk connector(s) at one or both ends.

#### **Rejoining Cables**

You should avoid cutting and re-joining cables. If this is necessary you must:

- Fit a ferrite on each side of the join. The specific ferrite to use depends on the cable type contact Raymarine for details.
- Take care not to damage any of the wires. Make sure that all the wires and, in particular, the screen are reconnected correctly.

If you are mounting the scanner on the mast of a sailboat, and will need to unstep the mast, you should install a suitable junction box inside the boat. On a radome scanner, the junction box should provide an 11- or 13-way terminal strip, depending on the number of power cores in your cable, with a 10 A rating. Also, you should keep the length of the un-screened coaxial cores to less than 30 mm to maintain EMC conformance.

### **Power Cable**

The SL72 PLUS Pathfinder Radar and SL72RC PLUS Pathfinder Radar/ Chartplotter systems are intended for use on ships' DC power systems operating in the 10.7 to 32 V DC range (that is, 12 V and 24 V systems, not 32 V systems). A 5 ft (1.5 m) power cable is supplied for connecting the ship's DC power to the display unit.

If a longer power cable run is required, use the supplied power cable to connect to the display unit. Then use a suitable connector block to connect the free end to the extension cable, taking particular care to ensure correct polarity. The supplied power cable has a cross-section of 2.0 mm<sup>2</sup>.

**Note:** For vessels with 24 V power systems, the power cable may be extended by up to 20 m using a wire gauge of 1.5 mm<sup>2</sup> (AWG 16) or greater, irrespective of the inter-unit cable length.

For vessels with 12 V power systems, longer power cable runs may require larger wire gauges to minimise any voltage drop in the cable. The length and type of the inter-unit cable also affect the wire gauge required for the extension power cable. In order to determine the correct supply cable size if the power cable must be extended, estimate the length of cable between the ship's main power source and the connector block, and then select the wire size indicated by the distance and inter-unit cable in *Table 8-2*.

For example, you might have a 18" scanner, with 20 m between the scanner and display unit, that you plan to connect by extending the supplied 15 m heavy inter-unit cable with a 5 m extension cable. In addition, your 12 V power supply might be 10 m from the display unit, requiring an extension of 8.5 m. To determine the wire gauge required for the power cable extension, refer to the table for the 18" scanner, go to the row labelled *15 m Heavy* + 5 m *ext*, and read across until you come to a maximum cable length greater than 8.5 m. This is the 10 m entry, in the column for 2.5 mm<sup>2</sup> wire gauge.

Inter-Unit Cable(s)	Powe	er Cable	e Core (e	ach core	2)	
mm <sup>;</sup> : AWG:s)	1.5 16	2.0 15	2.5 14	4.0 11	6.0 10	10.0 7
10 m Light	5.0	7.0	9.0	14.0	20.0	35.0
10 m Light + 5 m ext	1.0	2.0	3.0	4.5	7.0	12.0
10 m Light + 10 m ext	Do NO	)T extend	the powe	er cable		
15 m Light	1.0	2.0	3.0	4.5	7.0	12.0
15 m Heavy	7.0	10.0	13.0	20.0	30.0	50.0
15 m Heavy + 5 m ext	5.0	7.0	10.0	15.0	25.0	40.0
25 m Heavy	4.5	6.0	8.0	12.0	20.0	35.0
25 m Heavy + 5 m ext	3.5	4.5	6.0	9.0	15.0	25.0
25 m Heavy + 10 m ext	2.0	3.0	4.0	6.0	9.0	15.0

Table 8-2:Max. Extension Power Cable Lengths (m), 12 V Systems -<br/>18" Radome Scanner

**Note:** If you have an 18" radome scanner, and the wire gauge required for your extended power cable is unacceptably large, you should replace the supplied light (2 power core) inter-unit cable with the 25 m heavy (4 power core) inter-unit cable assembly (see table).

### **Inter-Unit Scanner Cable**

The inter-unit (scanner) cable entrance is at the rear of the scanner unit. If the unit is mounted on a hollow mast the cable may be run inside the mast and then fed through the radar's cable entrance. Make sure that the cable does not chafe where it enters the mast.

**Note:** *Route the cable from the display up to the scanner, since this will require the smallest clearance hole.* 

#### **CAUTION:**

The display connector on the inter-unit cable is a moulded plug that cannot be replaced. DO NOT remove this moulded plug.

The inter-unit cable, for connecting the scanner to the display unit, depends on your scanner package as follows

 Table 8-3:
 Inter Unit Cables required for each Scanner Type

Scanner Package	Inter-Unit Cable
E52026 2D Scanner	10 m light (2 power cores)
E52027 2D Scanner	15 m light (2 power cores)

The minimum bends permitted are:

Minimum bend, light cable	60 mm (~2.5 in) radius
Minimum bend, heavy cable	82 mm (~3.75 in) radius

The length of the supplied cable should be sufficient to complete the cable run required on most small vessels. For longer runs, additional or replacement cables are available, which have 4 power cores to minimize voltage drops over the longer cable run: these optional cables include 5 m and 10 m extension cables, and a 25 m replacement cable.

The maximum inter-unit cable length is limited by the minimum supply voltage and the cable type (2 or 4 power cores): if a mix of light and heavy cables is used, only 2 power cores are connected through.

**Note:** For vessels with 24 V power systems, any combination of inter-unit cables can be used.

For vessels with 12 V power systems, the recommended cable(s) for different run lengths are given in the following table, which assumes a minimum supply voltage of 10.7 V (the lowest voltage likely to be reached by a 12 V battery in normal marine use). **Do not use cable combinations that are not included in the table.** 

Systems		
Inter-Unit Cable Length Required (m)	Display/Scanne E52026 E52041	er Package E52027 E52042
10	Std 10 m light	N/A
15	Std + 5 m ext	Std 15 m light
20	Std + 10 m ext	25 m assembly
25	25 m assembly	25 m assembly
30	25 m + 5 m ext	25 m + 5 m ext
35	25 m + 10 m ext	25 m + 10 m ext

Table 8-4:Recommended Inter-Unit Cable(s) for Vessels with 12 V Power<br/>Systems

Refer to the packing list in Section 1.2 for cable part numbers.

**Note:** This table applies to systems using the standard 1.5 m power cable. If you extend the power cable you may need to select different inter-unit cable(s), as discussed in Power Cable on page 8-11.

nter-Unit Scanne

Cable
## 8.6 Securing the Radome Scanner to the Mounting Surface

#### CAUTION:

The drain tube must always be used, but may be shortened if necessary

**Note:** Using the paper template supplied with the scanner mounting kit, mark the flat mounting surface with the mounting holes and drain tube hole, and drill the holes as indicated on the template.

If it is impractical to drill a hole for the drain tube, then the scanner unit should be mounted on 4 suitable spacers 10 mm high and the drain tube length reduced by 10 mm. It will then be clear of the flat surface and can still perform its function.

**Note:** If you are using a Raymarine mast mount bracket, the surface is preprepared.

**Note:** If you are mounting the scanner on a flat surface, you may find it easier to fit the drain tube, as described in the following section, before securing the scanner.

- 1. Position the scanner on the mounting surface, ensuring that the cable inlet is pointing aft.
- 2. Locate the bolts and washers supplied with the scanner, grease the bolts, and secure the scanner to the mounting surface as shown in the following diagram. Tighten the bolts to 20 Nm (14.7 lb ft); ensure the scanner is tightly fitted.



Figure 8-7: Fitting the Scanner Locating Bolts

You may need to use longer M8 mounting bolts to secure the scanner if you have used shims to lower the radar beam.

8-14

## 8.7 Connecting the Inter-unit Cable to the Scanner

#### CAUTION:

Before wiring the scanner unit, make sure that the inter-unit cable is not connected and power is not applied to the display unit.

When you have run the inter-unit cable to the scanner location, connect the cable as follows:

- 1. Loosen the 4 screws securing the scanner cover. These screws are captive and should remain assembled to the lower flange assembly. Press the radome inwards to release the top. This breaks the seal and makes removal easier.
- 2. To avoid losing the scanner cover, tie the cord, attached to the inside of the base of the scanner, to the eye provided in the cover.
- 3. Remove the drain tube from inside the base of the scanner, and insert it into the drain hole as shown in the following diagram. Pull the tube gently from outside the scanner so that it clips into place.



Figure 8-8: Fitting the Scanner Drain Tube

- 4. Referring to *Figure 8-9*, remove the securing nut (1) from the watertight gland and grommet (2), where the inter-unit cable (3) will enter the base.
- 5. Slide the gland nut (1) onto the inter-unit cable (3), and insert the cable, still covered by its protective sleeve, through the gland and grommet into the base.
- 6. Carefully cut and remove the protective sleeve to expose the 8-way plug (4) and power cores (6). Place the cable in the earthing clamp (9), ensuring that the exposed wire braid sits in the earthing clamp.



1 Securing nut 2 Gland 3 Inter-unit cable 4 Eight-way plug 5 Eight-way socket 6 Power cores 7 Terminal clamp 8 Screwdriver 9 Earthing clamp 10 Top clamp 11 Clamp screws

Figure 8-9: Fitting the Inter-unit Cable to the Scanner

- 7. Connect the 8-way plug (4) to the connector (5). The correct fitting is with the small arrow marked on the body of the plug facing upwards and to the left hand side. The grey wire will then be at the left hand side and the white wire will be at the right hand side.
- Connect the red "+" and black "-" power cores (6).
   Connect the red cable lead to one of the terminal sockets marked "+", and the black cable lead to one of the sockets marked "-".

The terminal clamps (7) are operated using a screwdriver (8), as shown in the inset diagram on *Figure 8-9*.

- 9. Secure the nut (1) on the watertight gland, making sure that it grips the cable's outer sheath.
- 10. Secure the cable with the top clamp (10), using the two screws (11) provided. Ensure that the clamp goes around the exposed wire braid, and that the wire braid makes contact with the earthing clamp. Tighten the screws until the top clamp deforms *just enough* to contact the lower earthing clamp (see inset).

#### CAUTION:

It is essential that the drain tube is fitted and that the nut on the watertight gland is adequately tightened. If this is not done, water could become trapped in the scanner and cause irreparable damage.

- 11. Tighten the securing nut (1) again to ensure a waterproof seal.
- 12. Untie the cord from the scanner cover, and coil it up in the base of the scanner unit so that it cannot foul the rotating antenna.
- 13. Replace the scanner cover, aligning the mark on the cover with the mark on the scanner base above the cable gland, and tighten the 4 captive screws.Do not over-tighten these screws.

## 8.8 Mounting the Display Unit

The SL70 and SL70RC PLUS LCD display units are waterproof to CFR46 and can be installed either above or below deck. The display unit can be mounted using the mounting bracket supplied, or console mounted using the optional flush-mounting kit (see *Section 8.2*).

#### **Mounting Bracket**

The display unit can be mounted on a dash, chart table, bulkhead or deckhead.



Figure 8-10: LCD Display Mounting

- 1. Loosen the knobs and remove the mounting bracket from the display unit.
- 2. Mark the locations of the mounting bracket screw holes on the mounting surface.
- 3. Use the screws supplied to attach the mounting bracket at the marked locations.
- 4. Attach the display unit to the mounting bracket, adjust the display angle and tighten the knobs.

#### **Console Mounting**

The display unit can be console mounted if required, using the optional flushmounting kit (M92708).

#### CAUTION:

Make sure there are no hidden electrical wires or other items behind the location before proceeding. Make sure there is sufficient rear access for mounting and cabling.

- Check the selected location for the unit. A clear, flat area at least 9 in (230 mm) wide by 8¼ in (210 mm) high, with at least 6in (152 mm) of clearance behind the panel, is required.
- 2. Unpack the flush-mounting kit.
- 3. Using the supplied template, trace out the display unit opening.
- 4. Drill a  $\frac{1}{2}$  in (12.7 mm) pilot hole in each corner of the cut-out area.
- 5. Using a suitable saw, cut along the inside edge of the cut-out line.
- 6. Remove the mounting bracket knobs and bracket from the display unit. Make sure that the unit fits in the cut-out area.

If the optional screw fitting is required, drill four 3/16 in (5 mm) holes as indicated on the template.

Screw the studs into the holes provided at the rear of the display.

- 7. Connect the DC power cable, inter-unit cable, and any other accessory cables to the display. Avoid tight bends in the cables.
- 8. Place the gasket on the unit and slide the unit into the panel cut-out.
- 9. Use the flush-mounting kit to secure the unit to the console.

Alternatively, place a spacer over each of the four studs and secure with the thumb nuts.

## 8.9 System Connections

#### **Grounding the System**

It is important that an effective RF ground is connected to the system. You must ground the display by connecting the drain wire (shield) of the Power/ NMEA Input cable to the nearest ground point of the ship's RF ground system.

If you need to extend the wire, the extension wire should be an 8 mm braid or AWG 10  $(6.0 \text{ mm}^2)$  multi-stranded cable.

If your vessel does not have an RF system, connect the drain wire to the negative battery terminal.

#### **DC Power Connection**

The SL72 PLUS Pathfinder Radar and SL72RC PLUS Pathfinder Radar/ Chartplotter systems are intended for use on ships' DC power systems rated at 12 V or 24 V. Power is supplied to the scanner via the display unit.

The DC system should be either:

- Negative grounded, with the negative battery terminal connected to the ships ground.
- Floating, with neither battery terminal connected to the ships ground.

#### CAUTION:

This system is not intended for use on "positive" ground vessels. The power cable Ground (earth) connections must be connected to the ship's ground as described above.

The power connection to the display should be made at either the output of the battery isolator switch, or at a DC power distribution panel. Raymarine recommends that power is fed directly to the display via its own dedicated cable system and MUST be protected by a thermal circuit breaker or fuse, installed close to the power connection.

Vessels Supply	Device	Value
12 V	Isolator Switch min. rating	20A
	Thermal Breaker rating	10A
	Fuse value	15 A
	Isolator Switch min. rating	15 A
24 V	Thermal Breaker rating	5 A
	Fuse value	8 A

Table 8-5: Isolator Switch/Thermal Breaker/Fuse Values

Connections

## **Power for External Equipment**

# External equipment cannot be powered from the display's SeaTalk interface.

It must be powered from the ship's supply or via a SeaTalk bus.

Refer to Section 8.11 for further details.

## **Display Unit Connection**

The rear of the SL70 and SL70RC PLUS LCD displays provide the following connection sockets:

- Scanner (antenna) connection
- SeaTalk SL72 PLUS for SeaTalk data input and output or NMEA output SL72RC PLUS for SeaTalk data input and output
- NMEA Output SL72RC PLUS only for NMEA data output (see *Section 8.11*).
- **Power/NMEA Input**, for 12 V or 24 V DC power connection, two NMEA 0183 inputs and one RF ground (screen) connection.



SL70: 1, 2 Not used 3 Power and NMEA Input 4 Scanner 5 SeaTalk or NMEA output SL70RC: 1NMEA Output 2 Not used 3 Power and NMEA Input 4 Scanner 5 SeaTalk

Figure 8-11: SL70/SL70RC PLUS Display Connector Panel.

The following sections detail the display unit connectors for a stand-alone system. Connector details for an integrated system are given in *Section 8.11*.

## **Scanner Connection**

The inter-unit cable is connected to the scanner as described in *Section 8.7*. If you are using an inter-unit extension cable, connect this to the display unit, and connect the supplied cable to the extension cable.

The scanner connector pins are shown in the following diagram, together with the connections and core colours.

#### **CAUTION:**

The display connector on the inter-unit cable is a moulded plug that cannot be replaced. DO NOT remove this moulded plug.



Figure 8-12: Radar Scanner Connection

#### **Power and NMEA Input Connection**

The DC power and NMEA input should be connected at the rear Power/ NMEA seven-pin connector. The connector (viewed from the outside) and pin functions are shown in the following diagram and table. The NMEA Input is detailed in *Section 8.11*.



Pin No.	Function	Color
1	Channel 1 NMEA data input (+ve)	Orange
2	Channel 1 NMEA return (-ve)	Yellow
3	Battery negative	Black
4	Shield (drain wire)	No insulation
5	Battery positive (12/24 V systems)	Red
6	Channel 2 NMEA data input (+ve)	Green
7	Channel 2 NMEA return (-ve)	Blue

Scanner Connection

Figure 8-13: Power and NMEA Connector

#### Power Connection CAUTION:

If the power connections are accidentally reversed the system will not work. Use a multimeter to ensure that the input power leads are connected for correct polarity.

Switch off the display unit before you remove the power cord.

The RED wire must be connected to the feed from the positive (+) battery terminal and the BLACK wire to the feed from the negative (–) battery terminal. The shielded wire (screen) should be connected to the ship's RF ground as previously described in *Grounding the System* on *page 8-20*.

Any unused wires should be insulated and taped back.

## 8.10 Radar System Tests and Post Installation Alignment

Once you have installed your Pathfinder Radar System and made all the connections, you need to check your installation and perform the *System Tests* before using the system for navigation. It is strongly recommended that the System Tests are performed before connecting the radar to other equipment in an integrated system. If you have extended your inter-unit cable, you will also need to check the display timing. If you encounter any problems, refer to *Chapter 9*.

You may wish to read *Chapters 2 to 4*, and familiarise yourself with the operation of the system, before performing the initial set up and alignment.

## **System Check**

Before performing the functional test, check the following:

- All securing bolts are fully tightened and mechanical locking arrangements as specified are in place.
- Scanner and power connections have been made.
- All connecting wires are secured and protected as necessary.

**Note:** If you are the boat owner and have performed the installation yourself, ask your authorised installation dealer to check the installation before going to sea.

## **Switch On and Initial Setup**

To switch on the display unit, press and hold the **POWER** key until the unit beeps. The magnetron warm-up sequence should start, after which the unit should enter Standby mode.

The display switches on in the last used mode. If it is necessary to change the mode, press **DISPLAY** to show the Display pop-up. Press **DISPLAY** again, as necessary, to select Radar mode, then press **ENTER**.

If necessary, adjust the lighting (see *Changing the Lighting and Contrast* on *page 2-6*).

If required, change the default language settings as follows:

1. Press the **MENU** key to display the setup soft keys.



 Press the SYSTEM SET UP soft key. The SYSTEM SET UP menu is displayed, listing the parameters and their cur-

SYSTEM SET I	UP MENU
DATA BOXES	
BEARING MODE	TRUE
CURSOR REFERENCE	RELATIVE
CURSOR READOUT	RNG/BRG
DAY/NIGHT	RNG/BRG
HELP	ON
SOFT KEYS	ON
KEY BEEP	ON
MOB DATA	DR
MENU TIMEOUT PERIOD	NO TIMEOUT
DISTANCE UNITS	NAUTICAL MILES
SPEED UNITS	KNOTS 💌
DEPTH UNITS	METRES
TEMPERATURE UNITS	CENTIGRADE
VARIATION SOURCE	AUTOMATIC
BRIDGE NMEA HEADING	ON
DATA SELECTION	SEATALK/NMEA IN
CURSOR ECHO	<b></b>
DATE FORMAT	DD/MM/YY
ILME FORMAT	24 HOUR
ILME UFFSEI	
	ENGLISH (US)
SINULATUK	UP P D3650-5

rent settings. The complete list, which you can scroll down, is shown in the following illustration.

Figure 8-14: System Set Up Menu (SL72 PLUS)

- 3. Use the trackpad to move the selection bar down to the LANGUAGE option. the soft key labels are updated.
- 4. Use the soft keys to highlight the required language.
- 5. Press **ENTER** to return to the setup soft keys.
- 6. Press **CLEAR** to return to the normal radar screen.

## **Radar System Checks and Adjustments**

When the display is connected to a scanner unit you should perform the checks and adjustments detailed below.

#### **Transmission Check**

#### WARNING:

The radar scanner transmits electromagnetic energy. Ensure that the scanner has been installed according to the recommendations given in this handbook and that all personnel are clear of the scanner, before switching to transmit mode.

Ensure the display unit is in Radar mode.

To switch to transmit mode, press and release the **POWER** key. The antenna sweep should start to build up the radar picture.

Run through the operations described in *Chapter 3* and check that all the expected data is displayed.

#### **Bearing Alignment**

When the system is correctly installed, you must check the bearing alignment to ensure that targets appear at their correct bearing relative to the ship's bow, and adjust the alignment if necessary.

To adjust the alignment, you need to select a visible target of known bearing that is displayed on the radar, and then use the setup options to adjust the radar until the correct bearing reading is obtained.

➤ To determine the alignment error, use one of the methods detailed below.

- 1. Visually identify a suitable target, such as a buoy that can be seen towards the edge of the radar screen. Typically, this will be on the 1.5 nm range.
- 2. If the vessel is moored:
  - i. Determine the accurate bearing of the target relative to the ship's bow with the aid of a hand bearing compass. i.e. Subtract the ship's head bearing from the target visual bearing.

Example 1 Visual bearing=  $065 \,^{\circ}M$ Ship's head=  $021^{\circ}M$ Relative bearing=  $044^{\circ}R$ 

Example 2 Visual bearing =  $030^{\circ}M$ Ship's head =  $042^{\circ}M$ Relative bearing =  $-012^{\circ}(+360) = 348^{\circ}R$ 

- ii. Measure the relative bearing of the target on the radar using an EBL.
- iii. If there is a difference in the two bearings (alignment error), adjust the radar as detailed below.

If the vessel is under way (in reasonably calm conditions):

- i. Align the vessel's bow to the target.
- ii. Note the position of the target relative to the Heading marker.
- iii. If the target is **not** under the Heading marker, there is an alignment error and the radar can be adjusted as detailed below.

- 1. If a visual relative bearing of a target has been determined, as in 2.1 above, set an EBL to this relative bearing.
- 2. Press the **MENU** key to display the setup soft keys and select RADAR SET UP.

RADAR SET	UP MENU
EBL DISPLAY	RELATIVE
TIMED TRANSMIT	OFF
TRANSMIT PERIOD	20 SCANS
STANDBY PERIOD	10 MINS
DEFAULT MARK SYMBOL	x
MARK DISPLAY	OFF
CLEAR MARKS	
CUSTOM SCALE	OFF
BEARING ALIGNMENT	

Figure 8-15: Radar Set Up Menu

3. Use the trackpad to move the selection bar on the Radar Set Up Menu to BEARING ALIGNMENT.

D3649-2

- 4. Use the soft keys to adjust the Bearing Alignment slider and to rotate the radar picture. As soon as you start the adjustment, the menu is cleared so that the rotation of the picture can be seen. The keys can pressed and held, to rotate the picture quickly, rather than in single steps.
- 5. Rotate the picture to place the target under the EBL, or Heading Marker, depending on the method used to obtain the correct relative bearing.
- 6. When the bearing alignment error has been eliminated press **ENTER** to redisplay the Radar Set Up menu.
- 7. Press **ENTER** again to return to the set up soft keys, then press **CLEAR** to return to the normal radar screen.
- 8. After adjusting the radar, always check the bearing alignment at the next opportunity. Usually the bow alignment to target is the most convenient method (see *If the vessel is under way (in reasonably calm conditions):* on *page* 8-26).

## **Display Timing Adjustment**

The display timing can be affected by the length of the cable used to connect the scanner to the display unit. This in turn affects the short range accuracy shown on the display. If you have extended (or reduced) your inter-unit cable, you will need to check the display timing before using the system for navigation.

Incorrect timing is most noticeable on the 1/8 nm or 1/4 nm range scales. Targets such as bridges or piers appear bent or bowed.

**Note:** Under normal circumstances you do not need to adjust these settings, as they are set automatically at the factory. **If these parameters are set incorrectly the performance of the radar will be adversely affected.** Access to this menu is therefore via a hidden key press.

- ► To adjust for correct timing:
  - 1. Select the  $\frac{1}{8}$ nm range.
  - 2. On the radar locate a straight dock, seawall or bridge that is facing your ship. If the image is bent or bowed, as shown in the following diagram, then you need to adjust the timing.



Figure 8-16: Radar Display Timing

- 3. Press the **MENU** key to display the setup soft keys.
- 4. Press and hold the blank soft key directly to the right of the RADAR SET UP soft key for 5 seconds. The Advanced Set Up menu is then displayed.
- 5. Use the trackpad to move the selection bar down to the Display Timing option.
- 6. Use the soft keys to adjust the Display Timing slider. As soon as you start the adjustment, the menu page is cleared so that you can see the effects of the adjustment on the radar picture, and the radar is set to  $\frac{1}{8}$  nm range.
- 7. When the displayed image appears straight, press **ENTER** to return to the Advanced Set Up soft keys.
- 8. Press **CLEAR** to return to the setup soft keys, and **CLEAR** again to return to the normal radar screen.

Alternatively, you can use a VRM in conjunction with a target at a known distance and adjust the picture so the target co-incides with the VRM.

## EMC Conformance

Always check the installation before going to sea to make sure that it is not affected by radio transmissions, engine starting etc.

## 8.11 Integrated Systems

The SL72 PLUS display can be linked to other equipment to transfer data as **either**:

• SeaTalk input and output with NMEA input

or

• NMEA input and output

The SL72RC PLUS display can be linked to other equipment to transfer data as follows:

SeaTalk input/output

and

• NMEA input and output

Data received via SeaTalk or NMEA can be used to increase the functionality of the display. Other data can be viewed on the display.

Data can be transmitted via SeaTalk and NMEA to enhance other equipment. Some incoming data can be converted across the communication link and retransmitted - see *Data Conversion* on *page 8-35*.

## **Power for External Equipment**

**External equipment cannot be powered from the display's SeaTalk interface.** It must be powered from the ship's supply or via a SeaTalk bus. Ensure correct polarity of the SeaTalk connection.

For systems where the ship's power source is 24 V only, you may need to install a 24 V to 12 V DC converter. This is only necessary if the products being connected to the display are:

- SeaTalk compatible (for example, compass, GPS and instruments), and there is no existing SeaTalk bus
- NMEA compatible, but operate only from 12 V (for example, compass, GPS and some navigators)

The DC~DC converter must conform to the following specification:

Table 8-6: DC-DC Converter for External Equipment

Input	21 to 32 V DC
Output	13.6 V DC, isolated
Load	Continuous current rating, in excess of required load

## SeaTalk<sup>®</sup> and NMEA In

The primary data is in Table 8-7:

Data	Primary Uses	Suggested Source
Heading	North Up, Course Up modes MOB (if speed data also available)	Autopilot compass, Compatible NMEA Compass, Compass connected to SeaTalk bus
Position	MOB (also requires speed and HDG data) Position data in data box and Nav Window Waypoints and Marks SL72RC PLUS chartplotter - Own vessel position & Data Log	Existing GPS Navigator via SeaTalk bus Existing GPS (or Loran-C) navigator with NMEA output SeaTalk GPS connected via Auxiliary Junction Box
Speed	MOB (also requires HDG data) TTG and ETA calculations	As for position data Log (speed through water)
Waypoint	Graphical display SL72RC PLUS chartplotter - way- point and route transfer	Existing GPS Navigator via SeaTalk bus Existing GPS (or Loran-C) navigator with NMEA output

Table 8-7: Function of SeaTalk and NMEA Data

Heading data should ideally contain both magnetic and true heading. If only one is available then variation needs to be provided either manually or automatically - see *Variation Source* on *page 7-8*.

Some other radars and chartplotters can exchange their cursors via SeaTalk.

Locked heading should be used for Course Up if available via SeaTalk.

Other data connected via a SeaTalk bus or via NMEA is generally displayed in data boxes, e.g. depth, apparent wind angle and speed, time.

For details of received data refer to the table in *Appendix D:SeaTalk and NMEA Data Received and Transmitted*.

#### SeaTalk

The SeaTalk standard allows compatible instruments to be connected by a single cable carrying power and data in/out. This means that additional instruments and functions can be added to a SeaTalk system, simply by plugging them into the network.

SeaTalk is a precise, high-speed, bi-directional protocol which is flexible enough to adapt to any number of instruments, without a central processor. SeaTalk equipment can also communicate with non-SeaTalk equipment via the NMEA standard.

SeaTalk® ar NMEA In

## SeaTalk Connection

SeaTalk data, if present, is the primary source for all navigational data except heading.

**Note:** On the SL72 PLUS Radar display you can connect **either** SeaTalk input/ output **or** NMEA output, but not both. Ensure that the Data Selection option in the System Set Up menu is set correctly.

The SeaTalk input/output should be connected at the rear SeaTalk 3-pin connector. This appears as follows, when viewed from outside:



Figure 8-17: SeaTalk Connector

Pin No.	Function	Color
1	+12 V	Red
2	0 V	Shield
3	Data	Yellow

**Notes: 1**. If you use the SeaTalk connector you must fit the supplied ferrite to the cable for EMC CE conformance. The ferrite must be clipped to the cable as close to the connector as possible.

2. The display does not supply 12 V via the SeaTalk connector, neither does the SeaTalk connector require 12 V to operate. 12 V is required for other SeaTalk units

**3.** If you are connecting an active compass to the radar, the NMEA input has priority. You should, therefore use an NMEA input channel (see Power and NMEA Input Connection on page 8-22) rather than the SeaTalk interface, unless the compass only has a SeaTalk output.

To connect the display unit to the SeaTalk bus, connect a standard SeaTalk cable between the SeaTalk connector on the rear of the display and a SeaTalk instrument or the SeaTalk bus.

Standard SeaTalk cables are available in a range of lengths (part numbers W284 to W287), and cables for connecting to SeaTalk units with round

connectors are also available (part numbers D187 or D188), see *Section 8.2* for further details.

#### **NMEA 0183**

The NMEA 0183 Data Interface Standard was developed by the National Marine Electronics Association of America. It is an international standard that enables equipment from many different manufacturers to be connected together and to share information.

The information is passed in "sentences", each of which has a three-letter sentence identifier. When you check to see if one item will "talk" to another, make sure that the two items both use the same sentence identifiers. For example: VTG carries Course and Speed Over Ground data; GLL carries latitude and longitude; DBT carries water depth; MWV carries relative wind angle and wind speed data.

The NMEA 0183 standard carries similar information to SeaTalk. However, it has the important difference that one cable will only carry information in one direction. For this reason NMEA 0183 is generally used to connect a data receiver and a transmitter together: for example, a compass sensor transmitting heading to a radar, or a GPS sensor (or Chartplotter) transmitting position and navigation data to a radar.

#### NMEA Input Connection

The NMEA/Power input connector is normally used for non-SeaTalk Compass (heading) data or GPS. It can also be used for additional navigation data (if not provided via SeaTalk).

Connect the input(s) to the orange and yellow wires (Channel 1) and/or the green and blue wires (Channel 2). Refer to *Power and NMEA Input Connection* on *page 8-22* for further details.

For example, to connect a Raymarine Heading Sensor to the NMEA Channel 1 input, connect the cables and power supply using a suitable connector block, as shown in the diagram below. If installed, it may be convenient to connect power to the SeaTalk auxiliary junction box described in the following section.



Figure 8-18: NMEA Input Connection

## **Using the SeaTalk Auxiliary Junction Box**

A junction box (provided with the SL72RC PLUS Combined Radar/ Chartplotter; optional with the SL72 PLUS Radar displays) is used to connect the SeaTalk system to the display unit. This junction box enables the SeaTalk bus, power and GPS to be connected.

If power is not already available (via another SeaTalk instrument), the junction box can be used to apply power to the SeaTalk bus for other applications. The junction box may also be used for other purposes, e.g. supplying power to a flux gate compass and routing the compass data to the display NMEA In connection, or alternatively, for connecting a NMEA GPS system.

The junction box includes:

- SeaTalk cable and connector to attach to display unit
- Power cable to connect to 12 V power (if required)
- Input connections to connect SeaTalk cable from external equipment
- Spare connections for another instrument

#### **CAUTION:**

Ensure correct polarity of the 12 V supply before applying radar or SeaTalk power. It is recommended that a multimeter is used to check the connections.

*Figure 8-19* shows how to connect the junction box; *Appendix B* provides connection details for specific GPS and Beacon Receiver systems.

Using the SeaTall Auxiliary Junctior Box



Figure 8-19: Using the Auxiliary Junction Box

## **Data Output**

Data is transmitted in SeaTalk and NMEA formats as detailed in *Appendix D* and can be used to enhance other equipment as required. You can disable the transmission of individual NMEA output sentences - refer to *NMEA Out Set Up* on *page 7-9*.

The SeaTalk input/output connection is detailed in *SeaTalk Connection* on page 8-31.

#### **SL72 PLUS Radar Display**

On the SL72 PLUS Radar display NMEA output is connected at the rear SeaTalk 3-pin connector. This appears as follows, when viewed from outside:





If you are using NMEA output data, you must set the Data Selection option, in the System Set Up menu to NMEA IN/OUT.

#### SL72RC PLUS Combined Radar/Chartplotter Display

On the SL72RC PLUS Combined Radar/Chartplotter, the NMEA output connector is a 4-pin connector as illustrated below. The 1.5 m NMEA OUT cable has a ferrite clamp attached to ensure EMC conformance.



Figure 8-21: NMEA Output Connector

### **Data Conversion**

The SL72 and SL72RC PLUS displays convert some information across the communications links as follows:

NMEA Into NMEA Out and SeaTalkSeaTalkto NMEA Out

This enables data received by the display to be passed to other instruments. For example, if you have a master and a repeater display, you only need to connect NMEA In to the master display, which will pass the data to the repeater via SeaTalk.

You can prevent NMEA heading data being bridged onto the Seatalk bus - refer to *Bridge NMEA Heading* on *page 7-9*.

**Note:** To transfer NMEA data, or to convert the data, the display must be powered On.

## 8.12 Integrated System Checks

## **Chart Display - SL72RC PLUS only**

When you have connected your display unit to the required equipment ensure that position data is available at the display via NMEA or SeaTalk.

To confirm your chartplotter is operating correctly, perform the following checks:

- Without a chart card installed, select the Chart display mode and select a suitable range scale. Verify that the world map is visible. Use the trackpad to check cursor movement and normal scrolling action.
- 2. To ensure that the display is responding to position data: Press FIND SHIP, check the cursor is fixed on the vessel symbol which is correctly positioned at the center of the chart display.
- Insert a chart cartridge for the area of your vessel. Use the RANGE key to zoom-in to check that the chart data is being displayed.

## **Received Data**

If SeaTalk or NMEA In is connected, verify that the expected data is displayed.

On the SL72 PLUS Radar Display ensure that the Data Selection option in the System Set Up Menu is set to SEATALK/NMEA IN (the default setting).

- 1. Press **DISPLAY** and select the NAV DATA WINDOW ON. Check that the expected data is displayed.
- 2. If heading data is connected, select Chart mode and check it is displayed in the heading data box, or select Radar mode and check heading is displayed in the Status Bar.

## **Transmitted Data**

If SeaTalk or NMEA Out is being transmitted to other equipment check that the data is being received correctly.

On the SL72 PLUS Radar Display, if NMEA out is being transmitted, ensure that the Data Selection option in the System Set Up Menu is set to NMEA IN/ OUT.

# Chapter 9: Maintenance and Problem Solving

This chapter provides information on routine maintenance and on possible causes of problems you may experience with your SL72 PLUS Radar or SL72RC PLUS Combined Radar/Chartplotter system.

## 9.1 Maintenance

#### WARNING:



The display unit contains *high voltage*. Adjustments require specialized service procedures and tools only available to qualified service technicians - there are no user serviceable parts or adjustments and the operator should not attempt to service the equipment. *The operator should not remove the rear cover of the display*.

Always switch the radar system off before carrying out any routine maintenance on the scanner or nearby equipment. Switch off the display unit before removing the power cord.

## **Routine Checks**

The LCD display and radome scanner are sealed units. Maintenance procedures are therefore limited to the following periodic checks:

- Wipe the display clean with a damp cloth (ensure power is off).
- Examine the cables for signs of damage, such as chafing, cuts or nicks.
- Check that the cable connectors are firmly attached.
- Make sure the scanner is still attached securely to the mounting.
- Once a year remove, grease and re-attach the mounting bolts securing the scanner.

## **EMC Servicing and Safety Guidelines**

- Raymarine equipment should be serviced only by authorized Raymarine service technicians. They will ensure that service procedures and replacement parts used will not affect performance. There are no user serviceable parts in any Raymarine product.
- Some products generate high voltages, so never handle the cables/connectors when power is being supplied to the equipment.
- When powered up, all electrical equipment produces electromagnetic fields. These can cause adjacent pieces of electrical equipment to interact with one another, with a consequent adverse effect on operation. In order to minimise these effects and enable you to get the best possible performance

from your Raymarine equipment, guidelines are given in the installation instructions, to enable you to ensure minimum interaction between different items of equipment, i.e. ensure optimum Electromagnetic Compatibility (EMC).

- Always report any EMC-related problem to your nearest Raymarine dealer. We use such information to improve our quality standards.
- In some installations, it may not be possible to prevent the equipment from being affected by external influences. In general this will not damage the equipment but it can lead to spurious resetting action, or momentarily may result in faulty operation.

## 9.2 Resetting the System

There are three types of reset available for the display:

• Factory Reset: This resets all values back to their original factory settings.

#### CAUTION:

The factory reset clears the Marks database and, on the SL72RC PLUS chartplotter, the Waypoints and Routes databases.

- **Power-On Reset:** When you turn the display off and on again, the screen reverts to the fishfinder or chart picture with all windows cleared.
- **Picture Reset:** Press and hold the **DISPLAY** key for two seconds to return the screen to the full-screen picture of the top window with all windows cleared.

At power-on, the last-used values are retained for all the options, except for those listed in the following table which are reset to the factory default each time.

ltem	Power-on setting	
Heading Mode	Head Up (radar); North Up (SL72RC PLUS chart)	
Rain	OFF (but value stored) – radar only	
FTC	OFF (but value stored) – radar only	

OFF

OFF

ON, with last-used value

Table 9-1: Power On Default Settings

- ► To perform a factory reset:
  - 1. Press **MENU**.

Alarm

Zoom

Windows

Contrast Level

Backlight Level

2. Press the SYSTEM SET UP soft key to display the System Set Up page (see *Section 7.3* for details).

Within 30-70% range, if last-used outside this range.

ON at default setting if previously selected

3. Press and hold **MENU** for 5 seconds.

A countdown timer is displayed. If you release the **MENU** key before the timer reaches zero, the reset is not performed.

When the reset request has been accepted, the system restarts.

The factory default settings are listed in *Section 7.3* 

## 9.3 Problem Solving

All Raymarine products are, prior to packing and shipping, subjected to comprehensive test and quality assurance programs. However, if this unit should develop a fault, please refer to the following table to identify the most likely cause and the corrective action required to restore normal operation.

If you still have a problem after referring to the table below, contact your local dealer, national distributor or Raymarine Technical Services Department for further advice.

Always quote the product serial numbers. The display unit serial number is printed on the back of the unit.

## **Common Problems and Their Solutions**

Problem	Correction
Display does not function	<ol> <li>Make sure that the power supply cable is sound and that all connections are tight and free from corrosion.</li> <li>Check the system fuse.</li> </ol>
"Scanner not responding" message	Check that the cable connecting the scanner to the radar display unit is firmly attached and undamaged.
The bearing displayed on the radar display is not the same as the actual bearing.	Perform the bearing alignment procedure described in Section 8.7, Radar System Tests and Installation Alignment

Table 9-2.	Common Problems
Table 3-2.	

## **Technical Support:**

Please visit out website at:

www.raymarine.com/recreational/support

where you will find a Questions & Answers database, service information and e-mail access to the Technical Support department.

Alternatively, if you don't have access to the world wide web, call:

1-800-539-5539 extension 2444 or (603) 881-5200 extension 2444

Our Technical Support Specialists are available to answer questions about installing, operating and trouble-shooting all Raymarine products.

## How to Contact Raymarine (US)

#### **For Marine Product and Services Information**

Visit the Raymarine World Wide Web site for the latest information on the newest Raymarine electronic equipment and systems at:

www.raymarine.com

#### **For Accessories and Parts**

Many Raymarine accessory items and parts can be obtained directly from your authorized Raymarine dealer. However, if you are in need of an item not available from the retailer, please contact Raymarine Technical Services at:

1-800-539-5539 extension 2333 or (603) -881-5200.

Technical Service is available Monday through Friday 8:15 AM to 5:00 PM Eastern Standard Time.

Please have the Raymarine item or part number ready when calling if placing an order. If you are not sure which item is appropriate for your unit, you should first contact the Technical Support Department at:

1-800-539-5539 ext. 2444 or

(603)-881-5200 to verify your requirements.

#### **For Product Repair and Service**

In the unlikely event your Raymarine unit should develop a problem, please contact your authorized Raymarine dealer for assistance. The dealer is best equipped to handle your service requirements and can offer timesaving help in getting the equipment back into normal operation.

In the event that repairs can not be obtained conveniently, product service may also be obtained by returning the unit to:

Raymarine Product Repair Center 22 Cotton Road, Unit D Nashua, NH 03063-4219

The Product Repair Center is open Monday through Friday 8:15 a.m. to 5:00 p.m. Eastern Standard Time or Eastern Daylight Savings Time. All products returned to the Repair Center are registered upon receipt. A confirmation letter will be sent to you acknowledging the repair status and the product's reference number. Should you wish to inquire about the repair status of your unit, contact the Product Repair Center at:

1-800-539-5539

Please have the product reference number, or unit serial number, ready when you call. We will do everything possible to make the repair and return your unit as quickly as possible.

## How to Contact Raymarine (Europe)

In Europe, Raymarine support, service and accessories may be obtained from your authorised dealer, or contact:

Raymarine Company Anchorage Park, Portsmouth PO3 5TD, England Tel +44 (0)23 9269 3611 Fax +44 (0)23 9269 4642

Or visit the Raymarine World Wide Web site:

www.raymarine.com

#### **Accessories and Parts**

Raymarine accessory items and parts are available through your authorized Raymarine dealer. Please refer to the lists of component part numbers and optional accessories in the Installation chapter of this manual, and have the Raymarine part number ready when speaking with your dealer.

If you are uncertain about what item to choose for your Raymarine unit, please contact our Customer Services Department prior to placing your order.

## **Worldwide Support**

Please contact the authorized distributor in the country. A list of worldwide distributors is supplied with your system.

# **Appendix A: Specification**

## 2D 18" Radome Scanner Unit

General		
Approvals CE - conforms to	1999/5/EC, EN60945:1997	
FCC - conforms to	Part 80 (47CFR) and Part 2 (4	47CFR)
Dimensions	Φ468 x 227 mm (18.4 x 8.9	in)
Weight	6.5 kg (14.3 lbs)	
Input Voltage	8.7 - 32 V DC (from display u	unit)
Power Consumption	28 W (9 W Standby)	
Environmental	Waterproof to CFR46 Temperature range: Humidity limit: Maximum wind speed for sa	-10° to +55°C up to 95% at 35°C atisfactory operation: 100 Kts
Maximum Range Scale	24 nm	

Transmitter		
Transmitter Frequency	9410 +/- 30 MHz	
Peak Power Output	2.0 kW (nominal)	
Transmitter	Solid-state modula	tor driving Magnetron
Pulse Length/PRF		
Range (nm)	Pulse Length (µS)	PRF (Hz)
0.25 or less	0.065	3000
0.50	0.090	3000
0.75	0.150	3000
0.75 expanded	0.250	2500
1.50	0.350	1800
3.00	0.450	1400
3.00 expanded	0.600	1000
6.00 or greater	1.000	740
Standby Mode	Magnetron heater	and control left on, all other services off
Duplexer	Circulator	

# AntennaAntenna TypePatch arrayBeam Width (nominal)5.2° horizontal, 25° verticalPolarizationHorizontal

A-1

2D 18" Radome Scanner Unit

Antenna	
Antenna Side lobes	Less than -22 dB
Rotation Rate	24 rpm (nominal)
Receiver	
IF Frequency	60 MHz (nominal)
Receiver Characteristic	Semi-log
Receiver Noise Figure	Less than 5 dB (including Low Noise Converter/Limiter & IF Receiver)
Receiver Bandwidth	12/3/0.7/0.5 MHz

## SL72 PLUS and SL72RC PLUS 7" Displays

## General

Approvals: CE - conform to FCC - conforms to	1999/5/EC, EN60945:1997 Part 80 (47CFR) and Part 2 (47CFR)
Size: 7"	223 x 204 x 75mm (8.8" x 8" x 3"), excluding bracket
Weight	1.2 kg(2.6lbs)
Mounting	Bracket with panel mount option
Power	External 10.7 - 44 V DC required Floating earth/fully isolated 10 W consumption with full backlighting
Environmental: Operating/Storage Temp. Range Humidity limit	Waterproof to CFR46; suitable for external mounting -10°C to +70°C up to 95% at 35°C non-condensing
Controls	11 defined keys, 4 soft keys and trackpad
Cursor	Context sensitive, provides range/bearing or lat/lon
Display Type:	7 " Film Super Twist Neumatic (FSTN) LCD, monochrome with 4 gray scales
Resolution:	320 x 240 (1/4 VGA)
Display Size 7"	7" diagonal - 143 mm x 111 mm
LCD Contrast	64 levels, selectable via soft keys.
Illumination	Screen and keypad: 0 to 100 in 1% steps
Languages	UK English, US English, Danish, French, German, Dutch, Ital- ian, Icelandic, Norwegian, Portuguese, Spanish, Swedish, Finnish
Connectors	13 pin scanner 3 pin SeaTalk input/output - SL72RC PLUS, SeaTalk input/out- put or NMEA ouput - SL72 PLUS 4 pin NMEA output - SL72RC PLUS only 7 pin power including 2 NMEA input channels
Interfaces	1 x SeaTalk, receive and transmit- SL72RC PLUS, SeaTalk receive & transmit or NMEA transmit - SL72 PLUS 1 x NMEA 0183, transmit - SL72RC PLUS only 2 x NMEA 0183, receive C-MAP cartridge reader - 2 slots - SL72RC PLUS only
Cursor Echo	Cursor Echo between radar and chart on split screen and/or separate displays connected via SeaTalk.
Man Overboard (MOB Mode)	Mark placed with course line; readout shows range, bearing, lat/lon of MOB and time elapsed since MOB.
Screen Functions	Full, half and quarter screens available dependent on function
Data Boxes	Up to six user selectable information boxes

## **Radar Features**

Range Scales (Range Rings)	0.125 (0.0625), 0.25 (0.125), 0.5 (0.125), 0.75 (0.25), 1.5 (0.25), 3 (0.5), 6 (1), 12 (2), 24 (4). Performance limited by the scanner position. Range scales can be customized
Range Ring Accuracy	Better than $+/-$ 1.5% of the max. range scale in use, or 22 m (72 ft.), whichever is the greatest.
Bearing Accuracy	+/-1°
Variable Range Markers	2xVRMs, readout nm, kyds, sm, km
Electronic Bearing Lines	2xEBLs, floating if required, resolution 1°
Bearing Scale	360° graduated at 10° intervals
Minimum Range	23 m (25 yds)
Range Discrimination	23 m (25 yds)
Presentation Modes	Head up, Course up or North up (selectable True or Magnetic) Relative or True Motion
Scanner Control	Interference rejection, standby/transmit modes, pulse selection, Tune, Rain, FTC, and Sea controls, with selection of manual or auto- matic control of gain, sea clutter and tune (Auto GST <sup>IM</sup> )
Magnetic Sensor	NMEA or Seatalk
Magnetic Sensor Waypoint Navigation	NMEA or Seatalk Lollipop symbol, WPT range, bearing, TTG or lat/lon readout
Magnetic Sensor Waypoint Navigation Marks	NMEA or Seatalk Lollipop symbol, WPT range, bearing, TTG or lat/lon readout 100 Mark database
Magnetic Sensor Waypoint Navigation Marks MARPA	NMEA or Seatalk         Lollipop symbol, WPT range, bearing, TTG or lat/lon readout         100 Mark database         Manual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectors
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source	NMEA or Seatalk         Lollipop symbol, WPT range, bearing, TTG or lat/lon readout         100 Mark database         Manual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectors         Auto (SeaTalk/NMEA/Internal algorithm) or Manual
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm	NMEA or Seatalk         Lollipop symbol, WPT range, bearing, TTG or lat/lon readout         100 Mark database         Manual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectors         Auto (SeaTalk/NMEA/Internal algorithm) or Manual         2 guard zones, selectable sensitivity level, audible alarm
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm Radar/Chart Synchroniza- tion - SL72RC PLUS only	NMEA or Seatalk         Lollipop symbol, WPT range, bearing, TTG or lat/lon readout         100 Mark database         Manual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectors         Auto (SeaTalk/NMEA/Internal algorithm) or Manual         2 guard zones, selectable sensitivity level, audible alarm         User selectable in split screen mode provided chart data available
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm Radar/Chart Synchroniza- tion - SL72RC PLUS only Zoom Mode	NMEA or SeatalkLollipop symbol, WPT range, bearing, TTG or lat/lon readout100 Mark databaseManual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectorsAuto (SeaTalk/NMEA/Internal algorithm) or Manual2 guard zones, selectable sensitivity level, audible alarmUser selectable in split screen mode provided chart data availablex2, from 0.25 nm to maximum range, in 1/4 window
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm Radar/Chart Synchroniza- tion - SL72RC PLUS only Zoom Mode Off Centre Function	NMEA or SeatalkLollipop symbol, WPT range, bearing, TTG or lat/lon readout100 Mark databaseManual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectorsAuto (SeaTalk/NMEA/Internal algorithm) or Manual2 guard zones, selectable sensitivity level, audible alarmUser selectable in split screen mode provided chart data availablex2, from 0.25 nm to maximum range, in 1/4 window66% of radius (except maximum range)
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm Radar/Chart Synchroniza- tion - SL72RC PLUS only Zoom Mode Off Centre Function Display Windows	NMEA or SeatalkLollipop symbol, WPT range, bearing, TTG or lat/lon readout100 Mark databaseManual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectorsAuto (SeaTalk/NMEA/Internal algorithm) or Manual2 guard zones, selectable sensitivity level, audible alarmUser selectable in split screen mode provided chart data availablex2, from 0.25 nm to maximum range, in 1/4 window66% of radius (except maximum range)Radar, Chart, CDI, BDI and Navdata
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm Radar/Chart Synchroniza- tion - SL72RC PLUS only Zoom Mode Off Centre Function Display Windows Wakes	NMEA or SeatalkLollipop symbol, WPT range, bearing, TTG or lat/lon readout100 Mark databaseManual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectorsAuto (SeaTalk/NMEA/Internal algorithm) or Manual2 guard zones, selectable sensitivity level, audible alarmUser selectable in split screen mode provided chart data availablex2, from 0.25 nm to maximum range, in 1/4 window66% of radius (except maximum range)Radar, Chart, CDI, BDI and NavdataShort, medium, long, off
Magnetic Sensor Waypoint Navigation Marks MARPA Variation Source Guard Zone Alarm Radar/Chart Synchroniza- tion - SL72RC PLUS only Zoom Mode Off Centre Function Display Windows Wakes Target Expansion	NMEA or SeatalkLollipop symbol, WPT range, bearing, TTG or lat/lon readout100 Mark databaseManual acquisition of 10 targets, automatic tracking, dangerous target alarms, safe zone, target history, true or relative vectorsAuto (SeaTalk/NMEA/Internal algorithm) or Manual2 guard zones, selectable sensitivity level, audible alarmUser selectable in split screen mode provided chart data availablex2, from 0.25 nm to maximum range, in 1/4 window66% of radius (except maximum range)Radar, Chart, CDI, BDI and NavdataShort, medium, long, offOperator selectable (0.5 nm to 3 nm ranges only)

SL72 PLUS SL72RC PLU Displays

S

Downloaded from <u>www.Manualslib.com</u> manuals search engine

## **Chartplotter Features - SL72RC PLUS only**

Cartography	C-MAP® NT micro cartridges available from C-MAP® Chart of the world built in
Display Windows	Chart, Radar, Data Log, BDI, CDI, Navdata
Chart Scaling	1/64 nm (if cartographic data is available) to 4000 nm
Presentation Modes	North up (selectable True or Magnetic) Head up or Course up
Waypoints	1000 waypoints entered via cursor, lat/lon, range and bearing from present position or at vessels position. 16 character name can be assigned Additional storage available on User Cartridges
Waypoint Transfer	Current route via Seatalk, NMEA
Routes	A route plan may contain up to 50 waypoints. Up to 20 routes can be stored in the units internal memory Additional storage available on User Cartridges SmartRoute to create a route from a track history
Track History	5 tracks with up to 750 points in each can be stored in the units internal memory Additional storage available on User Cartridges
Alarms	Programmable arrival, cross track error, anchor drift, position fix/ data loss warning, countdown timer and alarm clock
Navigation Information	Own ships position in Lat/Lon, XTE, TTG and SOG/COG selectable. Mileage scale ruler. Bearing and distance to waypoint. Bearing and distance to cursor, SeaTalk data (see 'interfacing' section)
Variation Source	Auto (SeaTalk/NMEA/Internal algorithm) or Manual
Chart/Radar Synchroniza- tion	User selectable in split screen mode provided radar/chart data available

## Interfacing

SeaTalk Input	Depth, Speed Over Ground & Course Over Ground, Position, Waypoint number, range, bearing and time to go, Speed through water, Time, Cross Track Error, Heading, Wind, Date, Log/Trip, Pilot Status, Temperature, Man Overboard, and cursor position
NMEA Input	NMEA 0183 (GLL, GGA, GLC, GTD, VTG, BWC, BWR, RMA, RMB, RMC, XTE, VHW, HDG, HDM, HDT, DBT, DPT, APB,VLW, MWV, MTW,WPL, RTE and ZDA)
SeaTalk Output	Cursor data, Guard zone alarm and Navigational data bridged from NMEA
NMEA Output (User selectable)	APB, BWC, BWR,DBT, DPT,GGA, GLL, MTW, RMA, RMB, RMC, RSD, TTM, VLW, VHW, VTG, WPL, ZDA



# Appendix B: Using the Auxiliary Junction Box

The SeaTalk Auxiliary Junction Box is used to connect SeaTalk GPS and Differential beacon receivers to your display.

**Note:** With the exception of the Raystar 114, when you use the following Differential Beacon Receiver configurations, the receiver must be set to AUTO MODE in the GPS Set-Up page. Manual selections will not be accepted. Refer to Chapter 6 for details.

The recommended method of providing position, course over ground and speed over ground information to the displays is by connection to a SeaTalk GPS. The SL72RC PLUS chartplotter displays are supplied with an Auxiliary Junction Box, whose main purpose is to make this connection easier. The junction box has two flying leads, one with a SeaTalk plug for connection to the display and the other lead is for connection to a 12V power supply (the display does **not** provide power for the GPS).

The following sections detail the connections to the Auxiliary Junction Box for several different types of GPS, including a beacon receiver if installed. Except for Raystar 114, the differential beacon receivers used are Raymarine NRD-2A, Apelco BR101 and the Autohelm Beacon Receiver.

The connections detailed in the following sections ensure that the GPS will always operate in SeaTalk mode. Note that the Raystar 112LP must be the SeaTalk version.

B-1
## Raystar 112, 105, Apelco 182 and 182XT

In order to connect your GPS to your display, you must first cut off the 6-pin connector and strip back the insulation on all the wires. Connect to the Auxiliary Junction Box as shown in the first illustration below.

To connect your Differential Beacon Receiver, you must cut off the 5-pin connector (Raytheon and Apelco versions), strip back the insulation on all the wires and connect to the Auxiliary Junction Box as shown in the second illustration below.

## CAUTION:



# Autohelm GPS, Z260 and Z273

To connect your GPS to your display connect the wires as shown in the first illustration below.

To connect your Differential Beacon Receiver, you must cut off the 5-pin connector (Raytheon and Apelco versions) strip back the insulation on all the wires and connect to the Auxiliary Junction Box as shown in the second illustration below.

## CAUTION:



Raystar 112, 105, Apelco 182 and 182XT

## **Raystar 112LP (SeaTalk version)**

To connect your Raystar 112LP to your display, refer to the first illustration below or follow the instructions in *Chapter 8*.

To connect the Raystar 112LP and your Differential Beacon Receiver, cut off the 5-pin connector and strip back the red, black and green wires. Remove the sleeve from the end of the Raystar 112LP cable to expose the green and brown wires, then connect to the Auxiliary Junction Box as shown in the second illustration below.

## **CAUTION:**



# **Raystar 114 Combined GPS and Differential Beacon Receiver**

To connect your Raystar 114 Combined GPS and Differential Beacon Receiver to your display, cut off the 5-pin connector, strip back the insulation on all the wires and connect to the Auxiliary Junction Box as shown in the illustration below.

## CAUTION:

Ensure the correct polarity of the 12 V supply before applying display or SeaTalk power. It is recommended that a multimeter is used to check the connections.

**Note:** You can use the GPS Set-Up page to manually tune the Raystar 114. Refer to Chapter 6 for details.



**Raystar 120 WAAS Satellite Differential Receiver** 

To connect your Raystar 120 WAAS Satellite Differential Receiver to your display, connect to the Auxiliary Junction Box as shown in the illustration below. Optional connections to RTCM are also shown. Note that the green wire is not used.

### CAUTION:



# Appendix C: C-MAP Chart Card Features -SL72RC PLUS only

The C\_MAP chart cards display cartographic features which are derived from a library of symbols. The library includes a set of 16 x 16 pixel bitmaps which provide realistically shaped icons for many chart objects. However, these complex icons can overlap and clutter the display at some scales, so it possible for the user to select smaller, simple icons. Some chart objects are represented by text; in such cases conventional abbreviated text is used, for example, M - mud, R - rock, Wk - wreck

The chartplotter set up menu provides the sub-menu CUSTOMISE CHART, which lets you determine how chart features are displayed. You can set the icon display of many features to custom; you then use the CUSTOM soft key to switch the customized icons off/on. The factory default for the CUSTOM options is on.

Menu Option	<b>Chart Features</b>		
CHART TEXT	Names		
CHART BOUNDARIES	Chart Boundaries		
SPOT SOUNDINGS	Spot Soundings		
DEPTH SHADING LIMIT	Reference Depth		
DEPTH CONTOURS	Depths (Bathymetric I Depth Labels	Lines)	
DEPTH CONTOUR DIS- PLAY	Depth Contour Range		
NAV MARKS	Lights: Light; Light moire' effect; Light float; Light vessel	Buoys and Beacons: Buoy, cardinal Buoy, installation Buoy, isolated danger Buoy, lateral Buoy, safe water Buoy, special purpose Buoy, generic Beacon, cardinal Beacon, isolated dan- ger Beacon, lateral Beacon, safe water Beacon, special pur- pose Beacon, generic	Signals Anchor Cairn Chain/Wire Fog signal Radar reflector Top mark Nav aid, generic Extended nav- aid, generic Radar station Radar transponder bea- con Radio station

The chart features controlled from the Customize Chart menu are grouped as detailed below, some groups are sub-divided into categories

Menu Option	<b>Chart Features</b>	
LIGHT SECTORS	Light Sectors	
CAUTION & ROUTING DATA	Caution Areas Caution area Fishing facility Marine farm/cul- ture Cable, submarine Cable area Offshore prod'n area Pipeline Pipeline area Anchor berth Anchorage area Cargo tranship- ment area Contiguous zone Continental shelf area Custom zone Dumping ground Exclusive economic zone Fishery zone Fishery zone Fishery zone Fishery area Harbour area (administrative) Incineration area Log pond National territorial area Sea area Spoil ground Straight territorial sea baseline Submarine transit lane Territorial sea area Restricted area Sea Plane landing area Military practice area	Tracks and Routes Deep water route part Deep water route cen- terline Fairway Ferry route Navigation line Precautionary area Radar line Radar range Radio calling Recommended route centerline Recommended track Recommended traffic lane part Traffic separation line Traffic separation scheme boundary Traffic separation scheme crossing Traffic separation scheme lane part Traffic separation scheme roundabout Traffic separation zone Two-way route part
MARINE FEATURES	Tideways & Cur- rents	Seabed bottom Sand waves Seabed area

C-MAP Chart Card Features - SL72RC PLUS only

Menu Option	<b>Chart Features</b>		
LAND FEATURES	Natural Features Coastline Dune Hill Land elevation Land region Land Salt pan Slope topline Tree Vegetation area Natural Features - Rivers Canal Canal bank Rapids River River bank Waterfall Lake Lake shore	Cultural Features Airport area Built-up area Railway Road crossing Road part Runway Sloping ground Square Cable, overhead Fence Pipeline, overhead Pylon Telepheric Tunnel entrance	Building, religious Building, single Cemetery Fortified Structure Siloway route part Tank Chimney Dish aerial Flagstaff/flagpole Flarestack Mast Monument Radar dome plane land- ing area Tower Windmill Windmotor
ICON DISPLAY	Complex (detailed) o	bject/Simple object	

hart Card - SL72RC

LUS only

Menu option	<b>Chart features</b>		
PORTS	Ports: Berthing facility Causeway Checkpoint Crane Dam Distance mark Dock area Dry dock Dyke area Dyke crown Floating dock Gate Gridiron Harbour facility Hulk Landing place Landing stairs Lock basin Oil barrier Pile Pontoon Ramp Shoreline construction Slipway Weir Small craft facility	Services Coastguardstation Pilot boarding place Rescue station Signal station, traf- fic Signal station, warning	Port Information Port area Harbour master Coast Guard Police Customs Health emergency Post office Yacht club Boat yard Accessories Electrical/electronic repairs Engine repairs Sailmaker Fishing/diving gear, SCUBA Hotel/Inn Restaurant Bank/Exchange office Pharmacy Port/Marina Slipway Boat hoist Crane Fuel station Water Electricity Showers Launderette Public toilets Post box Public telephone Refuse bin Visitor's berth Chandler Provisions Bottle gas Car Parking Parking for boat and trai ers Caravan site Camping site Sewerage pump-out sta- tion

The following chart features are always displayed:

CARTOGRAPHIC	Line, generic
OBJECTS	Area, generic
NATURAL FEATURES	Land area Bridge

Menu option	Chart features
ROCKS	Underwater Rock
WRECKS	Wrecks
DEPTHS 1	Depth area
DEPTHS 2	Dredged area
DEPTHS 3	Intertidal area
PORTS	Mooring/Warping facility
CAUTION AREAS	Fish haven
OFFSHORE INSTALLA- TIONS	Diffuser Obstruction Production installation Offshore platform
AREAS, LIMITS	No data area
CARTOGRAPHIC OBJECTS	Incomplete survey area
NATURAL FEATURES (Ice)	lce area Pingo
COMPOSITE OBJECTS	Airport
	Anchorage Channel edge Deep water route Defined water Harbour Range system Lighthouse Mooring trot Navigation mark, afloat Navigation mark, fixed in point Traffic Separation Scheme Sys- tem
CARTOGRAPHIC AREAS	Cartographic II25 area

The following	chart features	are always	displayed
The following	chart reatures	alcalways	uispiayeu.

C-6

# Appendix D:SeaTalk and NMEA Data Received and Transmitted

The following table defines the data received on the NMEA/SeaTalk ports. Data sources are listed in order of priority except where indicated.

Data Received	Source
Position (LAT/LON)	SeaTalk, GGA, RMC, RMA, GLL
Position (Loran C TD's)	GLC, RMA, GTD
Speed and Course Over Ground	SeaTalk, RMC, RMA, VTG
Waypoint Data	SeaTalk, RMB, APB, BWC, BWR, RMB, XTE
Depth	SeaTalk, DBT, DPT
Apparent Wind Angle and Speed	SeaTalk, MWV (relative)
Boat Speed Through Water	SeaTalk, VHW
Total Log and Trip Log	SeaTalk, VLW
Water Temperature	SeaTalk, MTW
Average Boat Speed through the Water	SeaTalk only
Heading	SeaTalk, HDG, HDM, HDT, VHW
Locked Heading	SeaTalk only (Autopilot / Steering Compass)
Magnetic Variation	SeaTalk, RMC, RMA, HDG
Rudder Angle (not displayed)	SeaTalk only
Time (No priority)	SeaTalk, ZDA, GGA, RMC, GLL, BWC, BWR
Date	SeaTalk, ZDA, RMC
MOB data	SeaTalk only
Autopilot Status (Standby / Auto / Vane / Track)	SeaTalk only
Cursor Range and Bearing (from Chartplotter) Cursor Range and Bearing (from Radar)	SeaTalk only SeaTalk, RSD
Global Alarms - Watch alarm, Wind alarm, Autopilot alarms, Depth alarms.	SeaTalk Only
Waypoint arrival	SeaTalk, RMB, APB
Waypoint/Route Transfer	SeaTalk, WPL, RTE

\* If Magnetic Heading is not available, the True Heading and Variation (if available) are used to generate the magnetic heading.

The SL72 PLUS radar display unit transmits the following data, if available, on SeaTalk and NMEA:

Data Output	SeaTalk	NMEA Out
Position (LAT/LON)	В	_
Position (Loran C TD's)	_	_
Speed Over Ground and Course Over Ground	В	_
Waypoint Data	В	—
Depth	В	_
Apparent Wind Angle and Speed	В	_
Boat Speed Through Water	В	_
Total Log and Trip Log	В	
Water Temperature	В	_
Heading	В	_
Magnetic Variation	<b>v</b>	_
Time	В	_
Date	В	—
MOB data	<b>v</b>	—
Cursor Range & Bearing	<b>v</b>	RSD
EBL/VRM Data	—	RSD
Heading mode	_	RSD
Radar display range	<b>v</b>	RSD
Radar Tracked targets		TTM
Global Alarm	<b>v</b>	_

B Bridged from NMEA if selected in the System Set Up menu.

Data Output	SeaTalk	NMEA Out
Position (LAT/LON)	~	GGA, GLL, RMC, RMA
Position (Loran C TD's)	~	RMA
Speed Over Ground and Course Over Ground	~	RMC, VTG, RMA
Waypoint Data	~	RMB, APB, BWC, BWR
Depth	~	_
Apparent Wind Angle and Speed	~	_
Boat Speed Through Water	~	_
Total Log and Trip Log	~	_
Water Temperature	~	_
Heading	~	VHW <sup>.</sup>
Magnetic Variation	~	RMA, RMC
Time	~	ZDA
Date	~	ZDA
MOB data	~	_
Cursor Range & Bearing	~	RSD <sup>2</sup>
EBL/VRM Data	_	RSD <sup>2</sup>
Heading mode	_	RSD <sup>2</sup>
Radar display range	~	RSD <sup>2</sup>
Radar Tracked targets	_	TTM
Waypoint/Route Transfer		WPL, RTE
Global Alarm Waypoint Arrival Alarm	SeaTalk	— APB, RMB

The SL72RC PLUS combined radar/chartplotter display unit transmits the following data, if available, on SeaTalk:

\*4 Bridged from NMEA if selected in the System Set Up menu.

# **Appendix E: Abbreviations**

A	Amp
ANSI	American National Standards Institute
AWG	American Wire Gauge
BDI	Bearing and Distance Indicator
Brg	Bearing
CCFL	Cold Cathode Fluorescent Lamp
CD	Course Deviation Indicator
CFR	Code of Federal Regulations
CMG	Course Made Good
COG	Course Over Ground
CRT	Cathode Ray Tube
CTR	Center
dB	deciBels
DC	Direct Current
DMG	Distance Made Good
DR	Dead Reckoning
EBL	Electronic Bearing Line
EMC	Electro Magnetic Compatibility
ETA	Estimated Time of Arrival
FCC	Federal Communication Commission
FLT	Float - floating EBL/VRM
ft	feet
FTC	Fast Time Constant
GPS	Global Positioning System
dGPS	differential Global Positioning System
GRD	Guard Zone
GHz	Giga Hertz
HDG	Heading
HSB	High Speed Bus
Hz	Hertz
MHz	Mega Hertz
IEEE in, "	Institute of Electrical & Electronic Engineers inch
Kg	kilogram
kW	kilo Watt

Abbreviations

Abbreviations

lat	latitude
lbs	pounds
LCD	Liquid Crystal Display
lon	longitude
M	Magnetic
m	meters
MARPA	Mini Automatic Radar Plotting Aid
MBS	Main Bang Suppression
mm	millimeter
MOB	Man OverBoard
MRK	Mark
nm	nautical mile
NMEA	National Marine Electronics Association
POS	Position (of vessel)
RF	Radio Frequency
Rng	Range
rpm	Revolutions Per Minute
SSB	Single Side Band
SHM	Ships Heading Marker
SOG	Speed Over Ground
STC	Sensitivity Time Control
T	True
TFT	Thin Film Transistor
TTG	Time To Go
V	Volts
VHF	Very High Frequency
VMG	Velocity Made Good
VRM	Variable Range Marker
WPT	Waypoint
XTE	Cross Track Error
yds	yards
ZMB	Zoom Box

# Index

#### A

Accessories 8.4 Adding a Waypoint to a Route 5.18, 5.28 Adjusting Gain, Sea Clutter and Rain Clutter 3.7 Advanced Set Up 7.2, 7.15 **Display Timing 7.15** STC Preset 7.16 Tune Preset 7.16 Alarm Clock Alarm 6.4 Alarms 3.1, 3.22 Alarm Clock 6.4 Anchor 6.4 Arrival 5.32, 6.4 Controlling Guard Zones 3.19, 3.22 Countdown Timer 6.4 External 6.4 MOB 4.5, 6.6 Off Track 6.4 Setting 6.1, 6.5 ALARMS Key 1.14, 3.19, 3.20, 6.4, 6.5 Alignment Bearing 7.12, 7.14, 8.26 Anchor Alarm 6.4 Antenna Size 7.12, 7.14 Apelco 182 and 182XT GPS B.2 Arrival Alarm 5.32, 6.4 Autohelm GPS, Z260 and Z273 B.3 В BDI 1.5 Window Options 1.5, 2.10 Bearing Alignment 7.12, 7.14, 8.26 Bearing Mode 7.4, 7.6 Blind Sectors 3.6 Bridge NMEA Heading 7.5, 7.9, 8.35 Cable Runs 8.10 **Installation Considerations 8.2** Cables Extension 8.4, 8.12, 8.13 Inter-unit 8.4, 8.12, 8.13, 8.15 Power 8.11 Rejoining 8.10 SeaTalk 8.4 Cancel MOB 4.6, 6.7 CDI 1.5 Window Options 1.5, 2.10 Center Control (Radar) 2.17 Center the Chart 1.9, 2.19 Changing the Heading Mode 4.1 Changing the Radar Range 3.2 Changing the Targets Display 3.11

Chart Center 1.9, 2.19 Data 4.1, 5.2 Nearest 5.7 Object Information 5.4, 7.17, 7.19 Port 5.4, 5.5 Source 5.4 Tide 5.4, 5.5 Mode 1.5 Full Screen 2.7 Orientation 7.17, 7.18 Course Up 7.18 Head Up 7.18 North Up 7.18 Scale 2.19, 2.21, 5.2, 6.6 Simulator 2.1, 2.5, 7.11 Chart Card 1.9 Object Information 5.4, 7.17, 7.19 Chart Grid On and Off 2.13 Chartplotter Control Functions 2.19 **Display Options 1.10** Features 1.4, 1.9, A.5 Functions 1.11 Set Up 7.2, 7.17 Custom Options 1.10, 2.15 Radar/Chart Synch 1.9, 2.20, 7.17, 7.19 CLEAR Key 1.14 Clearing a Track 5.38, 5.40 Marks 7.12, 7.13 the Current Route 5.18, 5.23 Wakes 3.12 COG (Course Over Ground) 6.1 Data Box 7.4 Vector 7.17, 7.19 Combined Display Operating Modes 1.4 Combined Radar/Chartplotter Identifying Objects 3.1 Identifying Objects with Cursor Echo 4.6, 6.7 Switching Control 2.9 Connections 8.20 Display Unit 8.21 NMEA Input 8.21, 8.22, 8.30, 8.32 NMEA Output 8.21, 8.34 Power 8.20, 8.23 Power & NMEA In 8.21, 8.22, 8.32 Scanner 8.15, 8.21, 8.22 SeaTalk 8.21, 8.30 Context-sensitive Cursor 1.13, 2.19 Contrast Adjustment 2.6 **Control Functions** Chartplotter 2.19

Radar 2.16

Controlling Guard Zone Alarms 3.19, 3.22 Conventions Used 2.1 Countdown Timer Alarm 6.4 Course Up 4.2, 7.18 Creating a Route 5.18 by Placing Waypoints 5.19 from a Track 5.38, 5.42 Using the Waypoint List 5.20 Cross Track Error - See XTE Current Route 5.18 Altering 5.30 Clearing 5.18, 5.23 Cursor 1.12 Context-sensitive 1.13, 2.19 Data Box 2.13 Goto 5.30, 5.34 Readout 7.4, 7.7 Reference 7.4, 7.6 Cursor Echo 3.1, 4.1, 6.1, 6.7, 7.5, 7.9 Chart 4.6, 6.7, 7.9 Local 4.6, 6.7, 7.10 Radar 4.6, 6.7, 7.9 SeaTalk 4.6, 6.7, 7.10 **Custom Options** Chartplotter 1.10, 2.15 Customizing the Chart Display 7.17 the Screen Presentation Options 2.13 D Data Box 2.14, 7.4, 7.6 COG 7.4 Cursor 2.13 Date 7.4 Depth 7.4 Group of Six 2.14 On/Off 2.14 Heading 7.4 List of 7.4 Log/Trip 7.4 MOB 4.5, 6.6 Moving 2.14, 3.18 On/Off 3.18 Pilot 7.4

MOB 4.5, 6.6 Moving 2.14, 3.18 On/Off 3.18 Pilot 7.4 Position 7.4 Ruler 6.2, 6.3 SOG 7.4 Speed 7.4 Temperature 7.4 Tide Set/Drift 7.4 Time 7.4 VMG 7.4 VRM/EBL 3.18 Waypoint 7.4 Wind 7.4 XTE 7.4 Data Conversion 8.35 Data Display 5.25 Chart Object 5.4, 7.17, 7.19 Nearest 5.7 Port 5.4, 5.5 Source 5.4 Tide 5.4, 5.5 Route 5.18, 5.24 Data from other Equipment 4.1, 6.1, 6.6, 8.35 Chart 4.1 COG 6.1 Heading 1.5, 4.1, 4.5, 6.1, 6.6, 7.9, 8.2, 8.30 Navigation Data 4.1 NMEA 4.1, 4.4, 6.1, 8.32 Position 1.5, 4.1, 4.5, 6.1, 6.6, 8.30 Radar 6.1 SeaTalk 4.1, 4.4, 4.6, 6.1, 8.30 Speed 4.5, 6.6, 8.30 Waypoint 4.1, 8.30 Data Log Mode 1.5, 6.1, 6.10 Full Screen 2.7 Data Selection 7.5, 7.9 SeaTalk-NMEA 8.31, 8.34 Database List 1.12, 1.16 Route 5.15, 5.18, 5.22, 5.25 Retrieving 5.23 Track 5.40 Waypoint 5.8, 5.9, 5.13, 5.14, 5.19, 5.33 Date Data Box 7.4 Date Format 7.5, 7.10 Datum Selection 7.17, 7.19 Day/Night 7.4, 7.7 Dedicated Keys 1.3, 1.12, 1.14 ALARMS 3.19, 3.20, 6.4, 6.5 CLEAR 1.14 DISPLAY 2.7, 2.8, 2.16, 6.10 **GAIN 3.7** MARKS 4.4, 4.5, 5.9, 5.12, 5.36, 5.37, 6.6 MENU 2.5, 5.38, 6.8, 7.1, 7.2 MULTI 3.7, 3.22 POWER 2.2, 2.3, 2.4 RANGE 2.21, 2.22, 3.2, 5.2 VRM/EBL 3.13, 3.14, 6.1, 6.3 Deleting a Guard Zone 3.19, 3.21 a Mark 4.5 a VRM/EBL 3.16 Deleting - See also Erasing Depth Data Box 7.4 Determining Radar Range 3.3 D-GPS Set Up Beacon Frequency 6.9 Beacon ID 6.9 Bit Rate 6.9 Differential Age 6.9 Signal Strength & Signal to Noise Ratio 6.9

Display Operating Modes 1.4 Selecting 2.7 Display Features 1.4, 1.7 DISPLAY Key 1.14, 2.7, 2.8, 2.16, 6.10 **Display Options** Chartplotter 1.10 Display Timing Adjustment 8.27 Display Timing Set Up 7.15 Display Unit 1.i, 1.3 Connections 8.21 Console Mounting 8.18 Contrast Adjustment 2.6 Grounding 8.20 Lighting Adjustment 2.6 Location 8.9 Mounting 8.18 Specification A.3 Switching Off 2.4 Displaying a Waypoint 2.14 Bearing Data (EBLs) 7.12 Chart Data 5.3 Waypoint Data 5.8, 5.12, 5.25 Displaying the Radar and Synchronising Radar & Chart 2.30 Е EBL (Electronic Bearing Lines) 3.1, 3.13 Display 7.12 Echoes 3.4 False 3.5 Indirect 3.6 Multiple 3.6 Editing a Route 5.18, 5.27 Using the ST60/80 Navigator Keypad 5.17 Waypoint Details 5.8, 5.13 Electromagnetic Energy 1.i EMC Conformance 1.iii, 8.28 Servicing and Safety Guidelines 9.1 ENTER Key 1.14 Erasing a Route 5.18, 5.26 a Waypoint 5.8, 5.14 Expansion (Radar Targets) 3.5, 3.11, 3.12 Extension Cable 8.4, 8.12, 8.13 External Alarms 6.4 F Factory Reset 9.3 False Echoes 3.4, 3.5 Features 1.4 Chartplotter 1.4, 1.9, A.5 Display 1.7 Radar 1.4, 1.6, A.4

Floating VRM/EBLs 3.14, 3.16 Follow a Route 5.30 Route Options 5.30, 5.32 Stop 5.30, 5.34 FTC Control 3.5, 3.7, 3.10 Functions Chartplotter 1.11 Radar 1.8 G Gain **Recommendations 3.8** GAIN Key 1.14, 3.7 Goto a Target 5.30, 5.33 a Waypoint 5.30, 5.33 Cursor 5.30, 5.34 Stop 5.30, 5.34 GPS Positional Accuracy 6.8 Restart GPS 6.9 Set Up 6.1, 6.8 GPS SOG/COG Filter 7.5, 7.10 Grounding 8.20 Guard Zones 3.1, 3.19 Controlling Alarms 3.19, 3.22 Deleting 3.19, 3.21 Moving 3.19, 3.21 Placing 3.19, 3.20 Reshaping 3.19, 3.21 н Half Screen Windows 1.4, 2.7 Selecting 2.8 Head Up 4.2, 7.18 Heading 7.5, 8.35 Heading Data 1.5, 4.1, 4.5, 6.1, 6.6, 7.9, 8.2, 8.30 Heading Data Box 7.4 Heading Mode 4.2, 7.18 Changing 4.1 Course Up 4.2 Effect on VRM/EBLs 4.3 Head Up 4.2 North Up 4.2 Selecting 4.3 Heading Vector 7.17, 7.19 Help 7.4, 7.7 Help from Raytheon Europe 9.6 US 9.5 High Voltage 1.i L Identifying False Echoes 3.5 Identifying Objects 3.1 with Cursor Echo 4.6, 6.7 Indirect Echoes 3.6

Find Ship 2.19, 2.20

Installation Cable Runs 8.2, 8.10 EMC Conformance 8.28 EMC Guidelines 8.2 Integrated System 8.29 Location 8.2, 8.5, 8.9 Integrated System 1.3, 1.5, 5.18 Definition 1.2 Installation 8.29 Installation Checks 8.36 Switching Control Between Radar and Chart 2.9 Interference Rejection 3.5, 3.11, 3.12 Interpreting and Adjusting the Radar Picture 3.1, 3.4 Inter-unit Cable 8.4, 8.12, 8.13, 8.15 J Junction Box for External Instruments 8.33 Κ Key Beep 7.4, 7.7 Keys Dedicated 1.3, 1.12, 1.14 Soft 1.3, 1.12, 1.14, 7.4, 7.7 L Language 7.6, 7.10 Lighting Adjustment 2.6 Local Cursor Echo 4.6, 6.7, 7.10 Location Display Unit 8.9 Scanner Unit 8.5 Log/Trip Data Box 7.4 Loran TDs 5.11 Μ Magnetron 2.2 Maintenance 9.1 Make and Follow a Route Scenario 2.26 Managing Tracks 5.38 Marks 4.1, 4.4, 5.8 Clearing 7.12 Deleting 4.5 Moving 4.5 Options 7.12, 7.13 Placing 4.4 Symbol 7.12, 7.13 MARKS Key 1.14, 4.4, 4.5, 5.9, 5.12, 5.36, 5.37, 6.6 Master Display Definition 1.2 Measuring Distances Using the VRM/EBL Key 6.1, 6.2 Measuring Range and Bearing 3.1, 3.14 Floats 3.14, 3.16 MENU Key 1.14, 2.5, 5.38, 6.8, 7.1, 7.2 Menu Timeout 7.4, 7.7

MOB 4.1, 6.1 Alarm 4.5, 6.6 Cancel 4.6, 6.7 Data Box 4.5, 6.6 Data Selection 7.4, 7.7 Symbol 4.5, 6.6 Waypoint 4.5, 6.6 Modes Chart 1.5, 2.7 Data Log 1.5, 2.7, 6.1, 6.10 Full Screen 2.7 Radar 1.5, 2.7 Mounting the Display Unit 8.18 Console Mounting 8.18 Mounting the Scanner 8.14 on Power Boats 8.7 on Sailboats 8.7 Moving a Data Box 2.14, 3.18 a Floating EBL 3.17 a Guard Zone 3.19, 3.21 a Mark 4.5 a VRM/EBL 3.15 a Waypoint 5.9, 5.14, 5.18, 5.27 Cursor 1.13 MULTI Key 1.14, 3.7, 3.22 Multiple Echoes 3.4, 3.6 Ν Naming a Route 5.18, 5.22, 5.26 a Track 5.40 a Waypoint 5.8, 5.13, 5.17 Using the ST60/80 Navigator Keypad 5.17 Nav Data 1.5 from other Equipment 4.1 Window Options 2.10 Navigation Aid 1.i Navigational Echoes 3.4 Navigator Keypad 5.9, 5.15 NMEA 1.3, 1.5 Data 4.1, 4.4, 6.1, 8.32 Data Selection 7.9, 8.31, 8.34 Heading 7.5, 7.9, 8.35 Input Connection 8.21, 8.22, 8.30, 8.32 Output Connection 8.21, 8.34 NMEA Out Set Up 7.5, 7.9 North Up 4.2, 7.18 0 Object Information - Chart 7.17, 7.19 Displaying 5.4 Off Track Alarm 6.4 Offsetting the Center 1.6, 1.9 Range Rings 2.18

**Operating Controls** Cursor 1.12 Database List 1.12, 1.16 Dedicated Keys 1.3, 1.12, 1.14 Pop-up Menus 1.12, 1.15 Soft Keys 1.3, 1.12, 1.14, 7.4, 7.7 Trackpad 1.3, 1.12, 2.19 Operating Modes 1.4 Chart 2.7 Combined Display 1.4 Data Log 2.7, 6.1, 6.10 Plotter 2.22, 7.17, 7.18 Radar 2.7 Selecting 2.7 Switching Control 2.9 Orientation - Chart 7.17, 7.18 Ρ Picture Reset 9.3 Pilot Data Box 7.4 Place and Goto a Waypoint Scenario 2.24 Placing a Guard Zone 3.19, 3.20 a Mark 4.4 a VRM/EBL 3.14 a Waypoint 5.8, 5.9, 5.19 Plotter Mode 2.22, 7.17, 7.18 Pop-up Menus 1.12, 1.15 Port Data 5.4, 5.5 Position a Waypoint 5.8, 5.13 Position Data 1.5, 4.1, 4.5, 6.1, 6.6, 8.30 Position Data Box 7.4 Position Offset 7.17, 7.20 Positional Accuracy 6.8 Power Cable 8.11 Connection 8.20, 8.23 for External Equipment 8.21, 8.29 Power & NMEA Input Connection 8.21, 8.22, 8.32 POWER Key 1.14, 2.2, 2.3, 2.4 Power-on Reset 9.3 Power-on Sequence 2.2, 2.4 Chart Mode 2.4 Radar Mode 2.2 R Radar 1.3 Control Functions 2.16 Features 1.4, 1.6, A.4 Functions 1.8 Mode 1.5 Full Screen 2.7 Options 1.6

Set Up 7.2 Simulator 2.1, 2.5 System Alignment 8.24 System Test 8.24 Typical System Diagram 8.1 Window Options 2.10 Radar Display Center Control 2.17 Range Rings 2.18 Radar Set Up 7.12 Radar/Chart Synchronization 1.9, 2.20, 7.17, 7.19 Rain Control 3.5, 3.10 Distant Rain 3.10 Range Control 3.1 Determining 3.3 Scale Custom 3.2, 7.12, 7.13 RANGE Key 1.14, 2.21, 2.22, 3.2, 5.2 Range Rings 2.18, 3.2, 3.3 On and Off 2.13 Raystar 112 and 105 GPS B.2 Raystar 112LP GPS B.4 Raystar 114 GPS B.5 Raystar 120 WAAS GPS Receiver B.6 Rejoining Cables 8.10 Remote Cursor Echo Chart 4.6, 6.7, 7.9 Radar 4.6, 6.7, 7.9 Removing a Waypoint from a Route 5.18, 5.28 Reshaping a Guard Zone 3.19 Restart GPS 6.9 XTE 5.30, 5.33 Retrieving a Route 5.18, 5.23 Returning to the Full-Screen Display 2.9 Reverse a Route 5.27, 5.29 Review Your Passage Plan Scenario 2.28 Route Clearing 5.18 Creating 5.18 Creating from a Track 5.38, 5.42 Current 5.18 Data Display 5.18, 5.24 Database List 5.15, 5.18, 5.22, 5.23, 5.25 Editing 5.18, 5.27 Using the ST60/80 Navigator Keypad 5.17Erasing 5.18, 5.26 Follow 5.30 Loading from a User Cartridge 5.35 Naming 5.18, 5.22, 5.26 NMEA Transfer 5.35 Retrieving 5.18, 5.23

Range

Changing 3.2

Custom Scale 7.12, 7.13

Reversing 5.27, 5.29 Saving 5.18 Saving to a User Cartridge 5.35 Transferring 5.35 Route Leg 5.18 Data Display 5.24 Routine Checks 9.1 Ruler Data Box 6.2, 6.3 S Safety 1.i, 5.1 Electromagnetic Energy 1.i EMC Guidelines 8.2, 9.1 High Voltage 1.i Navigation Aid 1.i Saving a Route 5.18 a Track 5.40 Scale Chart 2.19, 2.21, 5.2, 6.6 Radar Range 3.2 Custom 7.12, 7.13 Scanner 1.i, 1.3 Connection 8.15, 8.21, 8.22 Location 8.5 Modes Scanner Off 2.2, 2.3 Standby 1.3, 2.2, 2.3 Timed Transmit 1.3, 7.12, 7.13 Transmit 1.3, 2.2 Mounting 8.14 on Power Boats 8.7 on Sailboats 8.7 Specification A.1 Switching Off 2.4 Transmission Check 8.25 Scanner Off Mode 2.2, 2.3 Scenarios Displaying the Radar and Synchronising Radar & Chart 2.30 Make & Follow a Route 2.26 Place & Goto a Waypoint 2.24 Review Your Passage Plan 2.28 Sea Clutter Control 3.5 **Recommendations 3.9** SeaTalk 1.3, 1.5 Cables 8.4 Connection 8.21, 8.30 Cursor Echo 7.9 Data 4.1, 4.4, 4.5, 4.6, 6.1, 8.30 Data Selection 7.9, 8.31, 8.34 Selecting a Half Screen Window 2.8 a Waypoint 5.8, 5.12 the Heading Mode 4.3 the Operating Mode 2.7

Send on HSB 7.12, 7.14 Servicing EMC Guidelines 9.1 Set Up Options 2.15 Set Up Parameters GPS Set Up 6.9 Seting Up a GPS 6.9 Setting Alarms and Timers 6.1, 6.5 Setting Up a GPS 6.1, 6.8, 6.9 Advanced Radar Options 7.2, 7.15 Chart Parameters 7.2, 7.17 GPS Set Up Restart GPS 6.9 Radar Parameters 7.2, 7.12 System Parameters 7.2, 7.4 Tracks 5.38, 5.39 Shadows 3.6 SHM (Ship's Heading Marker) 3.19 Head Up Mode 2.18 SHM (Ship's Heading Marker) 1.6 Side Lobes 3.5 Simulator 7.6, 7.11 Chart 2.1, 2.5 Radar 2.1, 2.5 SmartRoute 5.42 Soft Key Labels 7.7 Soft Keys 1.3, 1.12, 1.14, 7.4, 7.7 SOG (Speed Over Ground) Data Box 7.4 Specification 18" Radome Scanner A.1 Display A.3 Speed Data 4.5, 6.6, 8.30 Speed Data Box 7.4 ST60/80 Navigator Keypad 5.9, 5.15, 5.17 Standby Mode 1.3, 2.2, 2.3 Status Bar 1.6, 1.7, 1.9 STC Preset 7.16 Stop Follow 5.30, 5.34 Goto 5.30, 5.34 Track - See Clear Track Switching Chart Grid On and Off 2.13 Chartplotter On 2.4 Cursor Data Box On and Off 2.13 Databoxes On/Off 2.14, 3.18 Display On and Off 2.4 Range Rings On and Off 2.13 Scanner Off 2.4 Symbol Marks 7.12, 7.13 MOB 4.5, 6.6 Waypoint 5.8, 5.13, 7.17, 7.19 Synchronize Chart and Radar 1.9, 2.20, 7.17

System Connections 8.20 Grounding 8.20 Set Up 7.2, 7.4 т Target (Chart) 5.30 Arrival 5.30, 5.32 Goto 5.30, 5.33 Waypoint 5.30, 5.33 Targets (Radar) 1.3, 2.3 Control 3.5 Expansion 3.5, 3.11, 3.12 Interference Rejection 3.5, 3.11, 3.12 Wakes 3.5, 3.11 Wakes 3.12 Temperature Data Box 7.4 Terminology 1.2 Tide Data 5.4, 5.5 Tide Set/Drift Data Box 7.4 Tide Vector 7.17, 7.19 Time Data Box 7.4 Time Format 7.5, 7.10 Time Offset 7.5, 7.10 Timed Transmit Mode 1.3, 7.12, 7.13 Timers Alarm Clock 6.4 Countdown 6.4 Setting 6.1 Trackpad 1.3, 1.12, 2.19 Tracks Clearing 5.38, 5.40 Converting to Route 5.42 Database List 5.40 Managing 5.38, 5.40 Naming 5.40 Using the ST60/80 Navigator Keypad 5.17 Saving 5.40 Setting Up 5.38, 5.39 Transferring a Route 5.35 a Waypoint 5.8, 5.18, 5.35 Transmission Check 8.25 Transmit Mode 1.3, 2.2, 2.3 Tune Preset 7.16 Tuning the Receiver 3.5, 3.9 U Units 7.4, 7.8 User Cartridge 5.35 v Variation Source 7.5, 7.8 Vectors 7.17, 7.19 VMG Data Box 7.4 VRM (Variable Range Markers) 3.1, 3.13

VRM/EBL 3.14, 3.15, 3.16 Data Box 3.18 Effect of Heading Mode 4.3 VRM/EBL Key 1.14, 3.13, 3.14, 6.1, 6.3 W WAAS B.6 Wakes 3.5, 3.11 Clearing 3.12 Warranty 1.iii Waypoint 2.14, 4.1, 7.17, 7.19, 8.30 Adding to a Route 5.18, 5.28 Data Box 7.4 Data Display 5.8, 5.12, 5.25 Database List 5.8, 5.9, 5.13, 5.14, 5.19, 5.33 Displaying 2.14 Editing 5.8 Editing Details 5.13 Erasing 5.8, 5.14 Goto 5.30, 5.33 Loading from a User Cartridge 5.35 MOB 4.5, 6.6 Moving 5.9, 5.14, 5.18, 5.27 Naming 5.8, 5.13 Numbers 7.17, 7.19 Placing 5.8, 5.9, 5.19 Position 5.8, 5.13 Removing from a Route 5.18, 5.28 Saving to a User Cartridge 5.35 Selecting 5.8, 5.12 Symbol 5.8, 5.13, 7.17, 7.19 Target 5.30, 5.33 Transferring 5.8, 5.18, 5.35 Transferring on NMEA 5.35 Transferring on SeaTalk 5.35 Waypoint List Creating a Route 5.20 Wind Data Box 7.4 Window Options BDI 1.5, 2.10 CDI 1.5, 2.10 Chartplotter 2.10 Full Screen 1.4 Half Screen 1.4, 2.7 Nav Data 2.10 Radar 2.10 World Map 1.9, 5.2 Х XTE (Cross Track Error) Data Box 7.4 Restart 5.30, 5.33 Ζ Zoom 1.6, 1.9, 2.16

# **Limited Warranty Certificate**

Raymarine warrants each new Light Marine/Dealer Distributor Product to be of good materials and workmanship, and will repair or exchange any parts proven to be defective in material and workmanship under normal use for a period of 2 years/24 months from date of sale to end user, except as provided below.

Defects will be corrected by Raymarine or an authorized Raymarine dealer. Raymarine will, except as provided below, accept labor cost for a period of 2 years/24 months from the date of sale to end user. During this period, except for certain products, travel costs (auto mileage and tolls) up to 100 round trip highway miles (160 kilometres) and travel time of 2 hours, will be assumed by Raymarine only on products where proof of installation or commission by authorized service agents, can be shown.

## **Warranty Limitations**

Raymarine Warranty policy does not apply to equipment which has been subjected to accident, abuse or misuse, shipping damage, alterations, corrosion, incorrect and/or non-authorized service, or equipment on which the serial number has been altered, mutilated or removed.

Except where Raymarine or its authorized dealer has performed the installation, it assumes no responsibility for damage incurred during installation.

This Warranty does not cover routine system checkouts or alignment/calibration, unless required by replacement of part(s) in the area being aligned.

A suitable proof of purchase, showing date, place, and serial number must be made available to Raymarine or authorized service agent at the time of request for Warranty service.

Consumable items, (such as: Chart paper, lamps, fuses, batteries, styli, stylus/drive belts, radar mixer crystals/diodes, snap-in impeller carriers, impellers, impeller bearings, and impeller shaft) are specifically excluded from this Warranty.

Magnetrons, Cathode Ray Tubes (CRT), TFT Liquid Crystal Displays (LCD) and cold cathode fluorescent lamps (CCFL), hailer horns and transducers are warranted for 1 year/12 months from date of sale. These items must be returned to a Raymarine facility.

All costs associated with transducer replacement, other than the cost of the transducer itself, are specifically excluded from this Warranty.

Overtime premium labor portion of services outside of normal working hours is not covered by this Warranty.

Travel cost allowance on certain products with a suggested retail price below \$2500.00 is not authorized. When/or if repairs are necessary, these products must be forwarded to a Raymarine facility or an authorized dealer at owner's expense will be returned via surface carrier at no cost to the owner.

Travel costs other than auto mileage, tolls and two (2) hours travel time, are specifically excluded on all products. Travel costs which are excluded from the coverage of this Warranty include but are not limited to: taxi, launch fees, aircraft rental, subsistence, customs, shipping and communication charges etc. Travel costs, mileage and time, in excess to that allowed must have prior approval in writing.

### TO THE EXTENT CONSISTENT WITH STATE AND FEDERAL LAW:

(1) THIS WARRANTY IS STRICTLY LIMITED TO THE TERMS INDICATED HEREIN, AND NO OTHER WARRANTIES OR REMEDIES SHALL BE BINDING ON RAYMARINE INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABLE OR FITNESS FOR A PARTICULAR PURPOSE.

(2) Raymarine shall not be liable for any incidental, consequential or special (including punitive or multiple) damages.

All Raymarine products sold or provided hereunder are merely aids to navigation. It is the responsibility of the user to exercise discretion and proper navigational skill independent of any Raymarine equipment.

## **Raymarine**

## **Factory Service Centers**

#### **United States of America**

Raymarine Inc 22 Cotton Road, Unit D Nashua, NH 03063-4219, USA

Telephone: +1 603 881 5200 Fax: +1 603 864 4756 www.raymarine.com

Sales & Order Services Telephone: +1 800 539 5539 Ext. 2333 or +1 603 881 5200 Ext. 2333

**Technical Support** Telephone: +1 800 539 5539 Ext. 2444 or +1 603 881 5200 Ext. 2444 Email: techsupport@raymarine.com

Product Repair Center Telephone: +1 800 539 5539 Ext. 2118

#### UK, Europe, Middle East, Far East

Raymarine Ltd Anchorage Park, Portsmouth PO3 5TD, England

Telephone: +44 (0)23 9269 3611 Fax: +44 (0)23 9269 4642 www.raymarine.com

**Customer Support** Telephone: +44 (0)23 9271 4713 Fax: +44 (0)23 9266 1228

Email: techsupport@raymarine.com

	Stick barcode label here
Purchased from	Purchase date
Dealer address	
Installed by	Installation date
Commissioned by	
	Commissioning date
Owner's name	
Mailing address	

This portion should be completed and retained by the owner.